Brackets for Cameras without Built-in or Accessory Grips





Features:

- Pivoting flash arm keeps the flash centered above the lens for both horizontal and vertical compositions.
- Supplied with a machined, positive-locking shoe mount that is interchangeable with an optional handle mount.
- Strong, lightweight, aluminum construction with baked-on finish for hard use and durability.
- High-density, neoprene foam side grip for comfortable shooting or carrying.

LIGHT, FAST, LOW-PRICED!

Quick Flip Specifications

Net Weight: 10 oz. (Quick Flip 350) 12 oz. (Quick Flip 120) Bracket Height: 9.5" Nominal Lens-to-Flash Distance: 12" Includes: Shoe mount,* 1/4"-20 camera mounting knob Suggested Accessories: Camera Auto Quick Release, Cord Wrap Catalog Number: 310-635 (Quick Flip 350) Catalog Number: 310-666 (Quick Flip 120)

NOTE: Quick Flip models do not accept Camera Anti-Twist Plates.

Stroboflip

The most compact approach to flash rotation.

The Stroboflip is an ultra-compact, "gripless," flash-rotating bracket. It cradles the camera unobtrusively while maintaining an over-the-lens flash position. Its design lets you hold the camera, rather than a grip, and rotate the flash for horizontal or vertical composition. An additional advantage is that the stress and weight of the flash unit is transferred from the light-duty camera shoe to the rugged Stroboframe mount. The Stroboflip is made for shoe-type flash units.

Features:

- Accepts all 35mm SLRs and smaller 6 x 4.5mm cameras.
- Supplied with a machined, positive-locking shoe mount and a 35mm Anti-Twist Plate (interchangeable with other AT Plates).

Stroboflip

• Strong, lightweight aluminum construction with baked-on finish for hard use and durability.



* Stroboflip and Quick Flip brackets are not compatible with Metz quick release mounts. For Metz or other handle-type flash, use Bracket Handle Mount (#300-HAN), sold separately.

Stroboframe • Stroboframe