

microSTATION

MUSIC WORKSTATION



EDS-i Enhanced Definition
Synthesis - integrated

REMS GENERAL **MIDI**

External Setups

KORG

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
0	KORG	KLC M1		Name	OSC BAL	RESO	CUTOFF	EG INT	Click the "KORG" logo. Select "Load Controller Map..." from the displayed KORG logo menu. Load the controller settings file "M1.cmap" from the "Presets" folder that's located inside the folder where the KORG Legacy Collection is installed.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	CC#71	CC#74	CC#79	
1		KLC M1 Le		Name	OSC BAL	Free	CUTOFF	EG INT	Click the "KORG" logo. Select "Load Controller Map..." from the displayed KORG logo menu. Load the controller settings file "M1 Le.cmap" from the "Presets" folder that's located inside the folder where the KORG Legacy Collection is installed.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	off	CC#74	CC#79	
2		KLC WAVESTATION		Name	Vector X	Vector Y	Free	Free	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#16	CC#17	off	off	
3		KLC MS-20	[A]	Name	VCO 1 WAVE FORM	VCO 2 WAVE FORM	HPF CUTOFF	LPF CUTOFF	Click the "KORG" logo. Select "Load Controller Map..." from the displayed KORG logo menu. Load the controller settings file "MS-20.cmap" from the "Presets" folder located inside the folder where the KORG Legacy Collection is installed.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#82	CC#28	CC#74	
4		KLC Polysix	[B]	Name	VCO 1 LEVEL	VCO 2 LEVEL	HPF PEAK	LPF PEAK	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#20	CC#21	CC#29	CC#71	
5		KLC Polysix	[A]	Name	VCO WAVE FORM	VCO PWM ADJUST	VCF CUTOFF	VCF RESONANCE	Click the "KORG" logo. Select "Load Controller Map..." from the displayed KORG logo menu. Load the controller setting file "Polysix.cmap" from the "Presets" folder located inside the folder where the KORG Legacy Collection is installed.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#14	CC#74	CC#71	
6		KLC Polysix	[B]	Name	MG FREQUENCY	MG DELAY TIME	MG LEVEL	EG ATTACK	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#27	CC#24	CC#76	CC#73	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
7	KORG	KLC LegacyCell	[Encoder]	Name	Encoder 1	Encoder 2	Encoder 3	Encoder 4	Click the controller logo on the "PERFORMANCE" page. Select "Load Controller Map..." from the displayed controller menu. Load the controller setting file "LegacyCell.cmap" from the "Presets" folder that's located inside the folder where the KORG Legacy Collection is installed.
8				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#28	CC#29	CC#30	CC#31	
9			[Slider]	Name	Slider 1	Slider 2	Slider 3	Slider 4	
10				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#15	CC#5	CC#20	
11	KORG	KLC Mono/Poly	[A]	Name	XMOD INT	FREQ MOD	PWM INT	VCF Cut	Click the "FILE" button at the bottom of the screen. Click the "LOAD" button in the display and make the popup menu appear. Choose "Controller Map..." from the popup menu. Load the controller setting file "MonoPoly.cmap" from the "Presets" folder located inside the folder where the KORG Legacy Collection is installed.
12				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#12	CC#13	#CC15	#CC74	
13			[B]	Name	VCF EG ATTACK	VCF EG DECAY	VCF EG SUSTAIN	VCF EG RELEASE	
14				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	#CC28	#CC29	#CC30	#CC31	
11	KORG	microKORG	[A]	Name	OSC 1 Wave	Filter Cutoff	Filter Resonance	Filter EG Int	1: Connect the microSTATION's MIDI OUT jack to the microKORG's MIDI IN jack with a MIDI cable. 2: Set the EDIT SELECT 2 knob to "MIDI". Move Knob 1 to set the MIDI CH to "1". Move Knob 3 to set the CLOCK to "Ext". 3: Set the EDIT SELECT 2 knob to "GLOBAL". Move Knob 4 to set the POSITION to "PrE" (Pre TG). 4: Press the 4 key while holding the SHIFT key to enter MIDI Filter settings. Move Knob 1 to select "P-E" (PROGRAM CHANGE Enabled). Move Knob 2 to select "C-E" (CONTROL CHANGE Enabled). Move Knob 3 to select "b-E" (PITCH BEND Enabled).
12				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#74	CC#71	CC#79	
13			[B]	Name	OSC 1 Control2	OSC 2 Tune	OSC 1 Level	OSC 2 Level	
14				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#15	CC#19	CC#20	CC#21	
13	KORG	microKORG XL	[A]	Name	Filter1 Balance	Filter1 Cutoff	Filter1 Resonance	Drive/WS Depth	1: Connect the microSTATION's MIDI OUT jack to the microKORG XL's MIDI IN jack with a MIDI cable. 2: Set the KNOB FUNCTION SELECT dial to "FULL EDIT". 3: Move Knob 1 to set the page to "MIDI". Move Knob 2 to set the parameter to "MIDI CH". Move Knob 3 to set the value to "01". Move Knob 2 to set the parameter to "CLOCK". Move Knob 3 to set the value to "EXT MIDI". 4: Move Knob 1 to set the page to "GLOBAL". Move Knob 2 to set the parameter to "POSITION". Move Knob 3 to set the value to "PRE TG". 5: Move Knob 1 to set the page to "MIDI FLT". Move Knob 2 to set the parameter to "PROG CHG". Move Knob 3 to set the value to "ENABLE". Move Knob 2 to set the parameter to "CTRL CHG". Move Knob 3 to set the value to "ENABLE". Move Knob 2 to set the parameter to "P.BEND CHG". Move Knob 3 to set the value to "ENABLE".
14				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#27	CC#74	CC#71	CC#83	
13			[B]	Name	EG2(AmpEG) Attack	EG2(AmpEG) Release	MFX1 We/Dry	MFX2 We/Dry	
14				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#73	CC#72	CC#115	CC#116	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
15	KORG	RADIAS	[A]	Name	OSC1 Wave	Filter 1 Cut	Filter 1 Resonance	Filter 1 Balance	1: Connect the microSTATION's MIDI OUT jack to the RADIAS' MIDI IN jack with a MIDI cable. 2: Press the [GLOBAL] key to enter Global mode. Set "Position" on the "GLOBAL" page to "Pre TG". 3: Press the [PAGE] key to move to the "MIDI" page. Set "MIDI Ch" to "01" and "Clock" to "Ext-MIDI". 4: Press the [PAGE] key to move to the "MIDI FILTER" page. Set "ProgChg" to "o", "CtrlChg" to "o", "P.Bend" to "o".
16				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	CC#74	CC#71	CC#27	
17		R3	[A]	Name	OSC1 Control2	LFO 1 Frequency	OSC 2 Tune	Amp Level	
18				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#17	CC#90	CC#21	CC#7	
19	Ableton	Live	[Send]	Name	Track 1 Send	Track 2 Send	Track 3 Send	Track 4 Send	Load the "KORG microSTATION template.als" file. Select "Preferences..." in the "Options" menu (or select "Preferences..." from the "Live" menu on the Mac) to open the "Preferences" dialog. Set "Input" of "Remote Control" to "microSTATION(KEYBOARD)".
20				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#18	CC#18	CC#18	CC#18	
21			[Volume]	Name	Track 1 Pan	Track 2 Pan	Track 3 Pan	Track 4 Pan	
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#10	CC#10	CC#10	CC#10	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
22	Applied Acoustics Systems	Lounge Lizard EP-3	[A]	Name	Mallet Stiffness soft/hard	Mallet Force strength	Mallet Noise pitch	Mallet Noise decay	Select "Import..." from the "File" menu and load the setting file "KORG Midi Links.lx3".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#44	CC#45	CC#46	CC#47	
23		Ultra Analog VA	[B]	Name	Pickup Geometry Symmetry	Pickup Geometry Distance	Pickup Volume Input	Pickup Volume Output	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#52	CC#53	CC#54	CC#55	
24		String Studio VS	[A]	Name	OSC1 Detune	OSC1 PW	FILTER1 Cutoff	FILTER1 Q	Select "Import..." from the "File" menu and load the setting file "KORG Midi Links.axf" file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#44	CC#45	CC#46	CC#47	
25		Lounge Lizard Session	[B]	Name	FILTER1 ENV1 A	FILTER1 ENV1 D	FILTER1 ENV1 S	FILTER1 ENV1 R	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#52	CC#53	CC#54	CC#55	
26		Ultra Analog Session	[A]	Name	Chorus Mix	Chorus Depth	Chorus Rate	Delay Mix	Select "Import..." from the "File" menu and load the setting file "KORG Midi Links.sxf" file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#44	CC#45	CC#46	CC#47	
27		Lounge Lizard Session	[B]	Name	Excitator Prot (Force, Mass)	Excitator Stiff (Friction)	Excitator Velocity	Filter Cutoff	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#102	CC#103	CC#104	CC#105	
28				Name	Piano	Tune	Tremolo Depth	Tremolo Speed	Select "Import..." from the "File" menu and load the setting file "KORG Midi Links.lls" file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#71	CC#70	CC#92	CC#79	
29		Ultra Analog Session		Name	Keyboard Glide	Filter Cutoff	Filter Q	Filter Env Attack	Select "Import..." from the "File" menu and load the setting file "KORG Midi Links.us" file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#5	CC#74	CC#71	CC#85	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
30	Arturia	minimoog V	[A]	Name	Wave Osc 1	Wave Osc 2	Wave Osc 3	Cutoff	Copy the setting file "controlMidi" into the following folder: Windows: The "save" folder is located inside the folder where minimoog V is installed. (e.g. C:\Program Files\Arturia\minimoog V\save) Mac: /Library/Preferences/minimoog V/save folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.
31				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
32				CC#/Note	CC#16	CC#17	CC#18	CC#74	
33		CS-80V	[B]	Name	Level Osc 1	Level Osc 2	Level Osc 3	Level Ext	
34				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
35				CC#/Note	CC#80	CC#81	CC#82	CC#83	
36	ARP2600 V	moog modular V	[A]	Name	Attack Time Vca 1	Decay Time Vca 1	Sustain Level Vca 1	Release Time Vca 1	Copy the setting file "controlMidi" into the following folder: Windows: The "save" folder is located inside the folder where CS-80V is installed. (e.g. C:\Program Files\Arturia\CS-80V\save) Mac: /Library/Preferences/Cs80V/save folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.
37				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
38				CC#/Note	CC#92	CC#94	CC#95	CC#96	
39		ARP2600 V	[B]	Name	HighPass 1 Cutoff	HighPass 1 Resonance	LowPass 1 Cutoff	LowPass 1 Resonance	
40				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
41				CC#/Note	CC#65	CC#66	CC#67	CC#68	
42		ARP2600 V	[A]	Name	Filter 1 Cutoff Frequency	Filter 1 Resonance	Filter 2 Cutoff Frequency	Filter 2 Resonance	Copy the setting file "controlMidi" into the following folder: Windows: The "save" folder is located inside the folder where Moog Modular V is installed. (e.g. C:\Program Files\Arturia\Moog Modular V\save) Mac: /Library/Preferences/MoogModularV/save folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.
43				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
44				CC#/Note	CC#80	CC#16	CC#81	CC#17	
45		ARP2600 V	[B]	Name	125Hz Band Gain	350Hz Band Gain	1000Hz Band Gain	2800Hz Band Gain	
46				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
47				CC#/Note	CC#106	CC#107	CC#108	CC#109	
48		ARP2600 V	[A]	Name	PORTAMENTO TIME	DELAY Dry/Wet	DELAY time L	DELAY time R	Copy the setting file "controlMidi" into the following folder: Windows: The "save" folder inside the folder where ARP2600 V is installed. (e.g. C:\Program Files\Arturia\ARP2600 V\save) Mac: /Library/Preferences/arp2600v/save folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.
49				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
50				CC#/Note	CC#44	CC#45	CC#46	CC#47	
51		ARP2600 V	[B]	Name	INT.FIRTER FREQUENCY	RESONANCE	ADSR	FILTER TYPE	
52				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
53				CC#/Note	CC#52	CC#53	CC#54	CC#55	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting					
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT	
38	Arturia	Prophet V	[V]	Name	Osc A PW	Filter Cutoff	Filter Resonace	Filter Env Amount	Copy the setting file "controlMidi" into the following folder: Windows: The "save" folder is located inside the folder where Prophet V is installed. (e.g. C:\Program Files\Arturia\ProphetV\save) Mac: /Library/Preferences/prophetv/save folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.	
39				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#20	CC#74	CC#71	CC#79		
40		Analog Factory	[A]	Name	Filter Env Amount	Filter Cutoff	Filter Resonace	Volume	Copy the setting file "midi.prefs" into the following folder: Windows: The "save" folder inside the folder where Analog Factory is installed. (e.g. C:\Program Files\Arturia\Analog Factory\save) Mac: /Library/Preferences/AnalogFactory folder This operation will overwrite the previous MIDI Control settings. If necessary, back up the previous controlMidi file.	
41				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#69	CC#30	CC#68	CC#83		
42	Apple	GarageBand		Name	Level	Cut Off	Resonance	LFO Rate		
43	Expansion	BFD		Ch	Global Ch	Global Ch	Global Ch	Global Ch		
44				CC#/Note	CC#7	CC#74	CC#71	CC#90		
45				Name	Param 1	Param 2	Param 3	Param 4	Click the "Load" icon (located in the upper right corner of the BFD window) to load the "BFD_KORG.bfd" file.	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#18	CC#19	CC#16	CC#17		
				Name	Pan	Volume	Free	Free		
				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#10	CC#7	off	off		
				Name	Direct Master Level	Overhead Level	Room Level	PZM Level		
				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#16	CC#17	CC#18	CC#19		
				Name	Kick Trim	Snr Trim	HiH Trim	F Tom Trim		
				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#52	CC#53	CC#54	CC#55		
				Name	Kick Tune	Snr Tune	HiH Tune	F Tom Tune		
				Ch	Global Ch	Global Ch	Global Ch	Global Ch		
				CC#/Note	CC#44	CC#45	CC#46	CC#47		

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
46	GMEDIA	impOSCar		Name	Filter Frequency	Filter Q	Filter Separation	Filter Amount	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#73	CC#52	
47	GMEDIA	M-Tron		Name	Volume	Tone	Pitch	Amp Env Attack	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#7	CC#74	CC#95	CC#73	
48	GMEDIA	Oddity		Name	VCF Cutoff Frequency	VCF Resonance	HPF Cutoff Freq Q	LFO Freq Q	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#9	CC#8	
49	Image-Line Software	minimonsta		Name	Filter Emphasis	Filter Cutoff	Filter Contour	VCF Attack	For stand-alone operation Windows: Click the "SET UP" button in the lower right part of the "minimonsta" window to open the menu. Click on "Input device" and select "microSTATION KEYBOARD". Mac: Click the "SET UP" in the lower right part of the "minimonsta" window to open the menu. Click on "Input device" and select "CoreMIDI".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#71	CC#74	CC#70	CC#20	
50	Image-Line Software	FL Studio	[Pan]	Name	Master Pan	FX1 Pan	FX2 Pan	FX3 Pan	For stand-alone and plug-in synthesizer operation Select "MIDI settings" (located in the "OPTIONS" menu in the upper left corner of FL STUDIO window), and select "microSTATION 1 KEYBOARD". Select "Open" from the "FILE" menu, and load the "KORG microSTATION.flp" file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#16	CC#17	CC#18	CC#19	
51			[Volume]	Name	Master Volume	FX1 Volume	FX2 Volume	FX3 Volume	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#80	CC#81	CC#82	CC#83	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
52	MOTU	MachFive		Name	Filter Cutoff	Filter Resonance	Drive	Transpose	Select "Open..." from the "File" menu and open the song file "DP_microSTATION".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#75	CC#76	
53	Native Instruments	DP (Digital Performer)	[Pan]	Name	Track 1 Pan	Track 2 Pan	Track 3 Pan	Track 4 Pan	Select "Open..." from the "File" menu and open the song file "DP_microSTATION".
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#10	CC#10	CC#10	CC#10	
54			[Level]	Name	Track 1 Level	Track 2 Level	Track 3 Level	Track 4 Level	
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#7	CC#7	CC#7	CC#7	
55	Native Instruments	B4	[A]	Name	PERCUSSION VOL-UME	PERCUSSION DECAY	VIBRATO MIX	VIBRATO DEPTH	Select "Open..." from the "File" menu and open the song file "DP_microSTATION".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#70	CC#71	CC#73	CC#74	
56			[B]	Name	UPPER MANUAL 16'	UPPER MANUAL 5 1/3'	UPPER MANUAL 8'	UPPER MANUAL 4'	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#12	CC#13	CC#14	CC#15	
57	Native Instruments	B4 II	[A]	Name	PERCUSSION VOL-UME	PERCUSSION DECAY	VIBRATO MIX	VIBRATO DEPTH	Select "Open..." from the "File" menu and open the song file "DP_microSTATION".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#70	CC#71	CC#73	CC#74	
58			[B]	Name	Upper Drawbar 16'	Upper Drawbar 5 1/3'	Upper Drawbar 8'	Upper Drawbar 4'	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#12	CC#13	CC#14	CC#15	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
59	Native Instruments	Battery		Name	Controller A	Controller B	Controller C	Controller D	Press the "OPTIONS" button and open the Preference dialog. Set the MIDI controllers as below. A: CC#0, B: CC#1, C: CC#2, D: CC#3, E: CC#4, F: CC#5, G: CC#6, H: CC#7
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#0	CC#1	CC#2	CC#3	
60	Native Instruments	Elektrik Piano		Name	Sound Control Knob 1	Sound Control Knob 2	Sound Control Knob 3	Sound Control Knob 4	Press the "OPTIONS" button to open the "Settings" dialog. Confirm that "USE STD. CC#7 / CC#10 VOLUME & PAN" is active. In case it is not active, click it.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#20	CC#21	CC#22	CC#23	
61	Native Instruments	FM7	[A]	Name	Easy Edit Timbre Brightness	Easy Edit Timbre Harmonic	Easy Edit Timbre Detune	Easy Edit Timbre Env Amount	On the "MASTER" page, locate the "CONTROLLER DEFINE" parameters then press the "LOAD" button for "CONTROLLER ASSIGN" to load the setup file "KORG microSTATION.f7c".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#102	CC#103	CC#104	CC#105	
62	Native Instruments	FM7	[B]	Name	Filter Cutoff	Filter 1 Resonance	Filter Envelope Amount	Filter 1 Mode	On the "MASTER" page, locate the "CONTROLLER DEFINE" parameters then press the "LOAD" button for "CONTROLLER ASSIGN" to load the setup file "KORG microSTATION.f7c".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#111	CC#112	CC#113	CC#110	
63	Native Instruments	FM8	[A]	Name	Timbre Harmonic	Timbre Detune	Timbre Brightness	Timbre Env Amount	On the "MASTER" page, locate the "MIDI Controller Assignment" parameters then press the "LOAD" button for "CONTROLLER ASSIGN" to load the setup file "KORG MIDI Assignment.f8c".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#83	CC#20	CC#74	CC#79	
64	Native Instruments	FM8	[B]	Name	LFO Rate	LFO Vibrato	LFO Timbre	LFO Tremolo	On the "MASTER" page, locate the "MIDI Controller Assignment" parameters then press the "LOAD" button for "CONTROLLER ASSIGN" to load the setup file "KORG MIDI Assignment.f8c".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#90	CC#103	CC#104	CC#105	
65	Native Instruments	Massive		Name	Filter 1 Cutoff	Filter 1 Resonance	Filter 2 Cutoff	Filter 2 Resonance	1: Copy the setting file "KORG MIDI Setup.mca" into the following folder. Windows: The "mca" folder is located in the folder where the Massive is installed. (e.g. C:\Program Files\Native Instruments\Massive\mca) Mac:/Library/Application Support/Native Instruments/Massive/mca 2: Select "Preference..." in "Massive" menu to open "Massive Options". Double-Click "KORG MIDI Setup" in the "Midi Setups" of "Midi" page to turn it "on".
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#30	CC#68	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
66	Native Instruments	PRO-53		Name	Oscillator A Pulse Width	Oscillator B Pulse Width	Filter Cutoff	Filter Resonance	Click the "NI" logo. Select "Load Controllermap" in the displayed menu and load "DefaultMap.txt" from the "Presets"- "Controller maps" folder inside the folder where PRO-53 is installed.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#43	CC#55	CC#70	CC#71	
67	Propellerhead	Reason	[Pan]	Name	Channel 1 Pan	Channel 2 Pan	Channel 3 Pan	Channel 4 Pan	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#23	CC#24	CC#25	CC#26	
68			[Volume]	Name	Channel 1 Level	Channel 2 Level	Channel 3 Level	Channel 4 Level	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	CC#9	CC#10	CC#12	
69		Dr.Rex		Name	Filter Freq	Filter Res	Filter Mode	Filter Env Amount	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#76	CC#18	
70		Malstrom		Name	OSC A motion	OSC A shift	Filter A res	Filter A Freq	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#92	CC#86	CC#78	CC#79	
71		NN-19		Name	Filter Freq	Filter Res	Filter Mode	Filter Env Attack	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#76	CC#14	
72		NN-XT		Name	Filter Freq	Filter Res	Amp Env Attack	Amp Env Decay	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#73	CC#9	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
73	Propellerhead	ReDrum	[Pan]	Name	Drum 1 Pan	Drum 2 Pan	Drum 3 Pan	Drum 4 Pan	Load the "StylusRMX_KORG.mlt_rmx" as the MIDI Learn set file.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#19	CC#20	CC#21	CC#22	
74			[Level]	Name	Drum 1 Level	Drum 2 Level	Drum 3 Level	Drum 4 Level	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	CC#9	CC#10	CC#12	
75			[Pitch]	Name	Drum 1 Pitch	Drum 2 Pitch	Drum 3 Pitch	Drum 4 Pitch	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#51	CC#52	CC#53	CC#54	
76		Subtractor		Name	OSC 1 Phase	OSC 2 Phase	FM	MIX	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#93	CC#106	CC#108	CC#107	
77	Spectrasonics	Atmosphere		Name	Layer A Pan	Layer A Level	Layer B Pan	Layer B Level	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#83	CC#81	CC#84	CC#82	
78		Stylus RMX	[A]	Name	FILTER LFOS RATE	FILTER LFOS DEPTH	FILTER LFOS WAVE	CHAOS DOWN/UP	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#16	CC#17	CC#18	CC#19	
79			[B]	Name	CHAOS PATTERN	CHAOS REPEAT	CHAOS REVERSE	SAMPLE START	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#80	CC#81	CC#82	CC#83	
80		Trilogy		Name	Layer A Pan	Layer A Level	Layer B Pan	Layer B Level	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#83	CC#81	CC#84	CC#82	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
81	Steinberg	Cubase	[Audio Pan]	Name	Audio Pan1	Audio Pan2	Audio Pan3	Audio Pan4	First, you need to install the KORG USB/MIDI driver. 1: Select "Device Setup..." from the "Devices" menu and open the "Device setup" dialog. Select "Generic Remote" from the "Devices" list in the left column. Select "keyboard" for the "MIDI input" and press the "Import" button. Load "Cubase_KORG.xml". (If you do not find "Generic Remote" in the left column, please add it using the "Add/Remove" function.) 2: Press the "Apply" button.
82				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
83				CC#/Note	CC#10	CC#10	CC#10	CC#10	
84			[Audio Level]	Name	Audio Level 1	Audio Level 2	Audio Level 3	Audio Level 4	
85				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
86				CC#/Note	CC#7	CC#7	CC#7	CC#7	
87			[MIDI Pan]	Name	MIDI Pan1	MIDI Pan2	MIDI Pan3	MIDI Pan4	
88				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#41	CC#41	CC#41	CC#41	
			[MIDI Level]	Name	MIDI Level 1	MIDI Level 2	MIDI Level 3	MIDI Level 4	
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#35	CC#35	CC#35	CC#35	
			A1	Name	Oscillator 1 FM	Filter Cutoff	Filter Resonance	Filter Drive	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#74	CC#71	CC#29	
			Monologue	Name	OSC1 DEPTH	OSC2 PWM	OSC2 DEPTH	FX OVER DRIVE	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#103	CC#19	CC#105	CC#70	
			Tonic	Name	ENV MOD ATTACK	ENV MOD RELEASE	RES	CUTOFF	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#73	CC#72	CC#71	CC#74	
			Embracer	Name	OSC1 WAVE	OSC1 TONE	OSC1 WIDTH	OSC2 WAVE	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#9	CC#74	CC#16	CC#14	

					1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting				
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
89	Steinberg	Groove Agent		Name	Kick Volume	Snare Volume	Tom Volume	Hi-Hat Volume	In the host application, change the MIDI output channel for the MIDI track you want to use "Groove Agent" on to "ANY" or other multi-channel outputs.
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#73	CC#73	CC#73	CC#73	
90	Steinberg	HALion		Name	DCF CUTOFF	DCF RESONANCE	DCF VELOCITY	DCF ENV. AMOUNT	Enable "RECEIVE MIDI CONTROLLER" in "KEY/CONTROL OPTION" of the "OPTIONS" page.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#15	CC#80	
91	Steinberg	Hypersonic		Name	GM Edit: cutoff	GM Edit: resonance	GM Edit: filt env att	GM Edit: filt env dec+rel	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#74	CC#71	CC#77	CC#78	
92	Steinberg	Virtual Guitarist		Name	Shuffle	Dynamics	Timing	Decay	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#76	CC#79	CC#78	CC#75	
93	Waldorf	Attack		Name	Osc 1 Pitch	Osc 1 Level	Osc 2 Pitch	Osc 2 Level	In the host application, change the MIDI output channel for the MIDI track on which "Attack" is used for each of the sounds that you want to remote-control such as kick, snare, drum, etc.
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#13	CC#28	CC#22	CC#30	
94	ToonTrack	PPG Wave 2.V		Name	BASIS	VCF-CUTOFF	VCF-EMPHASIS	ENV1>VCF	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#8	CC#74	CC#71	CC#28	
95	ToonTrack	dfh		Name	Free	Free	Free	Free	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	Off	Off	Off	Off	
96	ToonTrack	EZ Drummer		Name	Free	Free	Free	Free	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	Off	Off	Off	Off	

									1: These operations will overwrite the previous MIDI Control settings. If necessary, back up the previous control Midi file. 2: When the MIDI channel settings of the host application and the plug-in software are the same, proper control may not be available. Please change the MIDI channel setting on either the host application or the plug-in software. Please refer to the application's manual for the correct setting
	Manufacturers	Product Name	Scene Variation		Knob 1	Knob 2	Knob 3	Knob 4	HINT
97	UltimateSoundBank	PLUGSOUND PRO	[Pan]	Name	Timbre 1 Pan	Timbre 2 Pan	Timbre 3 Pan	Timbre 4 Pan	
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#10	CC#10	CC#10	CC#10	
98		Ultra Focus	[Volume]	Name	Timbre 1 Volume	Timbre 2 Volume	Timbre 3 Volume	Timbre 4 Volume	
				Ch	Ch:01G	Ch:02	Ch:03	Ch:04	
				CC#/Note	CC#7	CC#7	CC#7	CC#7	
99		Charlie		Name	Filter Cutoff	Filter Resonance	Master filter cutoff	Master filter resonance	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#78	CC#74	CC#71	
100				Name	Filter Cutoff	Filter Resonance	Master filter cut frequency	Master filter resonance	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#78	CC#74	CC#71	
101		X-treme FX		Name	Filter Cutoff	Filter Resonance	Master filter cut frequency	Master filter resonance	
				Ch	Global Ch	Global Ch	Global Ch	Global Ch	
				CC#/Note	CC#77	CC#78	CC#74	CC#71	

Manufacturer Name

- KORG: These product names are the trademark or a registered trademarks of KORG Inc.
- Ableton: This product name is a trademark or a registered trademark of Ableton AG.
- Applied Acoustics Systems: These product names are the trademark or a registered trademarks of Applied Acoustics Systems DVM Inc.
- Arturia: These product names are the trademark or a registered trademarks of Arturia.
- Apple: This product name is a trademark or a registered trademark of Apple Inc.
- FXpansion: This product name is a trademark or a registered trademark of FXpansion Audio UK Ltd.
- GMEDIA: These product names are the trademark or a registered trademarks of GMEDIA Music.
- Image-Line Software: This product name is a trademark or a registered trademark of Image-Line Software.
- MOTU: These product names are the trademark or a registered trademarks of MOTU, Inc.
- Native Instruments: These product names are the trademark or a registered trademarks of Native Instruments GmbH.
- Propellerhead: These product names are the trademark or a registered trademarks of Propellerhead Software AB.
- Spectrasonics: These product names are the trademark or a registered trademarks of Spectrasonics.
- Steinberg: These product names are the trademark or a registered trademarks of Steinberg Media Technologies GmbH.
- Waldorf and the Waldorf Logo are registered trademarks of Waldorf Music GmbH.
- ToonTrack: These product names are the trademark or a registered trademarks of Toontrack Music AB.
- UltimateSoundBank: These product names are the trademark or a registered trademarks of Univers Sons, SA.

IMPORTANT NOTICE TO CONSUMERS

This product has been manufactured according to strict specifications and voltage requirements that are applicable in the country in which it is intended that this product should be used. If you have purchased this product via the internet, through mail order, and/or via a telephone sale, you must verify that this product is intended to be used in the country in which you reside.

WARNING: Use of this product in any country other than that for which it is intended could be dangerous and could invalidate the manufacturer's or distributor's warranty.

Please also retain your receipt as proof of purchase otherwise your product may be disqualified from the manufacturer's or distributor's warranty.

KORG KORG INC.

4015-2 Yanokuchi, Inagi-city, Tokyo 206-0812 Japan