



Quick Installation Guide

LCD Touchmonitor

www.elotouch.com

Revision C
P/N E893866

Elo Touch Solutions Technical Support

Online self-help: www.elotouch.com/go/websupport

North America

Elo Touch Solutions
301 Constitution Drive
Menlo Park, CA 94025
www.elotouch.com

Europe

Tel +32 (0)16 35 21 00
Fax +32 (0)16 35 21 01
elosales@elotouch.com

Technical Support contacts in your region:

www.elotouch.com/go/contactsupport

Asia-Pacific

Tel +81 (45) 478-2161
Fax +81 (45) 478-2180
www.tps.co.jp

Latin America

Tel 1-305-428-5210
Fax 1-305-717-4909
www.elotouch.com.ar

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.

Copyright © 2012 Elo Touch Solutions, Inc. All Rights Reserved.



① Power



④ OSD Remote (if applicable)



② Video



③ Touch



No touch driver installations needed
Aucune installation de pilote nécessaire tactile
No hay instalaciones de controlador toque necesario
Kein Touch-Treiber-Installationen notwendig
Nessun driver installazioni tocco necessario
Не прикасаться установок драйвера необходимы
タッチドライバをインストール不要
不需安裝觸摸驅動程序
不需安裝觸控驅動程式
필요 없음 터치 드라이버 설치 없음