

# Quick Start Guide

## GUVCD2800 Integrated Digital TV

# GRUNDIG


**1.** Install remote control batteries



**2.** Connect the aerial lead.



**3.** Plug in to the mains supply and switch on the mains socket.



Press the Power On/Off button on the front of the TV.

Power On/Off



**4.** Press any of the numeric buttons, P+ or P- to switch the TV on.




**5.** The message below will be displayed. Press SELECT to start the search for digital TV channels

Please ensure aerial is plugged in. Do you want to start first time installation?

Yes No

The search progression will be displayed as shown below.



**6.** Once the search for digital TV channels is complete the message below will be displayed. Press SELECT.


Do you want to search for analogue channels?

Yes No

When the warning message is displayed press ▼ to highlight CONTINUE and press SELECT.



**7.** The search progression will be displayed as shown below.



Once the search is complete the PROGRAM list will be briefly displayed and the TV will tune to the first channel found.

PROGRAM	PR	PR
01 BBC1	11	21
02 BBC2	12	22
03 ITV	13	23
04 CH 4	14	24
05 CH 5	15	25
06 C 40	16	26
07 C 43	17	27
08 C 46	18	28
09	19	29
10	20	30

NAME INSERT

DELETE AUTOSTORE

**8.** To switch between analogue and digital TV channels press the TV/DTV button.



Refer to the manual for detailed operating information.



# Connection Diagram

# GRUNDIG

This diagram shows a typical configuration with a recording device such as a DVD recorder or a video cassette recorder.  
Refer to the manual for how to set the EXT2 output to the digital TV channels so that they can be recorded.

