⊕ **AIPHONE**

# FLUSH-MOUNT ROUND SPEAKER

MODEL: *NB-L* (Sub station for NEM, NEM-A)

INSTALLATION MANUAL

❶ INSTALLATION

*Flush-mounting to ceiling;

1. Open a hole of 150 mmϕ (5-7/8"ϕ) in the ceiling.
2. Hook the speaker at one side to a spring of holder, and connect wires.
3. Hook the other side of the speaker, by pulling spring, and locate the speaker in the center of the hole.

HOLDER
CEILING
150 mm diameter (5-7/8")
SPRING
HOOK   HOOK

*Flush-mounting to ceiling, using NBZ-M square frame;

1. Open a hole of 150 mmϕ (5-7/8"ϕ) in the ceiling.
2. Attach the square frame to the speaker from the back.
3. Hook the speaker at one side to a spring of holder, and connect wires.
4. Hook the other side of the speaker, by pulling spring, and locate the speaker in the center of the hole.

HOLDER
CEILING
150 mm diameter (5-7/8")
SPRING
HOOK   HOOK
NBZ-M FRAME (attach to speaker)

❷ WIRING

(1) NB-L sub station, with call button;

COMMON (E)
LINE

CORRIDOR LAMP
NAR-3
NAR-4A

BLU GRN BLK RED ORG ORG
CONNECTOR
NB-L

RECEPTACLE & CALL BUTTON
NAR-1A &
NBR-8A

RESET BUTTON
NAR-2A

| 1 | 2 | 3 | ... | n | E |

MASTER
NEM
NEM-A
n: varies by master station model.

BLU : Blue
GRN : Green
BLK : Black
RED : Red
ORG : Orange

(2) When corridor lamp is installed;

Connect wires on the connector (female) and attach to the male connector.
When corridor lamp is installed, cut off green wire.

GREEN WIRE

INTERCOM SYSTEMS
⊕ **AIPHONE**
HOME, BUSINESS, INDUSTRY
Printed in Japan (E)