

Fisher-Price®


# Twirlin' Whirlin' Garden™

## Supplemental Instructions

Product Number: 71923

### We've Made a Change!

Please disregard assembly step 3 in the enclosed instructions and follow these instructions instead!



- Insert and snap the tabs on the rainbow backboard into the slots in the base.
- Insert and snap the flowers into the the base.
- Fit one of the the pegs at the center of the block rocker into a hole in the base. Press to snap the other peg on the block rocker into the hole in the base.

**Assembly is now complete. Please continue to read the instructions for play and care for important information!**