



Your CC comes standard with the ultimate in comfort, class and style. But that's just the beginning. You'll also discover dozens of sophisticated features that make driving it even more exhilarating. Because at Volkswagen, we want to be sure you get the most out of your time behind the wheel. So we've created this guide to take you through the finer points, and to show you how quickly you'll be speaking fluent Volkswagen.



Das Auto.

Learn more at vw.com/cc2012

BLUETOOTH®

CONNECTING YOUR BLUETOOTH EQUIPPED CELL PHONE TO YOUR CC

- 1 Make sure the CC is parked.
- 2 Make sure your cell phone is Bluetooth enabled.
- 3 Turn on the ignition. The Bluetooth feature goes into "discovery" mode for five minutes.
- 4 From your Bluetooth menu on your phone, search for new devices.
- 5 Your cell phone should offer a list of devices for you to choose from. Select the device "VW Phone."
- 6 Enter the passcode "0000" into your phone and press "pair." Your phone should be connected to the Bluetooth system.
- 7 The multi-function display will prompt you to create a user profile—press "OK."

NOTE: To allow Bluetooth to reconnect automatically each time you enter your car, be sure to set "VW Phone" as a "trusted device" on your phone (this varies from phone to phone, and may not be necessary on your specific device).

TO ANSWER AN INCOMING CALL

- ▶ When you get a call, Bluetooth will interrupt your radio. You'll hear a ringtone over your car's speakers.
- ▶ Press the phone button **A** on the multi-function steering wheel.



BLUETOOTH VOICE RECOGNITION

Just press and hold the microphone button **B** until you hear a musical chime. Your Volkswagen will say, "Main menu." Then proceed with one of the steps below.

DIAL BY NUMBER

- 1 After the beep, say "Dial number."
- 2 The system will respond "Number please."
- 3 After the beep, say the number. (You do not have to include "1" before the area code.)
- 4 The system will repeat the number, and then say "Continue."
- 5 To tell the system to call the number, say "Call."

DIAL BY NAME

- 1 After the beep, say "Call" followed by the name of the person you want to call. For example, "Call Mike Brown."
- 2 The system will answer "Calling Mike Brown."

REDIAL

- 1 After the beep, say "Redial."
- 2 The system will respond "Redial. Dialing."

HELP

- 1 After the beep, say "Help."
- 2 The system will respond "Help. Say a name plus 'call,' 'dial number,' 'redial.' You can also say 'music,' or 'further options.' To stop this dialogue at any time, say 'cancel.'"

Learn more at vw.com/cc2012

Important Warnings and Safety Information, which you must read, are listed on the last panel, under BLUETOOTH® WARNINGS.

PREMIUM 8 RADIO

TO SELECT AND SAVE A PRESET RADIO STATION

- 1 Push the power button to turn on the radio.
- 2 Press AM, FM or SAT to select a band.
- 3 Press the TUNE soft key **A**.
- 4 Use the knob at the lower right **B** to select a station. To make a selected station a preset station, press and hold any of the six preset station soft keys **C**. The new station will appear in the display.
- 5 To select a specific preset station, simply press the appropriate preset station soft key.



TO PLAY A CD

- 1 Press the LOAD/EJECT button **D**.
- 2 Press any of the six soft keys **E** to select a slot for the CD and then insert the CD.
- 3 Press the MEDIA hard key **F** and press CD to listen.



SATELLITE SIGNAL INTERRUPTION

Sometimes things like tall buildings and tunnels can interrupt the satellite signal. This is normal. The signal should return within a few moments as you drive. You can experience a wide variety of stations for free using your limited, complimentary subscription. Call SiriusXM Satellite Radio at 1-888-539-7474 for more information.

- BLUETOOTH® WARNINGS:**
Accidents and injuries can occur if the driver is distracted. Speaking on or using a phone while driving can distract the driver from traffic.
- Use of Bluetooth technology requires a compatible phone.
 - Select the volume settings so that the acoustic signals from the outside are still audible (for example, the sirens of emergency rescue vehicles). Observe legal regulations.
 - In areas with no or poor mobile network coverage and possibly in tunnels, garages and subways, phone conversations may be interrupted, and it may be impossible to make phone calls—even emergency calls!
 - In some countries, emergency calls may only be supported when the mobile phone is connected to a mobile phone package which has a SIM card that is "not blocked" and/or has sufficient credit on it.
 - Unmounted or improperly mounted mobile phones can fly around in the event of a sudden driving or braking maneuver or an accident. This may cause injuries.
 - Never place or mount a mobile phone on doors, on the windshield or on or near the area on the steering wheel marked "AIRBAG," the instrument panel, the seat backrests or the areas between these points and the driver/passengers. Mobile phones can lead to serious injuries in cases of accidents, especially when the airbags are inflated.
 - Always switch off your mobile telephone at gas stations or wherever there is a fire or explosion hazard. Electromagnetic radiation can cause sparks which can start fires.
 - The mobile phone will automatically connect to the mobile network when the Bluetooth connection to the mobile phone package is disconnected. Using a radio device in the vehicle without a connection to an external antenna might exceed electromagnetic radiation thresholds. This also applies if the external antenna is not installed properly.
 - Keep a distance of at least 8 inches between the antennas of the mobile phone and a pacemaker, since mobile phones can affect the functionality of a pacemaker.
 - Do not carry a mobile phone on standby mode in the breast pocket directly on top of a pacemaker.
 - If interference is suspected, immediately switch off the mobile phone.
 - The center armrest can interfere with the driver's elbow movement and thus cause accidents and severe injuries. Always keep the armrest closed while driving.

- PREMIUM 8 RADIO WARNINGS:**
Distracting the driver from traffic can lead to accidents and injuries. Using the radio system while driving can distract from traffic.
- Observe legal regulations.
 - Always drive attentively and responsibly.
 - Setting the volume too high can damage the hearing. This applies especially to volumes above approximately 85 decibels.
 - Select volume settings so that acoustic signals from the outside are always audible (for example, the sirens of emergency rescue vehicles).
 - Please lower the volume before changing or connecting to an audio source.
 - Unmounted or improperly mounted external devices can be thrown through the passenger compartment in the event of a sudden driving or braking maneuver or a collision, causing injury.
 - Never leave external devices in the doors, on the front windshield, on or near the area marked "AIRBAG" on the steering wheel, instrument panel, seat backs or between these areas and the occupants. External devices can cause serious injury in the event of a collision, especially if the airbags inflate.
 - Connecting cables of external devices may obstruct the driver. Route cables so as not to interfere with the driver.
 - The armrest can affect the elbow room of the driver and thus cause collisions and severe injuries. Always keep the armrest closed while driving.
 - Injuries can be caused by invisible laser beams if the housing of the CD player is opened.
 - Have the CD player repaired only by a specialist.

Important Warnings and Safety Information, which you must read, are listed on the last panel, under PREMIUM 8 RADIO WARNINGS.

This Guide is not a substitute for the Owner's Manual. You must read it and the warnings included in it.

CLIMATRONIC SYSTEM ▾



TO REGULATE THE TEMPERATURE

- ▶ Press the AUTO button **A**.
- ▶ Turn the left-side temperature dial **B** to the preferred temperature.

TO COOL THE INTERIOR QUICKLY

- ▶ Set the temperature dial between 64 and 68 degrees.
- ▶ If the AUTO function is already engaged, press the AUTO button again. This activates the HI AUTO function, which increases fan speed and activates the A/C automatically. Don't be concerned that the fan is loud; it is doing its job to create a comfortable environment as quickly as possible.

TO HEAT THE INTERIOR QUICKLY

- ▶ Set the temperature dial between 76 and 80 degrees.
- ▶ If the AUTO function is already engaged, press the AUTO button again. This activates the HI AUTO function, which increases fan speed. Don't be concerned that the fan is loud; it is doing its job to create a comfortable environment as quickly as possible.

TO DEFROST THE WINDSHIELD

- ▶ Press the MAX defrost button **C**. The A/C function comes on automatically to dry the air.
- ▶ When the windshield is clear, press the AUTO button again.

CRUISE CONTROL ▾

TO ACTIVATE

- ▶ Locate the cruise control stalk on the lower left-hand side of the steering column.
- ▶ Activate "Cruise" by pulling the lever toward you.



TO SET CRUISING SPEED

- ▶ When you get to your cruising speed, press the SET button at the end of the stalk, and then release. Now your car will remain at that speed without needing to use the accelerator. The CRUISE light, in the instrument cluster, will be green.
- ▶ To increase your speed to the nearest increment of 5 (45, 50, 55, etc.), press the stalk up.
- ▶ To decrease your speed to the nearest increment of 5 (45, 40, 35, etc.), press the stalk down.

TO DEACTIVATE

- ▶ To deactivate the cruise control, depress the brake pedal or push the stalk away from you.
- ▶ When you do this, the green cruise light shuts off.

Your set speed will remain in the cruise control memory. To recall it, pull the lever toward you and you'll feel the car return to its previous set speed. It will remain in memory until you turn your CC off.


KEY FOB ▾

LOCK

To lock all doors and the trunk, push the lock button **A** once.

UNLOCK

- ▶ To unlock the driver's door, push the unlock button **B** once.
- ▶ To unlock all doors and the trunk, press the unlock button twice, with a brief pause in between.



TRUNK

- ▶ To unlock the trunk only, press and hold the middle button **C** on the key fob until the trunk pops open. Push the VW logo and use the logo as a handle to open the trunk.
- ▶ To close the trunk, grab the ergonomic handles located near the outer corners and pull. Finish with a gentle push to help ensure it's securely closed.



MEMORY FUNCTION ▾

SETTING MEMORY SEATS AND MIRRORS

- 1 Close the door.
- 2 Insert the key in the ignition.
- 3 Turn the ignition on.
- 4 Adjust the seat and mirrors.
- 5 Press the SET button **A**, located above the power seat controls.
- 6 Within 10 seconds, press and hold one of the numbered memory buttons, also located above the power seat controls, until you hear a chime. That assigns your custom memory settings to that numbered memory button.



TWO WAYS TO RECALL MEMORY SEAT SETTINGS

- ▶ Briefly press the corresponding memory button when the door is open and the ignition is switched off OR...
- ▶ When door is closed or ignition is on, press and hold the corresponding memory button until the seat and mirrors move to your set memory position.

Learn more at vw.com/cc2012

⚠ CLIMATRONIC SYSTEM WARNINGS:

- Poor visibility increases the risk of collisions and other accidents that cause serious personal injuries.
- Always make sure all windows are clear of ice, snow, and condensation for good visibility to the front, sides, and rear.
 - Maximum heating output and defrosting performance are not possible until the engine has reached operating temperature. Wait until you have good visibility before driving off.
 - Always make sure you know how to properly use the heating and ventilation systems as well as the rear window defogger that you will need for good visibility.
 - Never use air recirculation for long periods of time. When the air conditioner is off and recirculation mode is on, condensation can quickly form on the windows and greatly reduce visibility.
 - Always switch off recirculation mode when it is not needed. Stale air causes driver fatigue and reduces driver alertness, which can cause accidents, collisions and serious personal injury.
 - Never switch off the fan for a long period of time and never use air recirculation for a long period of time because no fresh air will enter the passenger compartment.

⚠ CRUISE CONTROL WARNINGS:

- Using the cruise control when it is not possible to drive safely at a constant speed can be dangerous and can lead to an accident, with serious personal injury to you and your passengers.
- Never use cruise control when driving in heavy or varying traffic or when you cannot keep a safe distance between you and the vehicles ahead of you.
 - Never use cruise control on steep, winding, or slippery roads (such as gravel roads, wet roads, or snowy or icy roads) or on roads with standing water.
 - Never use cruise control when driving offroad or on unpaved roads.
 - Always adjust your speed and the distance you keep between you and the vehicles ahead of you to the road, traffic, weather, and visibility conditions.
 - To help prevent unintended operation of cruise control, switch the system off when it is not being used.
 - It is dangerous to use the Resume feature when the previously set speed is too high for the existing road, traffic, or weather conditions.
 - When traveling downhill, the cruise control may not be able to maintain a constant speed. The vehicle will speed up because of its own weight. Downshift and/or use the foot brake to slow the vehicle.

⚠ KEY FOB WARNINGS:

- Improper use of vehicle keys can result in serious personal injury.
- Always take the key with you when you leave the vehicle. It can be used to start the engine and operate vehicle systems such as the power windows, leading to serious personal injury. Children or other unauthorized persons could also lock the doors and the luggage compartment.
 - Never leave children, disabled persons, or anyone who cannot help themselves in the vehicle. The doors can be locked with the remote control key. This could result in people being trapped in the vehicle in an emergency. For example, depending on the time of year, people trapped in the vehicle can be exposed to very high or very low temperatures.
 - Heat build-up in the passenger and luggage compartment of a parked vehicle can result in temperatures in the vehicle that are much higher than outside temperatures, particularly in summer. Temperatures can quickly reach levels that can cause unconsciousness and death, particularly to small children.
 - Never remove the key from the ignition switch while the vehicle is moving or rolling to a stop. The steering wheel will lock and you will not be able to steer or control the vehicle.

⚠ MEMORY FUNCTION WARNINGS:

- Improper use of electrical front seat controls can cause serious personal injuries.
- The front seats in your vehicle can be electrically adjusted even when the ignition key is removed. Never leave children and persons who need help in the vehicle alone because the unsupervised use of the electric seat adjustments can result in serious personal injury.
 - Always make sure that no one is in the way while the front seats are being adjusted, or while calling up the stored memory settings for the front seats. In an emergency, stop automatic seat adjustment by pressing another seat adjustment switch.