



# **Electrolux**

## Factory Parts Catalog

Product No.	E30WD75GSS2
	31266300870S2
Series	30" warm drawer
Color	stainless
Market	North America
Wiring Diagram	318049903
Owner's Guide	318201018
Installation Instructions	318201811

# **Electrolux**

Electrolux Major Appliances  
North & Latin America  
P.O. BOX 212378  
AUGUSTA, GA 30917


Publication No.  
**5995513115**  
08/05/01  
(EN/SERVICE/ECL)  
377

### **30" WARMER DRAWER**

Model No.  
**E30WD75G**

Copyright © 2008 Electrolux Home Products, Inc.  
All rights reserved.

**BODY**



**BE30WD75GPS2**


---

**BODY**


---

POS. NO	PART NO.	DESCRIPTION
11	75303300265	Screw, 8-18 X 1/2, (4)
12	7318388000	Bumper, Absorber, felt, (2)
13 #	7316517900	Board, display
13A#	7318388111	Bracket Assembly, display board, w/overlay
*	75304464950	Screw, #6 - 32 x 5/16, (4)
19	7318246913	Panel, control, stainless
20	7318390200	Box, display
20*	75304467464	Screw, 8-18 x 5/16, (6), box mtg.
23	7318310108	Panel, service
24	7318310701	Bracket, mounting
32	7318228100	Strain relief
37 #	7316217002	Probe, oven temp
39	7318144005	Cord, service
77	7316247900	Spacer, power board
77A	7316114100	Spacer, (4)
81 #	7318255301	Element, warmer drawer
82	7318388600	Guard, element
84 #	7318005114	Thermostat
86	7316095800	Clip, hold down, warmer element
97 #	7316517800	Board, control, display realy
100	75304400427	Screw, 6-20 x 1/2, (2)
198	708008009	Bushing, nylon, snap
201	7318281506	Wrapper, upper
202	7318281021	Wrapper, lower
205	7318281207	Panel, side, black, RH
205A	7318281307	Panel, side, black, LH
209	7318247401	Bracket, wall
209*	75304464952	Screw, #10-16 x 1 1/4, (5)
* #	7318199767	Wiring Harness, main
* #	7318199765	Wiring Harness, communication
*	7318399000	Shield, wire
*	75303211311	Screw, 8 x 0.500
*	75303311306	Screw, 8-18 x 0.375, (8)

**DRAWER**



**DRAWER**

POS. NO	PART NO.	DESCRIPTION
1	7318246411	Drawer, warmer, w/track
3	7318394711	Panel Assembly, w/graphics, stainless, front, w/tape & window
4	7318247003	Glass, Drawer Panel, black
6	7318388330	Glass Holder, assembly, w/tape & bumper
9	7318247203	Panel, drawer, interior
10	75304436876	Screw & Washer, handle mtg., 10-24 x 1/2
20	7318373201	Magnet, drawer, (2)
21	7318378002	Bracket, magnet mtg, (2)
*	75304465874	Screw, #8-15 x 1/2, (6)
29	7318369410	Spacer, handle
39	7318238904	Handle, oven door, stainless
80	7318254407	Gasket, warmer drawer
85	7318345600	Rack, warmer drawer
123	7318247104	Panel, control, humidity
124	708002868	Screw, 10-24 x 0.500, probe, thrm brkt, shield, drwr, box
125	75304436030	Rivet
126	7318251100	Handle, control, humidity
*	75303323175	Adhesive tape, 1" lg.
*	7318163602	Cleaner, stainless steel
*	75303300265	Screw, 8-18 X 1/2, (4)
*	75303311306	Screw, 8-18 x 0.375, (8)
*	75304437021	Screw, mounting, 8-18 x 0.25, chrome, (2)

**WIRING DIAGRAM**

