

# FMWCC35

## Portfolio Case

### Installation Instructions

#### PenCentra 130

The PenCentra 130 portfolio case is designed to provide a compact, elegant solution for using and transporting your pen tablet and keyboard.

The portfolio case consists of two distinct storage areas: a pen tablet easel and a keyboard platform.

To open the portfolio, pull up the Velcro® strip that is securing the back flap, as shown in Figure 1. Unzip the wraparound zipper and flip the portfolio open. Extend the back flap so that it forms a stand for the pen tablet. (see Figure 2).




Figure 1. Closed Portfolio Case




Figure 2. Open Portfolio Case

Detach the Velcro® strips securing the vinyl screen flap and lay it over the back of the easel to reveal the pen tablet platform. At the bottom of the platform is a flexible ledge upon which the pen tablet sits. To the right of the ledge is an elasticized strap for securing a spare battery; a smaller strap for securing your pen is affixed to the top of the battery strap.

#### Installing the PenCentra 130

Tuck your PenCentra 130 behind the ledge lip and lay the system flat onto the platform. It should be a snug fit. When storing your pen tablet in the portfolio, lay the nylon flap over the screen to protect it from scratches. See Figure 3 for a fully assembled system in the portfolio.




Figure 3. Assembled PenCentra 130 in Portfolio

#### Installing the Keyboard

To install the keyboard, first remove the adhesive backing from the four Velcro strips that are positioned at the ends of the two strips on the keyboard platform. Holding the keyboard directly over the adhesive strips, carefully lower it so that it is centered on the platform. Press the keyboard down to create a strong adhesive bond.

Unfasten the Velcro®-backed cable strap located behind the keyboard. Route the keyboard cable through the cable strap and fasten the strap. Plug the keyboard cable into the PS/2-style port on the right side of the pen tablet.

### Carrying an Extra Battery

To carry an extra PenCentra 130 battery, stretch out the elasticized battery strap and slip the battery behind it. On the front of the strap, there is an elasticized pen holder with which you can store your pen when not in use.

### Attaching the Shoulder Strap

To attach the shoulder strap, open the spring-loaded clips on the end of the strap, and attach them to the shoulder strap D-rings on either side of the portfolio case (see Figure 1).

### Caring for the Portfolio

The portfolio case is made of rugged materials, and is designed to withstand daily use. Treat the case as you would a briefcase or purse.

Occasionally, the portfolio may become soiled. To clean it, use a clean cloth and warm soapy water to wash the soiled area. Do not submerge the case in water, as it may become warped.