



EQUINOX-HYPERCOM SETUP GUIDE

INCLUDED MODELS XE-A207, XE-A23S, XE-A407, XE-A43S, XE-A507

WWW.SHARPUSA.COM



Sharp Electronic Cash Register

Credit Card Authorization Terminal Setup

XE-A207 / XE-A23S / XE-A407 / XE-A43S / XE-A507

Equipment required

- Equinox-Hypercom T4220 Payment Terminal with application version 3.3.179 or higher
- Serial Cable (Part #810356-001)

Equipment available from First Data For ordering the terminal 1-866-712-8013 For setup assistance contact 1-855-838-8921

Prior to installation

• Confirm you have the correct ROM version




Determine the current ROM Version


PROCEDURE:




STEP 1
Press [MODE] key



STEP 2
Select 6 PROGRAM MODE



STEP 3
Select 1 READING





STEP 4
Select 16 ROM VERSION
See printed
PROGRAM Version

Upgrade NOT required if you have the following (or higher version):

XE-A207 / 23S = V1.09XE-A407 / 43S = V1.07

XE-A507 = V1.04



Connecting the Hypercom Device


PROCEDURE:






STEP 1

Connect the RJ-11 end of the serial cable to the Equinox/Hypercom Device






XE-A507

STEP 2

Connect the DB-9 end of the cable to the COM port on the back of the register

NOTE: On registers with two (2) COM ports, the cable should be connected to COM2



STEP 3

Plug in the Equinox/Hypercom device power supply

Device Configuration – Register settings

PROCEDURE:



STEP 1
Press the [MODE] button

STEP 2
Select 6 PROGRAM MODE
and [CA/AT/NS]

PROGRAM MODE

1 READING
2 SETTING

PGM 01

STEP 3
Select 2 SETTING
and [CA/AT/NS]

SETTING AV
7 DATE/TIME
8 OPTIONAL
9 REPORT
10 MESSAGE
11 DEVICE CONFIG

STEP 4
Select 11 DEVICE CONFIG



DEVICE CONFIG 1 KEYBOARD 2 DISPLAY 3 PRINTER 4 DET	
PGM	01

STEP 5 Select 4 EFT

EFT CHARGE TIME OUT1 TIME OUT2 TIME OUTS	<u>Isaan</u> 010 099 0099
PGM	01

STEP 5
Press the [.] button to change the setting so CHARGE = USED



STEP 6
Press the [CA/AT/NS]
button to save the change



STEP 7
Press the [ESC/CANCEL]
button 3 times
to return to cashier screen



Confirm connection – EFT

PROCEDURE:




STEP 1 Press the [MODE] button

STEP 2
Select 6 PROGRAM MODE
and [CA/AT/NS]

PROGRAM MODE
1 READING
2 SETTING
3 DET TIMEST
PGM 01

STEP 3
Select 3 EFT TEST
and [CA/AT/NS]



STEP 4
Select 1 EFT COMM TEST
and [CA/AT/NS]

STEP 5

Receipt will print when test is successful

NOTE: If error message appears confirm all steps



Credit Card operations – Basic Credit

PROCEDURE:

101.00	1.00
DEPT.01	
***TOTAL	1.00
DEPT.01	1.00
REG	01

STEP 1 Enter sales normally on


cash register



STEP 2


For Payment press [CH] button on keyboard

NOTE: If register has [CH] and [CH2], always use [CH] button for Credit Card payment



STEP 3

Register says "PROCESSING..."



STEP 4

On the Equinox/Hypercom terminal

Select


CREDIT

for the payment type





101.00	1.00
DEPT.01	
***TOTAL	1.00
DEPT.01	1.00
DEPT.01 REG	01





STEP 5

Swipe the Credit Card on the Equinox/Hypercom terminal

STEP 6

Register will close out transaction on approval of the credit card.

After processing register prints receipt based on setting

Equinox/Hypercom terminal will print Customer signature receipt





Designs and specifications subject to change without notice.

Sharp is a registered trademark of Sharp Corporation. Equinox and Hypercom are trademarks of Equinox Payments, LLC in the United States and/or other countries. All other trademarks and registered trademarks are the property of their respective holders.

© 2012 Sharp Electronics Corporation. All rights reserved.