

M-950

SONY

Pressman® Microcassette Recorder

- ▲ FEATHER TOUCH OPERATION
 - ▲ AUTO REVERSE
 - ▲ DETACHABLE SPEAKER
 - ▲ METAL CASE
 - LCD DISPLAY (TAPE COUNTER, BATTERY LEVEL)
 - VOICE OPERATED RECORDING (OFF/HIGH/LOW)
 - ZERO STOP COUNTER
 - FULL AUTO SHUT-OFF
 - MIC/EARPHONE JACK
 - 2-SPEED RECORD/PLAYBACK
 - SONYMATIC® AUTOMATIC RECORDING LEVEL CONTROL
 - DC-IN JACK
 - HAND STRAP ATTACHED
 - HINGED BATTERY LID
- ▲ STEP-UP FEATURE ▶ NEW FEATURE



PRESSMAN

features

- **MICROCASSETTE SYSTEM** uses ultra-compact easy-to-obtain microcassettes for recording and playback convenience
- ▲ **FEATHER TOUCH CONTROLS** are sensitive and logic-controlled for very fast, very easy operation
- ▲ **AUTO REVERSE** provides uninterrupted recording and playback of both microcassette sides
- ▲ **DETACHABLE SPEAKER** lets you speak playback through the speaker rather than an earphone so several persons can listen
- ▲ **METAL CASE** affords extra durability
- **LCD DISPLAY** clearly illustrates tape counter and battery level
- **VOICE OPERATED RECORDING (OFF/HIGH/LOW)** activates the recorder only when audible sound is present, at either a high or low volume sensitivity level, and conserves tape and eliminates soundless pauses during playback
- **ZERO STOP COUNTER** can be set at zero when starting a recording so tape will stop at that point when rewinding
- **FULL AUTO SHUT-OFF** at end of tape with unit in any mode helps reduce mechanical wear and conserves battery power
- **MIC/EARPHONE JACK** allows use of optional external microphone, or optional earphone for individual listening and privacy
- **2-SPEED RECORD/PLAYBACK** gives you the option of recording on a standard microcassette for twice its normal time, for an extended dictation or recording session
- **SONYMATIC® AUTOMATIC RECORDING LEVEL CONTROL** ensures correct recording levels for the particular situation
- **DC-IN JACK** permits two-way power operation, using available replaceable batteries or optional AC power adaptor
- **HAND STRAP ATTACHED** provides a secure, convenient band to hold onto or carry the unit
- **HINGED BATTERY LID** helps prevent accidental loss of lid

specifications

- TAPE SYSTEM:** 2 Track, 1 Channel Monaural Microcassette
FREQUENCY RESPONSE: 250-4000Hz
INPUTS: DC-In, 3V
 Mic, mini jack
OUTPUTS: Earphone Mini jack
SPEAKER: Detachable 1 7/16" (36mm) dia. x 1
POWER OUTPUT: AC 160 mW (at 10% THD)
POWER REQUIREMENTS: DC 3V with "AA" x 2 Batteries
 AC 120V, 60Hz
DIMENSIONS (WHD): 2 5/8" x 4 3/4" x 1" (66.7 x 120.8 x 25mm)
WEIGHT: 6 3/8 oz (180g) with batteries
SUPPLIED ACCESSORIES: Hand Strap
OPTIONAL ACCESSORIES: AC-E15HG AC Adaptor



©2002 Sony Electronics Inc.

Reproduction in whole or in part without written permission is prohibited. All rights reserved. Sony, Pressman, and Sonymatic are trademarks of Sony. Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.