




RANGE HOOD PARTS

For Model: RH2330XJQ0, RH2330XJZ0, RH2330XJB0, RH2330XJT0
 (Designer White) (Almond) (Black) (Biscuit)

30" RANGE HOOD
 (Vented)
 (Use with Gas or Electric Range)



Illus. No.	Part No.	DESCRIPTION
1	883191	Installation Hardware
2		Switch, Light
	883261	White Model
	883203	Black Model
	883335	Almond Model
	8189515	Biscuit Model
5	883103	Filter, With Lens
6		Nameplate
	8189511	White Model
	8189512	Almond Model
	8189513	Black Model
	8189514	Biscuit Model
7		Switch, Fan
	883262	White Model
	883202	Black Model
	883334	Almond Model
	8189516	Biscuit Model
8	883094	Light Socket
9	830428	Blade, Fan
10	830757	Motor, 2-Speed
11	883126	Bracket, Motor
12	830465	Screw, 8 x 1/4
13		Cover, wiring
	883095	White
	883096	Almond
	883169	Black
16	883353	Nut, 6-32 (2)
18	883354	Screw, 8-32 x 1/4 (2)
19	830753	Damper

LITERATURE PARTS

- LIT830735 Order Blank, Filter
- LIT8284637 Installation & Operating Instructions
- LIT883345 Wiring Diagram

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST