




RANGE HOOD PARTS

For Model: RH2330XJQ1, RH2330XJZ1, RH2330XJB1, RH2330XJT1
 (Designer White) (Almond) (Black) (Biscuit)

30" RANGE HOOD
 (Vented)
 (Use with Gas or Electric Range)



Illus. No.	Part No.	DESCRIPTION
1	883191	Installation Hardware
2		Switch, Light
	8189843	White Model
	8189845	Black Model
	8189844	Almond Model
	8189846	Biscuit Model
5	883103	Filter, With Lens
6		Nameplate
	8189511	White Model
	8189512	Almond Model
	8189513	Black Model
	8189514	Biscuit Model
7		Switch, Fan
	8189847	White Model
	8189849	Black Model
	8189848	Almond Model
	8189850	Biscuit Model
8	883094	Light Socket
9	883382	Blade, Fan
10	883378	Motor/Fan Assembly
11	883397	Bracket, Motor
12	830465	Screw, 8 x 1/4
13		Cover, wiring
	883095	White
	883096	Almond/Biscuit
	883169	Black
16	883353	Nut, 6-32 (2)
18	883354	Screw, 8-32 x 1/4 (2)
19	830753	Damper

LITERATURE PARTS

LIT830735	Order Blank, Filter
LIT8284867	Installation & Operating Instructions
LIT883184	Wiring Diagram

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST