

Gigaware®

Start Here

26-1429

Quick Start

2-Remote Recharge Station for Nintendo® Wii™

Package contents



Charger




Battery pack (2)



USB cable




User's Guide




Quick Start

② Place in dock




Charge with or without the Wii remote.

① Replace the original battery pack



③ Connect power



Connect to a USB power source.