



# CyberTrack Q1

1.3 Megapixel Desktop Webcam



Model: CyberTrack Q1

## QuickGuide

English

www.adesso.com

①

### LIMITED WARRANTY

Adesso provides a one year limited warranty for all of its products against defects in material and workmanship.

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

### SUPPORT

We have listed most of our FAQ's (Frequently Asked Questions) at: <http://www.adesso.com/faqs.asp>. Please visit our FAQ Service & Support pages before you contact our E-mail or Telephone Support.

**Email Support:** If our FAQ's do not help you resolve your issues, please email [support@adesso.com](mailto:support@adesso.com)

**Telephone Support:**  
Toll Free: (800) 795-6788  
9:00AM to 5:00PM PST Monday - Friday

②

### INTRODUCTION

Adesso's CyberTrack Q1 1.3 Megapixel Desktop Webcam allows you to record and share colorful VGA quality video with fine detail. This webcam offers you broad Instant Messenger compatibility, so you can enjoy video conferencing with today's most popular Instant Messenger applications. Also enjoy the integrated wide-angle microphone, that captures and delivers everything you have to say, and the auto light sensors, that keeps your image visible even with dim lighting. With all these great features you will never miss a conversation and you will feel like you are in the same room with your friends and family!

### SPECIFICATIONS

- Image Sensor: High Resolution CMOS Color Sensor
- Resolution: 1.3 Megapixels
- Video Format: 24-Bit True Color
- Interface: USB 1.1/2.0
- Frame Rate: 30 fps @ 320 x 240  
15 fps @ 640 x 480  
15 fps @ 2560 x 1920
- Dynamic Range: > 72db
- Focus Setting: Manual
- Features: Automatic White Balance  
Automatic Color Compensation

### REQUIREMENTS

- Hardware: VGA Display Card Supported with DIRECTX
- Operating System: Windows® 7, Windows® Vista & Windows® XP
- Connectivity Interface: USB 2.0 Port

③

### CONTENTS




A

CyberTrack Q1 Webcam



B


Quick Start Guide



C

Driver & Software CD

### DESCRIPTION



**NOTE:** To adjust focus use the Focus Ring located in front of lens.

④

### INSTALLATION

1. Flip and clip webcam on monitor edge or lay flat on desktop.




Flip & Clip




Lay Flat

2. Turn your computer ON and then plug the webcam USB cable into an available USB port.



3. Insert the enclosed Driver & Software CD into the CD-ROM drive of your computer. The installation menu will pop up automatically (click **setup.exe** if software manual does not run automatically).



⑤

4. Click **DRIVER SETUP** from installation menu to install webcam driver, after driver installation click **WEBCAM COMPANION 4** (optional) for bonus webcam features software installation.

**Note:** Webcam Companion 4 license key is located on software CD envelope.



5. After the installation is complete, your webcam is ready to be used with your instant messenger applications or with Webcam Companion 4 software.

### Video & Audio Setup for Instant Messenger

Use the following setup instructions according to your instant messenger application settings:

1. Select the video source "**Vimicro USB 2.0 UVC PC Camera**"
2. Select the audio source "**USB Microphone**"
3. Hit "**Save**" or "**Apply**" for the update settings

**Note:**

For more help on using Webcam Companion 4 see user manual on enclosed Driver & Software CD.

⑥