

Philips
CD/DVD Cleaner

Wet system

SAC2570



Clean your CD player's lens

Regular cleaning of your CD player's lens ensures optimum performance of your equipment. It is important to keep a CD player optical laser lens clean and dust free. This wet system safely removes dust, debris and other contaminants.

Maintain original sound quality

- Wet system

PHILIPS
sense and simplicity

CD/DVD Cleaner
Wet system

Specifications

Packaging Data

- Quantity: 1
- EAN/UPC/GTIN: 6 09585 11898 0
- Gross weight: .118 kg
- Tare weight: .01 kg
- Net weight: .108 kg
- Width: 159 mm
- Height: 25 mm
- Length: 248 mm

Outer Carton

- EAN/UPC/GTIN: 2 06 09585 11898 4
- Quantity: 72
- Gross weight: 8.49 kg
- Tare weight: .72 kg

- Net weight: 7.770 kg
- Width: 343 mm
- Height: 368 mm
- Length: 548 mm

Inner Carton

- EAN/UPC/GTIN: 1 06 09585 11898 7
- Quantity: 6
- Gross weight: .70 kg
- Tare weight: .06 kg
- Net weight: .64 kg
- Width: 163 mm
- Height: 125 mm
- Length: 273 mm

SAC2570/27

Product highlights

Wet system

The specially formulated fluid is applied to the brush on the CD lens cleaner. Then the disc is inserted into the CD player and "played".



Issue date 2008-11-15

Version: 1.0.4

12 NC: 9082 100 09626
UPC: 6 09585 11898 0

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com