



**SUBARU**

**SUBARU IMPREZA**

**INSTALLATION  
INSTRUCTIONS AND USER  
MANUAL**


**PART NUMBER: H001SFG310**

**DESCRIPTION: "Speed Dial" Update CD**



**IMPORTANT:** Please store these installation instructions and user manual with the vehicle's owner manual. If the vehicle's battery is replaced or the battery cables are disconnected, this update must be re-run to restore Speed Dial functionality.

**HANDS FREE UPDATE  
CONTENTS:**



**1X**


**TOOLS REQUIRED:  
NONE:**

1




Turn ignition switch to accessory power position. On map screen, press "Agree"

2



Press "Tilt" button on bottom right of head unit. On screen, press MAP button. When prompted, push yes.

3



Remove MAP disk. Place Update CD in MAP slot. **DO NOT** install the Update CD into the DVD/CD Slot.

4




The Data reading will begin automatically and will take 60-90 sec.

5




When the update is completed, the screen will display "Disc is not a MAP DVD".

6



Press "Tilt" button on bottom right of head unit. On screen, press MAP button. When prompted, push yes.

7



Remove Update CD. Place Map Disk in MAP slot. **DO NOT** install the Update MAP disk into the DVD/CD Slot.

8



The update can be confirmed by going to the navigation menu and pushing the "Version" icon.

9



The Version should be 6300 or higher.

# USER MANUAL ADDENDUM: This addendum includes user manual information for the Speed Dial function, which is added to the navigation system with the update CD.

## Making a phone call from the Speed Dial

It is possible to select a phone number from the Speed Dial registered with the in-vehicle equipment to make a phone call.

### NOTE

To use the Speed Dial, the phone number needs to be registered onto Speed Dial beforehand. (See page 218)

1 Press the **MENU** button.

2 Select **Phone** (Phone).



3 Select **Speed Dial** (Speed Dial).



4 Select the name or phone number of a person to whom you want to make a phone call.

You have a phone call. Speak over the phone.



When the phone call is over, hang up the phone.



## Editing the Speed Dial setting

### Adding the phone number to the Speed Dial memory

It is possible to add the phone number from the Phone Book to Speed Dial memory.

### NOTE

To add the phone number to the Speed Dial memory, the phone number needs to be registered onto Phone Book beforehand. (See page 201)

1 Press the **MENU** button.

2 Select **Phone** (Phone).




3 Select **Speed Dial Settings** (Speed Dial Settings).




4 Select **Add** (Add).



- 5 Select a name on a Phone Book whom you want to add to the Speed Dial memory.



- 6 Select a phone number which you want to add to the Speed Dial memory.



- 7 Select a registering position where you want to add to the Speed Dial memory.



- 8 If you are going to overwrite the Speed Dial memory, select **Yes** (Yes) to finish the adding.



## Deleting the phone number from the Speed Dial memory

It is possible to delete the phone number from the Speed Dial memory.

- 1 Press the **MENU** button.
- 2 Select **Phone** (Phone).



- 3 Select **Speed Dial Settings** (Speed Dial Settings).



- 4 Select **Delete** (Delete).



- 5 Select a Speed Dial memory which you want to delete.



6 Select **Yes** (Yes).



8 Select **Yes** (Yes).



7 If you need to delete all memories from Speed Dial, select **Del.All** (Delete all) on step 4.

