



Your Eos comes standard with quite a view. And that's just the beginning. You'll also discover dozens of smart features that make this convertible even more unique. Because at Volkswagen, we want to be sure that you're getting the most out of your time behind the wheel. So we've created this guide to show you a few of the things it can do, and to show you how quickly you'll be speaking fluent Volkswagen.



BLUETOOTH®

CONNECTING YOUR BLUETOOTH EQUIPPED CELL PHONE TO YOUR EOS

- 1 Make sure the Eos is parked.
- 2 Make sure your cell phone is Bluetooth enabled.
- 3 Turn on the ignition. The Bluetooth feature goes into "discovery" mode for five minutes.
- 4 From your Bluetooth menu on your phone, search for new devices.
- 5 Your cell phone should offer a list of devices for you to choose from. Select the device "VW Phone."
- 6 Enter the passcode "0000" into your phone and press "pair." Your phone should be connected to the Bluetooth system.
- 7 The multi-function display will prompt you to create a user profile—press "OK."

NOTE: To allow Bluetooth to reconnect automatically each time you enter your car, be sure to set "VW Phone" as a "trusted device" on your phone (this varies from phone to phone, and may not be necessary on your specific device).

TO ANSWER AN INCOMING CALL

- ▶ When you get a call, Bluetooth will interrupt your radio. You'll hear a ringtone over your car's speakers.
- ▶ Press the phone button **A** on the multi-function steering wheel.



BLUETOOTH VOICE RECOGNITION

Just press and hold the microphone button **B** until you hear a musical chime. Your Volkswagen will say, "Main menu." Then proceed with one of the steps below.

DIAL BY NUMBER

- 1 After the beep, say "Dial number."
- 2 The system will respond "Number please."
- 3 After the beep, say the number. (You do not have to include "1" before the area code.)
- 4 The system will repeat the number, and then say "Continue."
- 5 To tell the system to call the number, say "Call."

DIAL BY NAME

- 1 After the beep, say "Call" followed by the name of the person you want to call. For example, "Call Mike Brown."
- 2 The system will answer "Calling Mike Brown."

REDIAL

- 1 After the beep, say "Redial."
- 2 The system will respond "Redial. Dialing."

HELP

- 1 After the beep, say "Help."
- 2 The system will respond "Help. Say a name plus 'call,' 'dial number,' 'redial.' You can also say 'music,' or 'further options.' To stop this dialogue at any time, say 'cancel!'"

Learn more at vw.com/eos2012

CLIMATRONIC SYSTEM



TO REGULATE THE TEMPERATURE

- ▶ Press the AUTO button **A**.
- ▶ Turn the left-side temperature dial **B** to the preferred temperature.

TO COOL THE INTERIOR QUICKLY

- ▶ Set the temperature dial between 64 and 68 degrees.
- ▶ If the AUTO function is already engaged, press the AUTO button again. This activates the HI AUTO function, which increases fan speed and activates the A/C automatically. Don't be concerned that the fan is loud; it is doing its job to create a comfortable environment as quickly as possible.

TO HEAT THE INTERIOR QUICKLY

- ▶ Set the temperature dial between 76 and 80 degrees.
- ▶ If the AUTO function is already engaged, press the AUTO button again. This activates the HI AUTO function, which increases fan speed. Don't be concerned that the fan is loud; it is doing its job to create a comfortable environment as quickly as possible.

TO DEFROST THE WINDSHIELD

- ▶ Press the MAX defrost button **C**. The A/C function comes on automatically to dry the air.
- ▶ When the windshield is clear, press the AUTO button again.

Your Eos will automatically turn off the Climatronic system when you open the convertible top. The Climatronic system will store the temperature settings and return to those settings when the convertible top is closed.

KEY FOB

LOCK

To lock all doors and the trunk, push the lock button **A** once.

UNLOCK

- ▶ To unlock the driver's door, push the unlock button **B** once.
- ▶ To unlock all doors and the trunk, press the unlock button twice, with a brief pause in between.



TRUNK

- ▶ To unlock the trunk only, press and hold the middle button **C** on the key fob until the trunk pops open. Push the VW logo and use the logo as a handle to open the trunk.
- ▶ To close the trunk, grab the ergonomic handles located near the outer corners and pull. Finish with a gentle push to help ensure it's securely closed.



BLUETOOTH® WARNINGS:

- Accidents and injuries can occur if the driver is distracted. Speaking on or using a phone while driving can distract the driver from traffic.
- Use of Bluetooth technology requires a compatible phone.
 - Select the volume settings so that the acoustic signals from the outside are still audible (for example, the sirens of emergency rescue vehicles). Observe legal regulations.
 - In areas with no or poor mobile network coverage and possibly in tunnels, garages and subways, phone conversations may be interrupted, and it may be impossible to make phone calls—even emergency calls!
 - In some countries, emergency calls may only be supported when the mobile phone is connected to a mobile phone package which has a SIM card that is "not blocked" and/or has sufficient credit on it.
 - Unmounted or improperly mounted mobile phones can fly around in the event of a sudden driving or braking maneuver or an accident. This may cause injuries.
 - Never place or mount a mobile phone on doors, on the windshield or on or near the area on the steering wheel marked "AIRBAG," the instrument panel, the seat backrests or the areas between these points and the driver/passengers. Mobile phones can lead to serious injuries in cases of accidents, especially when the airbags are inflated.
 - Always switch off your mobile telephone at gas stations or wherever there is a fire or explosion hazard. Electromagnetic radiation can cause sparks which can start fires.
 - The mobile phone will automatically connect to the mobile network when the Bluetooth connection to the mobile phone package is disconnected. Using a radio device in the vehicle without a connection to an external antenna might exceed electromagnetic radiation thresholds. This also applies if the external antenna is not installed properly.
 - Keep a distance of at least 8 inches between the antennas of the mobile phone and a pacemaker, since mobile phones can affect the functionality of a pacemaker.
 - Do not carry a mobile phone on standby mode in the breast pocket directly on top of a pacemaker.
 - If interference is suspected, immediately switch off the mobile phone.
 - The center armrest can interfere with the driver's elbow movement and thus cause accidents and severe injuries. Always keep the armrest closed while driving.

CLIMATRONIC SYSTEM WARNINGS:

- Poor visibility increases the risk of collisions and other accidents that cause serious personal injuries.
- Always make sure all windows are clear of ice, snow, and condensation for good visibility to the front, sides, and rear.
 - Maximum heating output and defrosting performance are not possible until the engine has reached operating temperature. Wait until you have good visibility before driving off.
 - Always make sure you know how to properly use the heating and ventilation systems as well as the rear window defogger that you will need for good visibility.
 - Never use air recirculation for long periods of time. When the air conditioner is off and recirculation mode is on, condensation can quickly form on the windows and greatly reduce visibility.
 - Always switch off recirculation mode when it is not needed. Stale air causes driver fatigue and reduces driver alertness, which can cause accidents, collisions and serious personal injury.
 - Never switch off the fan for a long period of time and never use air recirculation for a long period of time because no fresh air will enter the passenger compartment.

KEY FOB WARNINGS:

- Improper use of vehicle keys can result in serious personal injury.
- Always take the key with you when you leave the vehicle. It can be used to start the engine and operate vehicle systems such as the power windows, leading to serious personal injury. Children or other unauthorized persons could also lock the doors and the luggage compartment.
 - Never leave children, disabled persons, or anyone who cannot help themselves in the vehicle. The doors can be locked with the remote control key. This could result in people being trapped in the vehicle in an emergency. For example, depending on the time of year, people trapped in the vehicle can be exposed to very high or very low temperatures. Heat build-up in the passenger and luggage compartment of a parked vehicle can result in temperatures in the vehicle that are much higher than outside temperatures, particularly in summer. Temperatures can quickly reach levels that can cause unconsciousness and death, particularly to small children.
 - Never remove the key from the ignition switch while the vehicle is moving or rolling to a stop. The steering wheel will lock and you will not be able to steer or control the vehicle.

CRUISE CONTROL ▾

TO ACTIVATE

- ▶ Locate the cruise control stalk on the lower left-hand side of the steering column.
- ▶ Activate "Cruise" by rotating the switch on the top of the stalk to "ON."



TO SET CRUISING SPEED

- ▶ When you get to your cruising speed, press the rocker switch down, towards SET/-, and then release. Now your car will remain at that speed without needing to use the accelerator. The CRUISE light in the instrument cluster will be green.
- ▶ To increase your speed, press the rocker switch up, towards RES/+.
- ▶ To decrease your speed, press the rocker switch down, towards SET/-.

TO DEACTIVATE

- ▶ To deactivate the cruise control, depress the brake pedal.
- ▶ When you do this, the green CRUISE light shuts off.

Your set speed will remain in the cruise control memory. To recall it, press the rocker switch up, towards RES/+. It will remain in memory until you turn your cruise control or the Eos off.

RNS 315 NAVIGATION ▾



TO ASSIGN A DESTINATION

- 1 Press the NAV hard key **A**.
- 2 Use the touchscreen to select ADDRESS, which is the flag icon **B**.
- 3 Use the touchscreen to enter the address in each field. Begin with the state, then the city, then the street, then the number, hitting OK after each entry.
- 4 Not sure about the number of the address you're looking for? You can just enter the state, the city, and the street.
- 5 Press the START soft key **C** in lower right to begin route.
- 6 The map to your destination will then be shown on the touchscreen.

NOTE: You can turn the control knob to zoom in and out of the map.



Please confirm with your Volkswagen Dealer that your navigation software is up to date.

SUNROOF ▾



The sunroof switch is on the console.

TO OPEN

- ▶ To open to the tilt position, press and release the switch once.
- ▶ To open the sunroof completely, press and release the switch once more.
- ▶ To slide the sunroof open, press and hold the switch.

TO CLOSE

- ▶ To close the sunroof, pull and hold the switch.



TO MINIMIZE WIND NOISE

We designed the wind deflector to help equalize air pressure and minimize wind noise.

- ▶ Raise the wind deflector **A** in the front by pressing it lightly after the sunroof is open.

PREMIUM 8 RADIO ▾

TO SELECT AND SAVE A PRESET RADIO STATION

- 1 Push the power button to turn on the radio.
- 2 Press AM, FM or SAT to select a band.
- 3 Press the TUNE soft key **A**.
- 4 Use the knob at the lower right **B** to select a station. To make a selected station a preset station, press and hold any of the six preset station soft keys **C**. The new station will appear in the display.
- 5 To select a specific preset station, simply press the appropriate preset station soft key.



TO PLAY A CD

- 1 Press the LOAD/EJECT button **D**.
- 2 Press any of the six soft keys **E** to select a slot for the CD and then insert the CD.
- 3 Press the MEDIA hard key **F** and press CD to listen.



SATELLITE SIGNAL INTERRUPTION

Sometimes things like tall buildings and tunnels can interrupt the satellite signal. This is normal. The signal should return within a few moments as you drive. You can experience a wide variety of stations for free using your limited, complimentary subscription. Call SiriusXM Satellite Radio at 1-888-539-7474 for more information.

Learn more at vw.com/eos2012

⚠ CRUISE CONTROL WARNINGS:

- Using the cruise control when it is not possible to drive safely at a constant speed can be dangerous and can lead to an accident, with serious personal injury to you and your passengers.
- Never use cruise control when driving in heavy or varying traffic or when you cannot keep a safe distance between you and the vehicles ahead of you.
 - Never use cruise control on steep, winding, or slippery roads (such as gravel roads, wet roads, or snowy or icy roads) or on roads with standing water.
 - Never use cruise control when driving offroad or on unpaved roads.
 - Always adjust your speed and the distance you keep between you and the vehicles ahead of you to the road, traffic, weather, and visibility conditions.
 - To help prevent unintended operation of cruise control, switch the system off when it is not being used.
 - It is dangerous to use the Resume feature when the previously set speed is too high for the existing road, traffic, or weather conditions.
 - When traveling downhill, the cruise control may not be able to maintain a constant speed. The vehicle will speed up because of its own weight. Downshift and/or use the foot brake to slow the vehicle.

⚠ NAVIGATION SYSTEM WARNINGS:

- Operating the radio navigation system while driving can distract from traffic and lead to accidents.
- Observe legal regulations.
 - Always drive attentively and responsibly.
 - Setting the volume too high can damage the hearing. This applies especially to volumes above around 85 decibels.
 - Select volume settings so that acoustic signals from the outside are audible (for example, the sirens of emergency rescue vehicles).
 - Inserting data media while driving can distract from traffic and lead to accidents.
 - Always keep the storage compartment closed while driving.

⚠ SUNROOF WARNINGS:

- Careless or unsupervised use of the panoramic sunroof may result in accidents and severe injuries.
- Only open or close the panoramic sunroof if no one is in the way.
 - Always take the key with you when you leave the vehicle.
 - Never leave children or disabled persons in the vehicle—particularly if they have access to the vehicle key. Unsupervised use of the vehicle key makes it possible to lock the vehicle, start the engine, turn on the ignition and operate the panoramic sunroof.
 - You can still use the panoramic sunroof for a short time after the ignition is switched off as long as the driver or passenger door has not been opened.

⚠ PREMIUM 8 RADIO WARNINGS:

- Distracting the driver from traffic can lead to accidents and injuries. Using the radio system while driving can distract from traffic.
- Observe legal regulations.
 - Always drive attentively and responsibly.
 - Setting the volume too high can damage the hearing. This applies especially to volumes above approximately 85 decibels.
 - Select volume settings so that acoustic signals from the outside are always audible (for example, the sirens of emergency rescue vehicles).
 - Please lower the volume before changing or connecting to an audio source.
 - Unmounted or improperly mounted external devices can be thrown through the passenger compartment in the event of a sudden driving or braking maneuver or a collision, causing injury.
 - Never leave external devices in the doors, on the front windshield, on or near the area marked "AIRBAG" on the steering wheel, instrument panel, seat backs or between these areas and the occupants. External devices can cause serious injury in the event of a collision, especially if the airbags inflate.
 - Connecting cables of external devices may obstruct the driver. Route cables so as not to interfere with the driver.
 - The armrest can affect the elbow room of the driver and thus cause collisions and severe injuries. Always keep the armrest closed while driving.
 - Injuries can be caused by invisible laser beams if the housing of the CD player is opened.
 - Have the CD player repaired only by a specialist.