



CA 210 Owners Manual

**128-6530
1 of 10**

Your system has many features and available options some of which are selected at time of installation. Consult your installing dealer for options that may have been installed and are not listed.

LOCKING THE SYSTEM:

1. Turn the engine OFF, exit the vehicle, and close all doors, hood and trunk.
2. Press and release the LOCK button of your keychain transmitter one time.

The vehicle's doors will lock, the parking lights will flash once, the horn will honk once, and the dash mounted LED will begin to flash slowly confirming the system is locked. If the optional starter inhibit feature is installed, the starter inhibit feature will turn on.

SILENT LOCKING:

1. Turn the engine OFF, exit the vehicle, and close all doors, hood and trunk.
2. Press and hold both LOCK & UNLOCK buttons of your key chain transmitter for 2 seconds. The parking lights will flash once, and the dash mounted LED will begin to flash slowly confirming the system is locked. The horn will not honk. If the optional starter inhibit feature is installed, it will activate.

UNLOCKING THE SYSTEM:

As you approach the vehicle, press and release the UNLOCK button on the keychain transmitter. The vehicle's doors will unlock, the parking lights will flash 2 times, the horn will honk 2 times, and the dash mounted LED will turn off. If the optional starter inhibit feature is installed, the starter inhibit feature will turn off.

SILENT UNLOCKING:

As you approach the vehicle, press and hold both LOCK & UNLOCK buttons on your key-chain transmitter for 2 seconds. The parking lights will flash 2 times, and the dash mounted LED will turn off confirming that the system is unlocked. The horn will not honk. If the optional starter inhibit feature is installed, it will deactivate.

VALET SWITCH:

The valet switch allows you to temporarily bypass the optional starter inhibit feature, eliminating the need to hand your transmitter to parking attendants or garage mechanics. When the system is in valet mode, the optional starter inhibit feature is bypassed, however the remote panic feature and remote door locks will remain operational.

1. Enter the vehicle, and turn the ignition key to the ON position.
2. Press and hold the valet push button switch until the dash mounted LED turns on solid. The system will remain in the valet mode.
3. To return to normal operation, press and release the push button switch any time the ignition is on.

NOTE: Always remember to return the vehicle to the valet OFF position. This will ensure that the optional starter inhibit feature remains active at all times

MANUALLY OVERRIDING YOUR SYSTEM:**USING THE VALET SWITCH MANUAL OVERRIDE**

The optional starter inhibit feature can be deactivated without the use of the keychain transmitter. This is necessary, since you will need the ability to operate your vehicle if the transmitter is lost or its battery fails.

1. Open the vehicle door.
2. Turn the ignition key to the ON position.
3. Within 5 seconds, press and release the valet switch.

The optional starter inhibit feature will enter the (by-passed) mode. You can now start and operate the vehicle normally.

Typically this override mode is used only if the transmitter has become inoperative.

ELIMINATING THE NORMAL ARM/DISARM CHIRPS

You can selectively eliminate the normal arm & disarm chirps by holding the transmitter button slightly longer when locking or unlocking. This will prevent the horn chirps for one arm or disarm cycle. If you find this inconvenient and wish to eliminate these chirps permanently, please check with your installation center.

REMOTE PANIC OPERATION:

The PANIC button on your keychain transmitter functions as a panic switch for use in emergency situations. To use remote panic:

1. Press and hold the PANIC button on the keychain transmitter for 3 or more seconds. The horn will immediately start honking.
2. To stop the honking, press and hold the PANIC button on the transmitter again for 3 seconds. If the button is not pressed, the horn will automatically stop honking after 30 seconds.

NOTE: While in the panic mode, pressing and releasing the lock, or the unlock buttons will, if the option is installed, lock and unlock the doors respectively. While in the panic mode, anytime the unlock button is pressed, the panic feature will continue for the allotted 30 seconds, however, the vehicle will be unlocked allowing the vehicle to start.

ADDITIONAL REMOTE FUNCTION CHANNEL 2

The system has an optional feature, (Channel 2), that can be connected to the Trunk Release. To operate channel 2, press and hold the TRUNK button of your keychain transmitter for four seconds.

CA-210

SYSTEM FUNCTIONS AT A GLANCE

DASH MOUNTED LED INDICATORS

SLOW FLASHING	=	LOCKED
OFF	=	UNLOCKED
ON SOLID	=	VALET MODE

ALARM SIREN CHIRP INDICATION

1 HONK*	=	LOCK
2 HONK*	=	UNLOCK

ALARM PARKING LAMP INDICATIONS

1 FLASH	=	LOCK
2 FLASH	=	UNLOCK

© 2003 Code Systems, Inc.



Code Systems, Inc. Limited Lifetime Warranty

Code Systems Inc. ("CODE") warrants to the ORIGINAL PURCHASER of this CODE vehicle security product (the "Product"), purchased from an authorized CODE dealer, that (except as provided below) should this Product under normal use and conditions, be proven defective in material or workmanship DURING THE LIFETIME OF THE VEHICLE IN WHICH IT WAS ORIGINALLY INSTALLED, such defect(s) will be repaired or replaced (at CODE's option) without charge for parts directly related to repairs of the defect(s).

Switches, indicator lights, and transmitter cases are similarly warranted to the original purchaser for a period of one (1) year from the date of purchase of the Product.

CODE accessories, sold separately, are covered by the applicable warranty accompanying the accessory.

This warranty is non-transferable, non-assignable and is voided when: (1) the Product is removed from the vehicle in which it was originally installed; or (2) the vehicle in which the Product was originally installed is transferred to another party.

This warranty does not apply to any product damaged by accident, physical or electrical abuse, improper installation, alteration, or use contrary to its intended function, fire, flood, or other natural acts.

In order for the Product to be repaired or replaced under the terms of this warranty, the defective Product must be returned to an authorized CODE dealer and accompanied by a copy of the retail sales receipt. The date of purchase and year, make and model of the vehicle in which the Product was originally installed must be clearly indicated on the sales receipt.

This warranty is exclusive and CODE MAKES NO OTHER WARRANTIES EXPRESSED OR IMPLIED. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. IN NO CASE SHALL CODE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

CODE does not warrant that the Product cannot be compromised or circumvented. THE EXTENT OF CODE'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT SHALL CODE'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE ORIGINAL PURCHASER OF THE PRODUCT WITHOUT INSTALLATION LABOR.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state

CODE SYSTEMS, INC.
1-800-421-3209

128-6530
7 of 10