

How to Use

Please rinse the Lid Set. Tea Strainer Set and the interior of the Mug. well with warm water before use. Be sure to check if the Seal Rubber, Tea Strainer Gasket is set correctly before use to avoid leakage.

### When using tealeaves.


- Remove the Lid Set from the Mug.
  - Do not only remove the Lid Cover but remove the Lid Set.
  - Leave the Tea Strainer in the Mug.
- **2** Put tealeaves into the Tea Strainer, add hot water and close the Lid Set.

If the Mug is filled too much. tealeaves and hot water. and then close the Lid Set

Adjust the amount of Close the Lid Set securely.

3 Open the Lid Set and drink.

Open the Lid Set and place it as illustrated. Take out the Tea Strainer and place on the Lid Set.




- When taking the Tea Strainer out from the Mug, be careful not to burn vourself as its handle and tealeaves can be very hot.
- Drain well when taking the Tea Strainer out from the Mug.
- Be careful not to let the Tea Strainer fall off from the Lid Set.
- Finer tea leaf pieces than the Tea Strainer mesh may get mixed
- 4 When finished drinking, put the Tea Strainer back into the Mug and close the Lid Set.
  - When closing the Lid Set, fold down the Tea Strainer Handle.
  - Do not carry the Mug by the Tea Strainer Handle. The Tea Strainer may detach from the Mug and the Mug may drop and cause scalding.

When drinking while the Tea Strainer is set in the Mug, be sure that it is fitted securely. 

**Z**ØJIRUSHI

Household Use Only

Stainless Steel Mug Bottle Model No. SM-CTE INSTRUCTION MANUAL



Please read before use. Keep the instructions for future references.

When tealeaves (and the Tea Strainer) are not used.

## 1 Remove the Lid Set from the Mug.

- Do not only remove the Lid Cover but remove the Lid Set.
- Pour a drink and close the Lid Set.
  - Close the Lid Set securely.



Pour a little amount of hot/cold water into the Mug and leave for about 1 minute to pre-heat/pre-cool achieving better heat retention.

# Cleaning

- For better usage, please remember to clean after every use
- When cleaning the Lid Set and the Tea Strainer Set, be sure to disassemble

The Lid Set and the Tea Strainer

Apply the diluted kitchen detergent to a sponge and wash. After insing, shake several times and wipe them dry.
As by using the product with tea leaves, the Tea Strainer Set and

id Set may discolor by tea stains. Although tea stains can not be

Rinse the whole exterior with warm water or with water.

The Inside

The Exterior

emoved thoroughly, they would not affect the usage of the product Wash the inside of the Mug with a sponge brush with a nandle, then dry it well. To avoid odors to develop, always wash the inside clean after every use.

- •Do not use a thinner, benzene, metal brush, and a brush with polishing
- substance, abrasive cleansers to avoid damages to the product.
- Do not use chlorine type bleach to avoid rust and pinholes to the interior. • Do not boil or use dish dryer or dish washer to clean the product to avoid
- damages, rust and deformation. Do not leave the product soaked in water.

## To remove rust spots or water stains.

As using the product you may find rust spots or water stains caused by substances and quality of water. To clean and remove such stains, remove the Tea Strainer Set and fill the mug with hot water containing 10% of vinegar and let stand for about 30 minutes

For cleaning stainless steel vacuum products and removing tea stains, we recommend using Zojirushi's cleaning detergent SB-ZA01. Remove the Lid Set when using the cleaning detergent SB-ZA01. Please contact Zojirushi Customer Service or your local dealer for further information.

## Please follow the instructions

Please follow the following instructions to avoid scalding, deformation and discoloration of drinks, as well as malfunction and contamination of the product.

Be careful not to scald yourself when

the product contains hot beverages.

exterior of the product will not be hot even if the

May cause scalds and may also stain the interior

of the car or your clothes. Attempting to use while

driving the car may cause serious accidents.

It may cause sparks and be dangerous. It may

also cause its deformation and discoloration.

Always close the Lid securely.

Do not bring the Mug near heat

sources such as gas heaters or

It may also cause its deformation and discoloration.

Hot drink may leak and cause scalding.

Due to the high level thermal effciency, the

product contains hot beverages.

Do not use while driving.

Do not microwave the Muq.

Keep the product away from the reach of infants

Keep the drink level as shown in the illustration below

· When using the Mug without the Tea Straine Fill up the product about 1cm below the rim

Inside of the Mug When using the Mug

(part A.)



Be careful not to over fill the Mug. Over filling may cause leakage

Always use with the Seal Rubber attached. Usage without the Seal Rubber may cause scalding and contamination.

Do not use the product if the thermal insulation is lost.

The damaged product's outer surface becomes hot when hot drink is filled up, and so dangerous.

cooking stoves.

### When using the drink holder of the vehicle:

①Check if the strength of the holder is sufficient to hold the Mug before use.

If it is not sufficient, the holder may come off or break and tip the Mug over resulting in scalding, stains on car interior or on clothing. ②When installing the automobile drink holder by yourself, use the built-in type.

Do not use the hanging type from the window or from the air-conditioner as the drink holder may slip

## • Depending on the type of the drink holders, the Mug may not fit in.

#### Finish the drink within the day.

Leaving drinks for a long period of time may cause the drinks to spoil, create gas which increases inner pressure and the Lid may pop out or drinks may splash out causing scalds and injury.

The illustration used in this Instruction Manual and the actual product may vary.

Do not use for other purposes.

# Clean the Mug after every use.

Not doing so may damage the Mug by rusting or creating pinholes, or the drinks will be spoiled.

#### Do not fill the Mug with the followings:

- Do not fill with dry ice or carbonated drinks.
- High inner pressure may cause drinks to splash out or the Lid may be damaged.
- Do not fill with Miso soup or any other salty food.
- Although the interior of the Mug is Non-Stick coated, salty soup or food may cause rust to the interior and damage the good thermal insulation.
- Do not fill with milk, dairy products or fresh juice.
   The quality of such may deteriorate when kept for long time causing gas and may splash out by the
- Do not add fruit. It may be clogged or cause leakage.

# Warning & Caution

Do not touch the mouth of the Mug with the spout of a hot kettle.

The Mug may tilt over causing scalds.

After washing the Lid Set, shake a few times to release the water contained, and wipe it dry.

Otherwise the remaining water may drip out.

To avoid bags getting wet, always place the Mug in an upright position.

Do not attempt to put large ice cubes into the Mug. Crush ice into small pieces. It may cause deformation or damage.

Do not drop or apply strong shocks

May cause plastic parts to break and dent the

Do not scratch the printing on the

Mug with hard elements.

to the product.

It may come off.

stainless steel exterior

Be careful not to close the Lid Set while the tealeaves or the string of the teabag is stuck at the Seal Rubber. It may cause leakage and resulting in scalding.



Keeping hot tea warm for long hours may cause the color of the tea to change. It is recommended to use the Compartment of the Mug to bring tealeaves with you for fresh brewing.


When carrying the Mug, do not hold the Tea Strainer Handle while it is set in It is dangerous as the Tea Strainer may slip out and the Mug may drop down.

# How to remove and attach the parts.


#### Lid Set

How to remove

①Turn the Lid Cover as illustrated (counterclockwise) to remove.



②Use a chopstick or similar stick which is round edged to lift the Seal Rubber from the gap provided to remove.




• At this time, please take caution not to damage the gasket.

• After removing the Lid Cover of the Lid Set, clean the Compartment as well.

## How to attach

①Align the concave part of the Seal Rubber with convex part of the Lid Set and fit in by pressing the circumference of the Seal Rubber. 2 Press in the Seal Rubber from outside towards the center with your finger to firmly



As there is no difference on the surface of the Seal Rubber it can be attached whichever side facing up

**—** 6 –

③Turn the Lid Cover as illustrated (clockwise)



## ■Tea Strainer Set

How to remove ①Pull the Tea Strainer Handle

Hold the Mug securely when removing the

2 Remove the Tea Strainer Gasket using a toothpick

Be careful not to damage the Tea Strainer Gasket. the Gap

### How to attach

 Attach the Tea Strainer Gasket facing the convex part



②Hold the Tea Strainer Handle and set the Tea Strainer into

- Do not apply strong impacts to the mesh part as well as the Tea Strainer
- Please do not attempt to detach the handle