




WARNINGS:

- Never leave pump unattended while in use.
- Carefully inspect the pump for damage before use and every use thereafter. Do not use if found damaged.
- Do not change the pump plug in any way.
- Do not leave unit plugged into 110 Volt AC power source while unattended.
- Keep pump out of reach of children.
- Do not use in or around water. For indoor use only.
- Never look into or point any opening toward your eyes while pump is operating.
- Do not open pump case, electrical hazards may result. There are no serviceable parts.
- For optimum pump performance, do not operate pump for more than 10 minutes continuously. Allow pump to cool down between operations.
- Let pump cool before storing with bed. Never twist the cord.
- Do not attempt to put any objects into the inflation or deflation ports at any time.
- Never allow paper, debris or small articles to be sucked into pump while operating.
- Do not let your bed come in contact with sharp, pointed objects.
- Do not use or place near heaters, open flame or other hot objects.
- Do not store in extreme temperatures that are above 90°F(32°C) or below 50°F(10°C).
- Product must be at room temperature prior to inflating.

NOTE: The Coleman® Deluxe pump is equipped with an automatic reset thermostat. The thermostat will automatically turn the pump off if the motor gets too hot. If you pump turns off, place the hand control switch in the OFF position, unplug and allow the pump to cool down. The pump will resume normal operation once it has cooled.

GROUNDING INSTRUCTIONS

This pump should be grounded while in use to protect the operator from electric shock. The pump is equipped with a 3-conductor cord and 3-prong grounding type plug to fit the proper grounding type receptacle. This pump is for use on any standard 110 Volt AC electrical outlet, and has a plug that looks like that shown in sketch (A). An adapter, see sketches (B & C), is available for connecting 3-prong grounding type plugs, see sketch (A), to 2-prong receptacles. The green colored rigid tab, see sketch (C), extending from the adapter must be connected to a permanent ground, such as a properly grounded outlet box. (Follow the adapter installation instructions provided with the adapter).



EXTENSION CORDS

Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in the line voltage resulting in loss of power and overheating. The following table shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the extension cord.


Volts 110 AC	Total length of cord in feet			
	0-25'	26'-50'	51'-100'	101'-150'
Ampere rating	AWG			
More Than - Not More Than				
0 - 5	18	16	16	14
5 - 10	18	16	14	12
10 - 12	16	16	14	12
12 - 16	14	12	Not recommended	

The Coleman Company, Inc. has been making people comfortable in the great outdoors since 1901. We've lit your way, cooked your food and warmed your nights. Our products have helped make a million memories. People from all over the world have counted on Coleman time and again for innovation and dependability. That's why, after almost a century, our dedication to quality shines on.

Please call or write us with any comments or questions

The Coleman Company, Inc.
3600 N. Hydraulic
Wichita, KS 67219 U.S.A.
1-800-835-3278
TDD: 316-832-8707

Manufactured in China

© 2005 The Coleman Company, Inc. All Rights reserved. Coleman®, Quickbed® and  are registered trademarks and Double-Lock™ and Comfort Control™ are trademarks of The Coleman Company, Inc.

(8/3/05)



How to Use and Enjoy Your

Coleman® Sleep System



Model #s 5998-830 and 5998-835

Warning: the power cord on this product contains lead, a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling.






Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5

INFLATION INSTRUCTIONS

1. Ensure your Deluxe Quickbed® Airbed is at room temperature prior to inflating.
2. Place your bed on the floor or other surface free of obstructions or sharp objects that may damage your product (see Figure 1).
3. Snap pump into housing (see Figure 2A & 2B).
4. Close the Double-Lock™ Release Valve by pushing inward to activate the internal seal and then close the cap (see Figure 3).
5. Plug cord into any standard polarized 110 Volt AC electric outlet.
6. Push Comfort Control™ switch to FIRM/INFLATE (see Figure 4 & 5). Bed will NOT over inflate to bursting.
7. Lie on the bed to adjust the firmness to your desired comfort level. To make the bed softer, press the SOFT switch on the Comfort Control™ hand control. To increase the firmness press FIRM/INFLATE on the hand control (see Figure 4).




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10




Fig. 11

DEFLATION & STORAGE INSTRUCTIONS

1. Remove pump from housing (see Figure 2 & 6).
2. Open the cap and pull out firmly on the Double-Lock™ Release Valve to open internal seal (see Figure 7).
3. Place DEFLATION end of pump inside the Double-Lock™ Release Valve (see Figure 8).
4. Plug in the pump and press the FIRM/INFLATE switch on the Comfort Control™ hand control (see Figure 4) to turn the pump on. Do not press SOFT; this switch only works when pump is engaged with housing.
5. Once bed is completely deflated, push in with the pump. This will close the valve around the internal post. Then close the cap (see Figure 8 & 9).
6. Snap the pump back into housing (see Figure 2 & 10).
7. Carefully roll/fold bed around pump for storage (see Figure 11).
8. Place bed in provided carry bag. Bed should be stored at room temperature (above 50°F / 10°C and below 90°F / 32°C).

CLEANING

CAUTION: Before cleaning any area of this product (pump or bed) make sure pump is unplugged.

Coleman® Bed

The bed itself may be cleaned using a mild soap and water. Do not use strong chemicals or detergents. Allow your bed to completely dry before storing.

Mattress Pad/Topper

Removable quilted poly/cotton mattress pad may be machine washed in warm water with a mild soap or detergent. Tumble dry on LOW HEAT.

TROUBLESHOOTING

1. Check to make sure pump is properly snapped into the housing. If it is not fully engaged in housing neither the FIRM/INFLATE or SOFT feature on the hand control will work properly.
2. If your product seems to be leaking air, ensure that the Double-Lock™ Release Valve is properly closed. Valve should appear depressed into itself when properly closed. Make sure the valve is sealed around the internal stopper before closing the cap. Do this by pressing in on the valve before closing the cap.

REPAIR

For inadvertent punctures a patch is included. Please use this patch with a repair kit that can be purchased at most retailers or you can purchase a Coleman® repair kit (model #806-153T) by calling customer service at 1-800-835-3278 or visit www.coleman.com.

ONE YEAR LIMITED WARRANTY

The Coleman Company, Inc. ("Coleman") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Coleman, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new manufactured or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Coleman dealers, service centers, or retail stores selling Coleman® products do not have the right to alter, modify or in any way change the terms and conditions of this warranty. This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, discoloration or fading, use contrary to specified instructions, disassembly, repair or alteration by anyone other than Coleman or authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes. **COLEMAN SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN DURATION TO THE DURATION OF THE ABOVE WARRANTY. SOME STATES, PROVINCES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATIONS TO HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.**

HOW TO OBTAIN WARRANTY SERVICE: Take this product to an authorized Coleman service center. you can find the nearest authorized Coleman service center by calling 1-800-835-3278 or TDD 316-832-8707. If a service center is not conveniently located, attach a tag to the product that includes your name, address, daytime telephone number and description of the problem. Include a copy of the original sales receipt. Carefully package the product and send either by UPS or Parcel Post with **shipping** and **insurance** prepaid to:

For products purchased in the United States:

The Coleman Company, Inc.
3600 North Hydraulic
Wichita, KS 67219

DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE. If you have any questions regarding this warranty, please call 1-800-835-3278 or TDD 316-832-8707.