Coleman®

# 16'x14' Convertible Insta-Clip Shelter
Instructions apply to Part Number 9600-161

ASSEMBLY PARTS

When You Are Ready To Set Up Your Shelter

–Select a level area clear of rocks, branches and other hard or sharp objects.
–Do not set up your shelter under trees.
–For easier set up, two or more people are recommended.
–Place fabric in center of selected location and assemble above fabric.

Poles (6) Part No. 9392-2291

Hub (1) Part No. 9392-2351

1 Pole Assembly

–You will need to assemble and connect one pole at a time to the hub.
–Do not completely assemble poles.
  a) Beginning at spring-clip end of pole, assemble all but the last shock-corded section. The pole and one section should curve downward. (illus. 2)
  b) Insert the spring-clip end into one of the hub ports until it clicks into position. (illus. 1), (illus. 2)
 c. Repeat for each of the five remaining poles (illus. 2)

Hub

Illus. 1
Poles inserted
into hub

Hub

Insta-Clips

Illus. 2
Shelter laid out in position
with partially assembled frame
locked into hub.

2 Attach Shelter to Frame

–With the frame still partially set up, clip the center of the shelter to the center hub. (illus. 3)
–Starting towards the center of the shelter, clip the shelter fabric to the poles.

Start by attaching the center of the shelter to the pole hub.

illus. 3 Shelter clipped to partially assembled frame

3 Complete Shelter

–Fully extend each pole by straightening all shock-corded pole sections.
–Insert the pin on the pin and ring system, at the corner of the Screen House into the the pole end. (illus. 4), (illus. 6)
–Repeat for remaining poles.
–Adjust poles to pull the shelter taut and stake down through the fabric loops at the end of pin and ring. (illus. 5), (illus. 6)
–Attach guy lines to fabric guy loops at each corner and stake out (illus. 6)
–Screen doors conveniently tuck into pocket when not in use. (illus. 7)

illus. 6 Completed shelter with guy lines staked out

illus. 7
When not in use, screen door can be tucked into side pocket.
(Do not store shelter with screens in pocket.)

illus. 4
Insert into the pole end

illus. 5
Stake through stake loop

Things You Should Know

• Never store shelter, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your shelter. Use separate storage bag.

• STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE SHELTER FABRIC OR STAKE LOOP TO REMOVE STAKE.

• SHELTER POLES SHOULD NOT BE LEFT TELESCOPED TOGETHER DURING STORAGE.

• Do not leave your shelter set-up for weeks at a time, be aware that exposure to the ultraviolet rays of the sun can seriously damage material and/or cause it to become discolored.

WARNING: Keep all flame and heat sources away from this shelter fabric.
This shelter meets the flammability requirements of CPAI-84. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the shelter fabric may render the flame-resistant properties ineffective.

Coleman

THE COLEMAN CO., INC.
3600 N. Hydraulic • Wichita, Kansas 67219
1-800-835-3278 • www.coleman.com

MADE IN SRI LANKA

PRINTED IN SRI LANKA Rev. 11/04