

⚠ WARNING: Read airbed instruction manual and follow all safety instructions to avoid serious injury or death.

Not for use by children 3 and younger or people with limited mobility. They may suffocate in a face down position or become trapped and suffocate in the gap between the airbed and adjacent furniture or wall. If the airbed is under inflated or deflates during use, this risk of suffocation may increase.

Do not let young children sleep on this airbed until they are mature enough to sleep in an adult bed. Young children can suffocate on adult beds (including airbeds), particularly when sleeping with another person. Ask your pediatrician for specific recommendations for your child.

Adult supervision required for inflation and deflation.



This airbed can melt or burn. Keep away from open flames, heaters, and other hot objects. Do not smoke on or near the airbed.



This airbed is not for use in water. It is not a life saving device, personal flotation device, or water toy.



This airbed is not a toy. Do not stand, walk, jump or play on the airbed. This can result in serious injury or damage to the airbed.




How to Use and Enjoy Your Coleman®


Quickbed® Airbed with Built-In CPX™ Pump




Inflation Instructions



1. Make sure the Control Dial is in OFF position.



2. Unroll and layout airbed in position. Close secondary valve as shown in "Double Lock™ Valve Operation". Valve should appear depressed into itself.




3. Connect pump to power source. Turn control dial to INFLATE and begin inflation. When bed is fully inflated, turn dial to OFF position.


NOTE:
To adjust firmness briefly turn control dial:
DEFLATE decreases firmness.
INFLATE increases firmness.

Deflation Instructions

To Deflate Using the Built-in Pump:




1. Make sure the Double Lock™ Valve is closed.



2. Connect pump to power source. Turn Control dial to DEFLATE position.

To Deflate Without Use of Pump:



1. To deflate, open external stopper and pull to extend out allowing air to escape. When fully deflated close stopper.



Please call or write to us at our nearest location with any comments or questions.

The Coleman Company, Inc. • 3600 North Hydraulic • Wichita, KS 67219 U.S.A.
1-800-835-3278 in the United States • www.coleman.com

Sunbeam Corporation (Canada) Limited • DBA Jarden Consumer Solutions
20B Hereford Street • Brampton ON L6Y 0M1
1-800-387-6161 in Canada • www.coleman.com

© 2011 The Coleman Company, Inc. All right reserved.
Coleman®, Quickbed®, , and are registered trademarks and Double Lock™ and CPX™ are trademarks of The Coleman Company, Inc.

Note: The product may look different from yours. It is for illustration purpose only.

Important Things You Should Know

- Carefully inspect the pump for damage before first use and every use thereafter. Do not use if found damaged.
- Keep unit out of reach of children.
- Do not expose to rain or sunlight. Household use only.





Warnings

- Follow the instructions carefully on articles to be inflated, never exceed recommended pressure. Bursting items can cause serious injury.
- Do not open case, electrical hazards may result. There are no user serviceable parts.
- Do not use under wet conditions. Keep away from water.
- Do not use or place near heaters, open flame or other hot objects.
- Never look into or point any opening toward your eyes while pump is operating.
- Do not attempt to put any objects into the inflation or deflation port at any time.
- Never leave pump unattended while in use.
- Never allow sand, paper, debris or small articles to be sucked into pump while operating.
- **DO NOT BLOCK THE AIR VENTS DURING OPERATION, THIS COULD DAMAGE THE MOTOR.**

To Install Or Replace Batteries

Your new pump operates on 4 “D” cell batteries. For longest life, use alkaline batteries.


1. With pump off, press two release tabs to remove 4D battery pack. (Fig. 1)
2. Press snap feature to open the 4D battery pack top cover. (Fig. 2)
3. Install 4 batteries in the correct orientation as shown on the battery housing. Always be careful that all 4 batteries are installed correctly. (Fig. 3)
4. Close top cover and install 4D battery pack properly into the pump. (Fig. 4)



Note: For optimum performance, alkaline batteries are recommended.

Parts List

1. 5010000712
4D (6V) Battery Pack



Alternative Power Sources For This Product

- 2000002672
6V NiMH Rechargeable Battery Pack
- 2000003287
6V Sealed Lead Acid Rechargeable Battery Pack

Note: To order an alternative power source for this product, please go to www.coleman.com or call Coleman Customer Service.


Double Lock™ Valve Operation

To Open Valve

Open - Step 1:




Open - Step 2:



Fully Opened Valve
Firmly pull cap to unseat valve from inner yellow post.

To Close Valve

Push to Close



CAUTION: Air temperature and weather do affect the air pressure in inflatable products. In cold weather your airbed will lose some pressure due to the fact that the air will contract. If this occurs, you may want to add a little air to improve your airbed's performance. However, in hot weather, the air will expand. You must let some air out to prevent the airbed from failing due to overpressure. You should avoid exposing your airbed to extreme temperatures (hot or cold).