

# attwood<sup>®</sup> Centric Seating System

## Installation Instructions

Attwood marine hardware, navigational lighting, bilge pumps, and other marine accessories are specified more than any other brand by America's best-known boat manufacturers as original equipment. Look to Attwood for quality replacement parts and marine accessories.

### SAVE THESE INSTRUCTIONS

Form Number 69341 Rev. C

04-11

The Centric Seating System is designed for quality boat seating, with stationary- and swivel-mount attachment to fishing boat pedestals. The seats are constructed of tough materials that are resistant to moisture and corrosion.

### REQUIRED FOR INSTALLATION

- Adjustable wrench.
- 1/4" - 20 diameter stainless fasteners. Fastener types can be bolts, or thread cutting bolts. Length must be no longer than 1" (25mm) long plus the thickness of the attachment base.
- Four flat and four lock washers.

If installing optional 7029-1 Locking Latch:

- Cordless drill and 5mm diameter drill bit.
- Two (2) #68 x 3/16" tri-fold aluminum rivets with .040"-.5" grip range.

### ! WARNING

Read installation instructions carefully before installing seats. Improper mounting may result in serious injury.

### MOUNTING SEAT TO BASE


Centric Seats can be mounted to a fixed base, pedestal base, swivel base or slider mount.

### MOUNTING SEAT (Figure 1)

**NOTE:** T-nuts are factory-installed. The T-nuts are 1/4" x 20-barrel style "Propel<sup>®</sup>" nuts.

**NOTE:** Bolts must be 1/4"-20 thread, no longer than 1" (25mm) long plus the thickness of the mounting base.

Figure 1




1. Place washers on fasteners. Insert fasteners up through base and tighten into T-nuts of the seat.
2. Attach Back Panel using three (3) attachment clips fasteners supplied.

### INSTALL OPTIONAL LOCKING LATCH (Figure 2)

The Locking Latch holds the seat closed tightly. Lift the latch to release the lock and raise the seat back.

1. Prior to installing back panel, hold the latch with Attwood<sup>®</sup> logo outward. Place top end into the latch pocket.
2. Use latch as template to drill two (2) 5mm (13/64") holes in the pocket.
3. Attach latch with two (2) #68 tri-fold rivets (not provided).
4. Test latch for proper holding.
5. Attach back panel by pressing it into the cover attachment clips.

Figure 2



### ATTWOOD LIMITED WARRANTY

ATTWOOD CORPORATION, 1016 North Monroe, Lowell, Michigan 49331 ("Attwood") warrants to the original consumer purchaser that Attwood brand products will be free from defects in materials and workmanship under normal use and service for one year from the date of original consumer purchases.

This limited warranty is not applicable if the product has been damaged by accident, improper installation, unreasonable or improper use, lack of proper maintenance, unauthorized repairs or modifications, normal wear and tear, or other causes not arising out of defects in materials or workmanship.

Attwood products are warranted for use on pleasure boats. Any other use — including but not limited to commercial, racing, or nonmarine use — are not covered under this warranty. Attwood's obligation under this warranty is limited to repair of the product at Attwood's plant or replacement of the products at Attwood's option without expense to the original consumer purchaser. Any expenses involved in the removal, reinstallation or transportation of the product are not covered by this warranty.

The product must be returned to Attwood's plant at the address above, postage prepaid, and insured with proof of original purchase including date.

If Attwood is unable to replace the product and repair is not commercially practical or cannot be timely made, or if the original consumer purchaser is willing to accept a refund in lieu of repair or replacement, Attwood may refund the purchase price, less an amount for depreciation. The acceptance by Attwood of any product returned or any refund provided by Attwood shall not be deemed an admission that the product is defective or in violation of any warranty. Products that are replaced or for which a refund is issued become the property of Attwood.

THIS WARRANTY IS ATTWOOD'S ONLY EXPRESS WARRANTY OF THIS PRODUCT. NO IMPLIED WARRANTY SHALL EXTEND BEYOND ONE (1) YEAR FROM THE DATE OF ORIGINAL CONSUMER PURCHASE. ATTWOOD SHALL NOT BE LIABLE FOR ANY DAMAGES FOR LOSS OF USE OF THIS PRODUCT, NOR FOR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES, COSTS OR EXPENSES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.