



# exponent™

# Avior™ X<sup>2</sup>

part number 2000000453

## POLE ASSEMBLY PARTS

### Main Tent Pole (Red)

Part No. 9830-1121

### Side Pole (Silver)


Part No. 9830-1221

### Rainfly

Part No. 9830-1321


## 1 Layout & Positioning of Rainfly, Pole Assembly

- Layout and position Rainfly with doors facing desired direction. (illus. 1) Unzip doors.
- For best results in windy conditions, position back of tent into the wind.
- Insert the cap end of the Main Pole into front sleeve. (illus. 1)
- Insert the cap end of the Side Pole into back sleeve. (illus. 1)




## 2 Assemble Frame

- Start with the Main Tent Pole and gradually apply pressure to the pole, forming an arch, until you are able to insert the pole tip into the grommet on the corner web. (illus. 2, illus. 3)
- Repeat for Side pole. (illus. 2, illus. 3)




illus. 2  
Insert Pole Tip  
into grommet.





### 3 Attach Tent

- Layout the tent. (illus. 4)
- Position the tent in under the Rainfly
- Starting at the back of the tent, clip the tent to the Rainfly in the corners and then the side. (illus. 6)
- Attach the top of the tent to underside of the Rainfly with toggle and loops.
- Optional ground cloth in vestibule can be removed or attached and clipped to the webbing at front of the Rainfly. (illus. 6)
- Stake out rainfly doors, keep rainfly taut. (illus. 6)
- Attach Guy Lines to Guy Wings on back and sides of the Rainfly and stake out. (illus.6).



illus. 5  
Tent clips onto  
pole stake loop



illus. 4  
Tent positions  
in under Rainfly

### Things You Should Know

- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside surfaces of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside your tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and by providing good ventilation through the tent.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE TENT FABRIC OR TENT STAKE LOOP TO REMOVE STAKE.
- TENT POLES SHOULD NOT BE LEFT TELESCOPED TOGETHER DURING STORAGE.



**eXponent™**

3600 N. Hydraulic • Wichita, Kansas 67219  
1-800-835-3278 • [www.coleman.com](http://www.coleman.com)