

Hardware:
Herrajes:
Matériel:

h
Clevis Pin - 2
Pasador de horquilla - 2
Anneau brisé - 2


i
Cotter Pin - 2
Clavija hendida - 2
Goupille fendue - 2

j
J-Clip - 7
Grapa J - 7
Écrou à ressort en J - 7


18

2 -  **210**


3 -  **310**




19



20




21



22

2 -  **h**  **i**





SPIRIT[®]

210[™], 310[™]

89942 US 06/25/10
NG
US ENGLISH

UNPACKING INSTRUCTIONS • INSTRUCCIONES DESEMPAQUETAR • INSTRUCTIONS POUR LE DEBALLAGE

Left Door Panel - 1
Panel de la puerta izquierda - 1
Panneau de porte gauche - 1

Right Door Panel - 1
Panel de la puerta derecha - 1
Panneau de porte droit - 1

Door Handle - 2
Asa de la puerta - 2
Poignée de porte - 2

Right Frame - 1
Bastidor derecho - 1
Coffrage droit - 1

Left Frame - 1
Bastidor izquierdo - 1
Coffrage gauche - 1

Cookbox Assembly - 1
Ensamble de la caja de cocción - 1
Ensemble du boîtier de cuisson - 1

Front Panel - 1
Panel delantero - 1
Panneau avant - 1

Slide Out Grease Tray - 1
Bandeja de goteo - 1
Plateau de recueil des gouttes - 1

Shroud - 1
Defensa - 1
Structure - 1

Right Side Table - 1
Mesa lateral derecha - 1
Tablette latérale droite - 1

Left Side Table - 1
Mesa lateral izquierda - 1
Tablette latérale gauche - 1

Cooking Grate - 2
Parrilla de cocción - 2
Grille de cuisson - 2

Knob - 2-3
Perilla - 2-3
Bouton - 2-3

Front Frame Support - 1
Soporte delantero del bastidor - 1
Support du châssis avant - 1

Rear Frame Support - 1
Soporte posterior del bastidor - 1
Support du châssis arrière - 1

Bottom Tray - 1
Bandeja del fondo - 1
Plateau inférieur - 1

Catch-Pan - 1
Plato recolector - 1
Egouttoir - 1

Disposable Drip Pan - 2
Bandeja de goteo desechable - 2
Egouttoir jetable - 2

Rear Panel - 1
Panel trasero - 1
Panneau arrière - 1

Flavorizer® Bar - 5
Barra Flavorizer® - 5
Barre Flavorizer® - 5

Locking Caster - 2
Rueda loca con traba - 2
Ecrou de verrouillage - 2

Caster - 2
Rueda loca - 2
Ecrou - 2

Catch-Pan Holder - 1
Sostenedor del plato recolector - 1
Support de l'égouttoir - 1

Left Trim Piece - 1
Pieza de ajuste izquierda - 1
Garniture gauche - 1

Right Trim Piece - 1
Pieza de ajuste derecha - 1
Garniture droite - 1


Warming Rack - 1
Rejilla para calentar - 1
Grille de maintien au chaud - 1

HARDWARE
HERRAJES
MATÉRIEL

ASSEMBLY INSTRUCTIONS • INSTRUCCIONES DE MONTAJE • INSTRUCTIONS DE MONTAGE

TOOLS NEEDED:
HERRAMIENTAS REQUERIDAS:
OUTILS NECESSAIRES:





△ IMPORTANT: TO PROPERLY ALIGN FRAME AND DOORS, ASSEMBLE GRILL ON A FLAT AND LEVEL SURFACE.

△ IMPORTANTE: PARA ALINEAR CORRECTAMENTE EL BASTIDOR Y LAS PUERTAS, ARME LA BARBACOA SOBRE UNA SUPERFICIE PLANA Y HORIZONTAL.

△ IMPORTANT: POUR ALIGNER CORRECTEMENT LE CHASSIS ET LES PORTES, ASSEMBLEZ LE GRILL SUR UNE SURFACE PLANE ET A NIVEAU.

