




BULKHEAD PARTS

For Model: LDR3822PQ1
(Designer White)

COMPACT
ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: LDR3822PQ1
(Designer White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	15	359702	Cap, Screw	32	3394508	Ring, Bearing
	8578198	Use & Care Guide	16	9830393	Clip	34	690997	Ring, Tri
	9830513	Label, Operating Instructions	17	3404153	Thermostat, 180°F (82°C)	35	3397590	Roller, Support
	9831728	Label, Wiring Diagram	18	348197	Washer, Support	36	3399506	Shaft, L.H.
	8535901	Label, Energy Guide	19	90767	Screw, 8-18 x 3/8	37	3399507	Shaft, R.H.
			20	8558178	Control, Electronic	38	8066086	Drum Hole Plug
2	696538	Air Duct Assembly	21	3391885	Connector, Edge	41	8531964	Lint Screen
3	3390646	Screw, 8-18 x 5/16	22	3403591	Heater Element	42	94614	Terminal
4	660074	Thermostat, 145°F (63°C)	23	279457	Wire Kit (For Heater Element Wiring Harness Repair)	43	8531967	Cover, Lint Screen
5	345965	Guard, Exhaust				44	342202	Screw, 10-16 x 1/4
6	339956	Seal	24	3976479	Pad, Sensor	45	3395683	Connector (Motor)
7	696426	Wheel, Blower	25	348378	Screen, Back-up	46	8066094	Seal
8	694419	Buzzer, Mini	26	345325	Gusset (2)	47	3397269	Connector, Timer
9	489463	Screw, 8-18 x 5/8	27	3359452	Nut, 3/8-16	48	8299820	Harness, Wiring
10	696419	Scroll, Fan	28	695943	Drum Assembly	49	3936144	Connector, 3-Circuit
11	3394204	Bulkhead	29	345648	Seal, Rear	50	3388703	Washer, Support
12	3398161	Clip	30	97787	Screw, 11-16 x 3/4	55	696302	Shield, Exhaust
13	3401380	Box, Heater	31	685207	Baffle, Drum (3)			
14	343641	Screw, 10-16 x 1/2						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LDR3822PQ1

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: LDR3822PQ1
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, 10-16 x 1/2
2	347812	Panel, Rear
3	348726	Base Assembly
4	660658	Clamp, Motor(2)
5	8538265	Motor, 60 Hz.
6	697776	Screw, Ground (10-32 x 5/8)
7	696541	Base, Motor
8	8066084	Bushing, Snap
9	691366	Idler & Pulley Assembly
10	3390631	Screw, 10-16 x 3/8
12	8066051	Pulley, Motor 60 Hz.
15	8066064	Belt, Drive
16	348705	Panel, Side (2)
18	3406104	Door Switch Assembly
19	697773	Screw, 6-20 x 7/8
20	693943	Front Panel
21	685203	Clip, Felt Pad
22	8066123	Seal & Bearing Assembly
23	345670	Lock, Top
24	3389441	Catch, Door
25	348023	Hinge & Pin Assembly (2)
26	696144	Strike, Panel
27	3390734	Seal, Door
28	694091	Screw, 8-18 x 3/8
29	695656	Door, Rear
30	348205	Door, Front
31	8562104	Handle, Door
32	660719	Caster (4)
33	20063371	Cord, Power
34	3394083	Clip (2)
35	345790	Bracket, Power Cord
36	98234	Clip, Panel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LDR3822PQ1
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	345703	Top
2	3406860	Bracket, Front Panel
3	307563	Rivet, Pop (2)
4	8563881	Timer, 60 Hz.
5		(Timer Motor Not Serviceable)
6	348171	Bracket, Timer
7	311865	Screw, 8-32 x 7/32
8	3390646	Screw, 8-18 x 5/16
9	8562101	Panel, Control
10	8544955	Timer Knob Assembly
11	3977456	Switch, Push-To-Start
12	8544939	Knob, Push-To-Start
13	339554	Screw, 10-16 x 5/16
14	8536939	Clip, Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: LDR3822PQ1
(Designer White)

<u>Illus.</u>	<u>Part</u>	
<u>No.</u>	<u>No.</u>	<u>DESCRIPTION</u>

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray

350930 White

PAINT, BULK (1 qt.)

799344 White (Uncut)