




TOP AND CONSOLE PARTS

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7		Knob, Assembly	17	343641	Screw, 10-16 x 1/2
	W10054090	Guide, Quick Start		8574957	White	18	8558863	Bracket, Console
	W10054080	Use & Care Guide		8574959	Black	19	3394427	Clip-Harness
	W10054160	Wiring Diagram		8574958	Biscuit	20	94613	Terminal
Following May Be Purchased			8	337686	Screw, 8-18 x 1/2	21	8563853	Bracket, Machine Controller
<u>DO-IT-YOURSELF REPAIR MANUALS</u>			9	94614	Terminal, Female	22	W10111608	Control, Electronic
	677818	Dryer	10	8572270	Assembly, Lint Screen	23	3347243	Connector 6-Circuit
2	8563974	Assembly, User Interface	11		Cover, Lint Screen	24	353424	Connector Sensor
3		Panel, Console		W10044320	White	25	3401144	Connector, (PTS Relay)
	W10110325	White	12	W10044470	Hinge, R.H.	26	3403499	Connector, 2-Position (Gas Valve)
	W10110330	Black		W10044480	Hinge, L.H.	27	3403498	Connector, 3-Position (Gas Valve)
	W10110328	Biscuit	13	3196537	Screw, 8-18 x 5/8	28	W10111432	Harness, Wiring
4	W10003770	Screw, 6-19 x 3/64	14	3936144	Connector	29	8558853	Screw, Grommet (2)
5	717252	Plug, 2 Way Terminal	15	3395683	Connector (Motor)	30	237446	Washer (Top/Chute)
6	8564265	Cover, Rear UI-Assembly	16		Top			
				8565025	White			
				8565028	Black			
				8565027	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8533974	Screw, Ground	19	W10007520	Clip, Ground (2)	32		Handle, Door
2	3390631	Screw, 10-16 x 1/2	20	8576625	Lock, Front Top (2)		W10111246	White
3	693995	Screw, Hex Head	21		Panel, Front		W10111248	Black
4	3387374	Spring, Idler			(Includes Illus. 34.)		W10111247	Biscuit
5	8558833	Cover, Terminal Block		8565033	White	33	W10044490	Seal, Front Panel
6	8566208	Assembly, Switch		8565036	Black	34		Plug, Front Panel
7	8558830	Panel, Rear		8565035	Biscuit		8564457	White
8	8568303	Locator, Snap Down	22	8564011	Bracket, Switch		8573008	Black
9	8572983	Door Strike	23		Plug-Hole		8573005	Biscuit
10	3978977	Door Switch Assembly		3404413	White	35	344020	Power Cord
11	3389420	Retainer-Idler 1/4-20 x 1/16		3404416	Black	36	3394083	Clip, Front Panel
12	8565015	Glass, Inner Door		3404415	Biscuit	37	238088	Hinge, Top (2)
13	8578538	Belt Restrainer	24	8572982	Assembly, Door Catch	38	8547174	Idler & Pulley Assembly
14	8578560	Hole-Plug Assembly, Hinge & Pin	25	8575027	Seal, Door	39	8547168	Belt, Drive
15			26	308499	Pal Nut (4)	40	8547166	Base Motor
	8565018	White	27	8539897	Jumper, (Belt Switch)	41	W10002600	Screw
	W10050090	Black	28	W10100830	Screw, 10-16 x 3/64	42	8578565	Pulley, 60 HZ
	W10050050	Biscuit	29	8539897	Screw	43	8566152	Motor, Assembly 60 HZ
16	3392100	Foot, Dryer	30		Door Inner	44	660658	Clamp, Motor
	279810	Foot-Optional (Extended Length) (Package of 2) (Not Included.)		8565037	White	45	8557890	Burner, Assembly 60 HZ
17	342055	Screw, 8-18 3/64	31	8575052	Black/Grey			(See Pages 7 & For Further Burner Breakdown)
18		Cabinet		W10116925	White	46	W10076060	Seal-Window
	8557569	White		W10116927	Black	47		Window Outer
	W10045390	Black		W10116926	Biscuit		8575030	White
	8572115	Biscuit					8575049	Black
							8575050	Biscuit
						48	18849	Pad, Top Hinge

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION
1	8544805	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3387459	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	487909	Screw, 8-15 x 1/2
7	3196537	Screw
8	8539889	Harness, Flame Switch
9	8577274	Thermister, Internal-Bias
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	8546149	Clip-Heater Box
13	343641	Screw, 10-16 x 1/2
14	8544803	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	8544810	Collar, Lint Chute
17	8558890	Bulkhead, Front
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	8544813	Seal, Lint Chute
22	3977373	Bracket, Drum Light
23	8565688	Baffle, Drum (3)
24	8557270	Drum, Assembly
25	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
26	3392519	Thermal-Fuse
27	3934666	Nut, 3/8-16 (R.H.)
28	8573836	Shield, Exhaust
29	W10109200	Screw, 11-16 x 3/4
30	8576468	Pad, Sensor
31	8557277	Seal, Drum
32	3402841	Lens, Drum Light
33	338906	Sensor, Radiant
34	8557242	Bulkhead
35	W10001120	Nut, 3/8-16
36	8536973	Roller Support
37	8575324	Shaft (R.H.)
38	8575325	Shaft (L.H.)
39	690997	Ring, Tri
40	W10053480	Bracket, Lint Chute
41	3390631	Screw, 10-16 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8557890 BURNER ASSEMBLY

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



BA-155

Illus. No.	Part No.	DESCRIPTION
1	8557890	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	3390631	Screw, 10-16 x 3/8
7	8544751	Base, Burner
8	3387057	Screw, 8-18 x 3/8

Illus. No.	Part No.	DESCRIPTION
9	234826	Orifice, Burner Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8281924	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	8182790	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)

Illus. No.	Part No.	DESCRIPTION
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator

Following Parts Not Illustrated

49572 Conversion Kit (Type 1) to Type (4) LPG.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: WGD6400SW1, WGD6400SB1, WGD6400SG1
(White/Grey) (Black) (Biscuit/Gold)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

279948	Kit, Dryer Repair
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
W10071550	Dry Rack
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
72032	Black

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Black
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------