

PARTS LIST

for



ELECTRIC DRYER

MODEL
LE5650XMW2

▲W-White



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




Whirlpool CORPORATION

Benton Harbor, Michigan.

CABINET PARTS

For Model: LE5650XMW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LE5650XMW2

Illus. No.	Part No.	DESCRIPTION
1	690236	Wire, Ground (Motor)
2	3393008	Screw, 10-16 x 1/2
3	688412	Clip, Harness Retainer
4	3393657	Restrainer, Belt
5	690893	Cover, Terminal Block
6	279393	Terminal Block Kit For Terminal Block
7	346368	Panel, Rear
8	693994	Screw, Hex Washer Head (7)
9	691581	Clip, Door Switch
10	347207	Switch, Door
11	98129	Screw, 6-20 x 1-3/8
16	3392100	Foot, Dryer (4)
17	690363	Locator, Top (2)
18		Cabinet
	3394109	White
19	98234	Clip, Ground (2)


Illus. No.	Part No.	DESCRIPTION
21		Upper Front Panel Assembly
	693197	White
22	693995	Screw, 10-16 x 1/2
23	685203	Clip
24	3389441	Catch, Door
27	694091	Screw
28	348023	Hinge & Pin (2)
29	3394083	Clip, Front Panel (2)
31	98997	Clip, Harness
33	696144	Strike, Door
35	695656	Door, Rear
36		Door Front
	348205	White
37		Handle, Door
	686711	White
38	349462	Seal & Bearing Assembly
40	279318	Terminal, Brass & Tinned (Includes Illus. 6)

Illus. No.	Part No.	DESCRIPTION
41	690261	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler Pulley Assembly
54	3393008	Screw, 10-16 x 1/2
56	3394651	Belt, Drive
57	348780	Base, Motor
58	172455	Bolt, 5/16-18 x 3/4
59	3389627	Pulley, 60 Hz.
61	3388235	Switch (Use W/3391888 Motor)
62	3391888	Motor Assembly 60 Hz.
63	660658	Clamp, Motor (2) 343481 (Alt.) 685441 (Alt.)
67	685763	Seal, Door
87	697776	Screw, 10-32 x 1/2 (External Ground)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LE5650XMW2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LE5650XMW2

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	358470	Panel, Rear Console	18	690292	Control Knob, Temperature	62	90015	Clip
4		Cap, End (L.H.)	21	3393916	Timer Assembly (60 Hz.)	63	688805	Clip
	375333	White				67	689559	Nut, Push-In (4)
5	355326	Screw, 8-18 (4)	29	339554	Screw, Tapping (2)	71	343641	Screw, 10-16 x 1/2
6		Cap, End(R.H.)	30	98460	Nut, Push-In (2)	72	690853	Wire, Ground
	375337	White	39	660936	Switch, Push-to-Start	79	694720	Switch, Temperature
8	358473	Nut, Push-In (2)				81	346219	Button, Push-to-Start
10	339392	Screen, Lint				82	358472	Stop, Push-In (2)
11		Cover, Lint Screen	48	690200	Timer Knob			10875 Wire, Splicing
	688150	White	49	693994	Screw, Hex Washer Head (4)			120 Volt
12	339229	Hinge, R.H.						299885 Wire, Splicing
	339230	Hinge, L.H.	50	693995	Screw, Hex Washer Head (2)			240 Volt
13	688983	Screw, 8-18 x 5/8	53	359708	Bracket, Control			
14	358225	Screw, 8-18 x 1 (2)	54	688350	Panel, Console			
16		Top						
	688479	White						
17	3393989	Harness, Electric Wiring						


LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>LITERATURE PARTS</u>			<u>OPTIONAL PARTS NOT INCLUDED</u>					
LIT3391427		Guide, Dryer	<u>PAINTS</u>			<u>PAINT, BULK (1 qt.)</u>		
LIT3391339		Use & Care Guide	<u>PAINT, TOUCH-UP (1/2oz.)</u>			799344 White (Uncut)		
LIT3389444		Instructions, Installation	72017 White			<u>Following May Be Purchased</u>		
LIT3393057		List, Service Parts	<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>			<u>DO-IT-YOURSELF REPAIR MANUALS</u>		
			350930 White			LIT677813 Automatic Washer (Belt Drive)		
			350938 Primer, Gray			LIT677818 Dryer		
			350941 Leveler (Thinner)			LIT677821 Compactor		
						LIT677967 Dishwasher		
						LIT677971 Ice Maker (In Refrigerator)		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: LE5650XMW2



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly	13	343641	Screw, 10-16 x 1/2	43	339489	Shaft, R.H.
2	3390291	Thermostat, 250 F (121 C)	14	695547	Box, Heater	44	3389901	Roller, Support
3	686889	Pad, Cabinet	15	3389946	Thermostat, Cut-Off	46	348197	Washer, Support
4	3388703	Washer, Support	16	687128	Screw, 10-16 x 1/2	47	120377	Nut, 3/8-16
5	90767	Screw, 8A x 3/8	17	660982	Element, Heater 693300 (Alt.) 696579 (Alt.) 693062 (Alt.)	48	685775	Bulkhead
6	3392247	Pad, Blower Housing	19	3387134	Thermostat, Internal-Bias	62	3394508	Ring, Bearing
7	347139	Seal, Lint Chute	20	3392519	Thermal Fuse	63	690372	Screw, 11-16 x 7/8
8	3392123	Seal, Blower Shaft	23	279457	Wire Kit (For Heater Element Wiring Harness Repair)	66	337449	Seal, Rear Drum
10	694089	Wheel, Blower	26	695239	Screw, 8-18 x 3/8	67	695584	Drum Assembly
11	695081	Housing, Blower	41	690997	Ring, Tri	68	342847	Baffle, Drum
12	337272	Clip	42	347364	Shaft, L.H.	69	348945	Bracket, Support
						70	90296	Clip
						73	339956	Seal
						74	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST