


For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
(White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	13		Filler, Wrapper	26		Button, Water
	2318583	Use & Care Guide		2223893W	White			Filter
	2223419	Service & Wiring Sheet		2223893T	Biscuit		2260503W	White
	2223996	Installation Instructions		2223893B	Black		2260503T	Biscuit
	2318827	Energy Guide		2223893AP	Apollo Gray		2260503B	Black
	2220407	Modular Icemaker Service Sheet	14		Grille		2260503AP	Apollo Gray
		Front Roller Asm		2322206W	White	27	2260526	Housing, Water Filter
2		Left Side		2322206T	Biscuit			Water Filter
	2306950	Right Side		2322206B	Black	28	4396841	Water Filter
	2306951	Strap, Roller		2322206AP	Apollo Gray	29	2307051	Door Closer (FC)
3	2223263	Roller, Rear (2)		3400108	Screw	30		Cap, Water Filter
4	2306949	Clip, Retainer (4)	15		Hinge, Top FC			White
5	2223388	Clip, Grille	16		White		2260518W	White
6	2155013	Screw		2307007W	Biscuit		2260518T	Biscuit
7	488500	Shim		2307007B	Black		2260518B	Black
8	2223545	Hinge Top, RC		2307007AP	Apollo Gray		2260518AP	Apollo Gray
9		White	17	489464	Screw	31		Cabinet (Not A
	2307008W	Biscuit	18	940139	Drain Fitting	32	489483	Screw
	2307008T	Black	19	2254566	Tube, Extension			Serviceable Part)
	2307008B	Apollo Gray	21	2223409	Cover, Unit	34	2307049	Door Closer (RC)
	2307008AP		22	2223387	Pin, Roller (4)	35	3400858	Screw
10	3400113	Screw	23	549193	Clamp, Service Cord	36	2224020	Tube, Filter Outlet
11	3400243	Screw	24	489084	Screw	37	2319868	Tube, Filter Inlet
12	2307179	Hinge Assembly, Bottom-RC	25	2307152	Hinge Assembly, Bottom-FC			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2224121	Escutcheon, Meat Pan Control
3	2224123	Slide Meat Pan Control
6	1118894	Switch, Rocker Arm
7	2188820	Thermistor
9	2319866	Ladder, Shelf (2)
10	2301234	Housing, Door Control
11	489084	Screw
13	2301235	Slide, Door Control
14	2171846	Release Valve
15	2209204	Clip, Thermistor
16	2179404K	Rack, Wine & Egg
17	2317105	Cover, Thermistor
18	489478	Screw
19	2304597	Gasket, Air Baffle
20	2223403	Cover, Air Baffle
24	2224076	Air Diffuser Assembly
25	2220377	Air Baffle
29	2162085	Socket
31	2223876	Reservoir
32	2205813	Strap
33	2255743	Light Bulb
34	2223663	Light Lens
37	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1	2224061	Shelf Assembly, Cantilever (2)
2	2301025	Button, Humidity
3	2301026	Slide, Humidity
4	2301117	Gasket, Side (2)
5	2203027	Cover, Meat Pan (Includes Items 13, 14, 15 & 20)
6	2301023	Snack Pan (Includes 30 & 31)
7		Glide Assembly, Crisper Pan
	2301548	Right Side
	2301549	Left Side
8	2301001	Window, Crisper Pan
9	2301567	Cover, Crisper (Includes 2, 3, 4, 11, 12, 13, 14 & 19)
10	2301027	Glass, Cover
11	2301116	Gasket (Front)
12	2301115	Gasket (Rear)
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2301031	Crisper Pan (Includes 8, 13, 14, 19 & 31)
17	2223790	Meat Pan (Includes 13, 14, 19 & 22)
18		Glide Assembly, Snack Pan
	2301550	Right Side
	2301551	Left Side
19	489261	Screw
20	2223487	Deflector
21		Support Assembly
	2301569	Right Side
	2301570	Left Side
22	2203031	Handle
25	2196485	Stud Assembly
26	2301566	Shelf, Snack Pan
27	3400894	Screw
28	2196483	Stud Assembly
29	8281158	Screw
30	2301006	Window, Snack Pan
31		Cap, Snack Pan
	2301016	Right Side
	2301017	Left Side

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# FREEZER LINER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2223777	Spacer, Slide (2)
5	2196483	Stud Assembly
6	2223811	Basket, Deep (2)
8	8281158	Screw
9	2223500	Shelf Assembly, Cantilever (2)
11	2224053	Front, Basket
13		Shelf Track
	2223787	Right Side
	2223788	Left Side
14	2223681	Shelf, Fixed
15	2223812	Basket, Lower
17	842534	Clip, Air Duct
18		Glide Assembly, Basket (2)
	2301544	Right Side
	2301545	Left Side
19	2259487	Cover, Emitter
20	8534064	Screw
22	2198635	Spring
23	2198634	Pin
24	2198665	Tube, P.C. Board
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2224125	Cover, Ice Maker
28		Slide, Ice Maker Mounting
	2212321	Right Side
	2306900	Left Side
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255561	Cover, Receiver
37	2301340	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
44	3400893	Screw
45		Ladder
	2320024	Left Side
	2320025	Right Side
46	2303378	Shield, Wiring

# MOTOR AND ICE CONTAINER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS


For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	2223317	Ice Bin
2	2255580	Crusher Bin
3	2258222	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (4)
6	2255460	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2188918	Coupling
17	8281164	Screw
18	3400065	Screw
19	2301345	Button, Bin
20	2212371	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw
23	8281163	Screw
24	2188919	Holder
26	2198628	Seal
30	2188916	Drive Shaft
31	2256154	Enclosure, Motor
32	2315547	Dispenser, Motor
33	2212305	Cover
36	2315559	Sleeve, Coupling
37	2187725	Wire Harness, IDI Motor
100	2315952	Ice Container (Complete)



# REFRIGERATOR DOOR PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
(White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# REFRIGERATOR DOOR PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2307199W	White
	2307199T	Biscuit
	2307199B	Black
	2307199SA	Monochromatic Stainless
2	2203087K	Trim, Shelf
3	2255421	Dairy Door
4	2223883	Caddy, Can
5	2165792K	Butter Dish
6	2219698	Stud, Handle
7		Door Gasket, Magnetic
	2223841	Mist Beige
	2223911	Black
8		Handle
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless Steel
9		Screw
	W10010140	Chrome
	W10010150	Black
10	2223879	Dairy Compartment
11	488208	Screw
12	2307048	Door Closer, Upper Cam
13	2308050	Thimble, Top
14	489420	Screw
15		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black
16	2223860	Door Bin (3)
17	3400012	Screw
18	2224173	Door Bin, Shallow
19		Nameplate
	W10046670	White
	W10046700	Biscuit
	W10046640	Black
	W10046610	Gray
20	2156006K	Plug, Trim

# FREEZER DOOR PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
(White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# FREEZER DOOR PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2320129W	White
	2320129T	Biscuit
	2320129B	Black
	2320129SU	Monochromatic Stainless
2		Handle
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless Steel
3	2219698	Stud, Handle
4	488208	Screw
5	3400012	Screw
6		Screw
	W10010140	Chrome
	W10010150	Black
7	2304925K	Shelf Bin (3)
8		Door Gasket, Magnetic
	2223850	Mist Beige
	2223912	Black
9	2304895	Safety Barrier
10	2219982	Trim, Door Shelf
11	2308050	Thimble, Top
14	2307050	Door Closer, Upper Cam
16	489420	Screw
17		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black

# DISPENSER FRONT PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
(White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# DISPENSER FRONT PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)	11		Lever, Ice Dispenser	21		Front Cover, Housing (Not Available, Order #23)
2	3196537	Screw		2259396W	White			
3	2194719	Retainer, Levers		2259396T	Biscuit			
4	2304772	Spring, Torsion		2259396SB	Black	22	489000	Screw
5	2196195	Pin		2259396AP	Apollo Gray	23		Front Cover Assembly (Includes Items 13, 19, 20 & 21)
6	2180353	Door, Ice	12	2180224	Guide, Ice			
7	2304355	Door Mechanism Assembly	13	2305571	Gasket			
8	2205686	Mechanism Delay	15	2323009	Bracket, Control			
9		Grille, Overflow	17		Lever, Water Dispenser		2318821W	White
	2206670W	White		2259395W	White		2318821T	Biscuit
	2206670T	Biscuit		2259395T	Biscuit		2318821B	Black
	2206670B	Black		2259395SB	Black		2318821US	Universal Silver
	2206670US	Universal Silver		2259395AP	Apollo Gray	24	2304673	Bracket, Dispenser
10	2209718	Water Fitting Assembly (Includes Water Tube)	19		Overlay, Front Cover (Not Available, Order #23)	25	2195051	Strain Relief
			20		LED Display (Not Available, Order #23)	26	3400065	Screw
						27	2252127	Sleeve, Mechanism

# AIR FLOW PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2223733	Retainer, Fan Motor
3	2223298	Air Scoop
4	2223303	Air Duct, Upper
5	2223771	Air Duct Freezer
6	2319914	Bi-Metal, Defrost
7	2259385	Fan Motor
8	2169142	Fan Blade
9	2304241	Gasket, Evaporator Cover (2)
10	2223986	Fan Grommet (2)
12	2310236	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155789	Gasket, Fan Scroll
16	2203876	Gasket
17	2223413	Cover, Evaporator (Includes #9)
18	8281159	Screw
21	489478	Screw
22	2223395	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PARTS

For Models: KSCS23FSWH00, KSCS23FSBT00, KSCS23FSBL00, KSCS23FSMS00  
 (White) (Biscuit) (Black) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1	2319753	Control Box (Includes #6)
5	2223882	Heat Shield Asm (Includes #17)
6	2307037	Control Board Asm
10	2223506	Light Lens, Control Box
17	2223857	Light Socket
19	2223678	Light Bulb

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# UNIT PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	777070	Screw	25	2223398	Tray, Evaporator	Following Parts Not Illustrated and Optional Parts Not Included		
2	2225834	Fan, Blade	26	2224022	Heat Shield			
3	2223315	Condenser Assembly	27	2319825	Drier			
4	8281197	Screw	28	2223801	Compressor (Includes Items 12 & 39)			
5	3400524	Screw (6)	29	2223800	Spacer (5)			
6	2223703	Housing, Control Board	31	2187849	Harness, Main Control			
7	2223351	Tube Suction	32	2224024	Fan, Motor Bracket			
8	2161302	Sleeve	33	2210737	Heater, Defrost			
9	W10000040	Washer	34	2304287	Clip			
10	2301979	Plate, Mounting	36	2304175	Inverter Box			
11	8281196	Screw	37	W10000070	Screw	978025		Valve, Access (1/4")
12	2215676	Cover, Terminal	38	2223352	Tube, Discharge	978026		Valve, Access (5/16")
14	2185788	Clamp, Cable	39		Grommet (4)	978027		Valve, Access (3/8")
15	488649	Screw		2183042	Production	978028		Valve, Access (1/2")
18	2223353	Tube, Condenser to Heat Loop		4387558	Service	978029		Valve, Access (5/8")
19	2307028	Electronic Control	41	2223394	Extension, Air Baffle	978030		Valve, Access (3/4")
20	2306932	Baseplate				876764		Valve, Access (3/16")
21	2169104	Insulation, Sound	42	2155547	Clip, Heat Shield	<b>REFRIGERANT CHARGE</b>		
22	2188823	Evaporator	45	2187737	Unit Harness			6.00 oz.
23	2161324	Clamp	63	2209709	Connector, Water Tube			(R-134A)
24	2188729	Fan, Motor						



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
(White) (Biscuit) (Black) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
5	628379	Clip, Fuse
9	489478	Screw
10	2315533	Water Valve Asm
14	2208136	Tube Clip
18	2174358	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638)
22	628356	Cup, Water Fill
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	2315522	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187467	Harness, Wiring
33	2303583	Bracket, Icemaker Mounting
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	2198597	Icemaker Assembly

# OPTIONAL PARTS (NOT INCLUDED)

For Models: KSCS23FSWH01, KSCS23FSBT01, KSCS23FSBL01, KSCS23FSMS01  
 (White) (Biscuit) (Black) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>			<b><u>PAINT, BULK (1 qt.)</u></b>			<b><u>TORX SCREW WRENCH</u></b>		
	*350942	Primer, White		799340	Black		1117510	Torx Key
	*350939	Black		799344	White			
	*350930	White		8171358	Graphite			
	*8171357	Graphite		4392900	Biscuit			
	*4392901	Biscuit						
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>			<b><u>Miscellaneous</u></b>					
	72017	White		212643	Sealer, Gum (4 Feet)			
	80051	Graphite		479502	Tape, Vinyl (3/4 x 108")			
	72032	Black		505587	Sealer, Mastic (1 Qt.)			
	4392899	Biscuit		503695	Cork, Sealer (1/4 Pound)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			

**\*Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST