



For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: **KSRS25ILWH13**, **KSRS25ILBT13**, **KSRS25ILBL13**, **KSRS25ILSS13**  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>LITERATURE PARTS</b>			9	2203771	Hinge Top (RC)	22		Cabinet (Not A Serviceable Part)
1	LIT2261499	Energy Guide	10	2203098	Plate, Screw	23		Hinge Cover
	LIT2255706	Owner's Manual	11	8281227	Screw		2203408W	White
	LIT2255376	Service & Wiring Sheet	12		Hinge Cover		2203408T	Biscuit
	LIT2220407	Modular Icemaker Service Sheet		2203407W	White		2203408B	Black
				2203407T	Biscuit	24	549193	Clamp, Service Cord
			13	2217075	Hinge Bottom (2)	25	489084	Screw
			14		Filler, Wrapper	26	2155311	Door Closer, Lower Cam (2)
				2196094	White	27	489483	Screw
				2196150	Biscuit	28	2186443	Housing, Water Filter
				2196097	Black	29	2203220	Water Filter Cap, Water Filter
			15		Grille	30		
				2186881W	White		2186494W	White
				2186881T	Biscuit		2186494T	Biscuit
				2186881B	Black		2186494B	Black
			16	489497	Screw	31	489500	Screw
			17	489464	Screw	32	3400113	Screw
			18	940139	Drain Fitting	33	3400103	Screw
			19	1108438	Extension Tube	36	2203770	Hinge Top (FC)
			20	1108439	Clip, Drain Tube			
			21	2188739	Cover, Unit			
<b>Following May Be Purchased</b>								
<b>DO-IT-YOURSELF REPAIR MANUALS</b>								
	LIT787316	Icemaker						
2	2174748	Front Roller (2)						
3	3400517	Screw						
4	2196236	Roller (Rear) (2)						
5	489427	Screw						
6	2155013	Clip, Grille						
7	489478	Screw						
8		Shim						
	2156056	(2)						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR LINER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2182147	Louver
6	2256035	Bracket, Dual Crisper
7	2216113	Thermistor
8	2256037	Wire Harness, Dual Crisper
9	2206273	Shelf Ladder
10	487539	Screw
11	486298	Screw (2)
15	2216112	Air Diffuser Assembly
16	2212240	Air Diffuser Cover
17	2150331	Cover, Wiring
18	2162085	Socket
19	2217199	Reservoir
20	527949	Light Bulb
21	2209769	Light Lens
22	488280	Screw
23	2179404	Rack, Wine & Egg

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2195978	Shelf Assembly, Cantilever (2)
2	2174253	Button, Humidity
3	2174252	Slide, Humidity
4	2174273	Gasket, Side (2)
5	2223357	Cover, Meat Pan (Includes Items 13, 14, & 15)
6	2255144	Glass, Cover
7	8281158	Screw
8	2255143	Glass, Cover
9	2256153	Cover, Crisper (Includes 2, 3, 4, 11, 12, 13, 14, & 19)
10	2196483	Stud Assembly
11	2223361	Gasket, (Front)
12	2223362	Gasket, (Rear)
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2223358	Crisper Pan (Includes 13, 14, 18, 19, & 21)
17	2223359	Meat Pan (Includes 13, 14, 19, & 22)
18	2174076	Window, Crisper
19	489261	Screw
20	2176095	Deflector
21	2223286	Cap, Crisper Pan Right Side
22	2223285	Cap, Crisper Pan Left Side
23	2174362	Window, Meat Pan
24	2216624	Egg Bin
25	2174021	Shelf & Roller Assembly
26	489439	Screw
27	3400894	Screw
28	2196485	Stud Assembly
29	2188669	Snack, Pan
30	2179243	Trim, Handle
31	2206346	Shelf, Snack Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# FREEZER LINER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2216113	Thermistor
3	3400893	Screw
4	2198697	Gasket
5	2223538	Basket, Top
6	2223541	Basket, Tall
12	2205826	Basket, Front
13		Shelf Track
	2261449	Right Side
	2261448	Left Side
14	2205837	Shelf
15	2223536	Basket, Sloped
16	486298	Screw (8)
17	842534	Clip, Air Duct (2)
19	2198587	Cover, Emitter
22	2198635	Spring
23	2198634	Pin
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2198642	Cover, Ice Maker
28	2212321	Slide, Ice Maker Mounting
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	527949	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2198588	Cover, Receiver
37	2198637	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2198609	Left Side
	2198610	Right Side
46	2219878	Shield, Wiring

# MOTOR AND ICE CONTAINER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MOTOR AND ICE CONTAINER PARTS


For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2198573	Ice Bin
2	2212367	Crusher Bin
3	2211590	Auger
4	2198603	Blade, Stirring
5	1119007	Spacer, Flat (6)
6	2255460	Cover, Crusher
7	1119013	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2198601	Blade, Fixed
10	1119012	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	1119006	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2198605	Button, Bin
20	2212371	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw (2)
23	8281163	Screw
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	999536	Drive Shaft
31	2198655	Bracket, Motor
32	2198594	Dispenser, Motor
33	2198626	Cover
34	8281162	Screw
35	489478	Screw
36	2212365	Sleeve, Coupling



# REFRIGERATOR DOOR PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# REFRIGERATOR DOOR PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #6)
	2207183W	White
	2207183T	Biscuit
	2207183B	Black
	2207183S	Stainless
2	2218122	Compartment Door
3	2205821	Shelf Bin (4)
4	3400012	Screw
6		Door Gasket, Magnetic
	2221302	Mist Beige
	2221313	Black
7	2193409	Beverage Holder
8		Handle
	2207112W	White
	2207112T	Biscuit
	2207112B	Black
	2207112S	Stainless Steel
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2200082	Chrome
	2200082B	Black
13		Screw
	3400898	White
	8281135	Biscuit
	3400899	Black
	3400897	Chrome
18	2165792	Butter, Dish
20	2159124	Gasket
21		Endcap
	2207111W	White
	2207111T	Biscuit
	2207111B	Black

# FREEZER DOOR PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# FREEZER DOOR PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2216062W	White
	2216062T	Biscuit
	2216062B	Black
	2216062S	Stainless
2		Handle
	2207112W	White
	2207112T	Biscuit
	2207112B	Black
	2207112S	Stainless
3	2171070	Shelf Bin (3)
5	2206178	Dispenser Harness
6	2154473	Connector
7		Screw
	3400898	White
	8281135	Biscuit
	3400899	Black
	3400897	Chrome
8		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
10	2219982	Trim, Door Shelf
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2200082	Chrome
	2200082B	Black
17	3400012	Screw
19	488500	Screw
23		Endcap
	2207110W	White
	2207110T	Biscuit
	2207110B	Black

# DISPENSER FRONT PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS


For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2256199	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2207109W	White
	2207109T	Biscuit
	2207109B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2180259	White
	2186850	Biscuit
	2180261	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2180268	White
	2186852	Biscuit
	2180270	Black
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available, Order #23)
20	2187406	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2207153W	White
	2207153T	Biscuit
	2207153B	Black
25	2195051	Strain Relief
26	3400065	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AIR FLOW PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer Fan Motor
3	2198595	Air Scoop
4	2212377	Air Duct, Upper
5	2198580	Air Duct Freezer
7	2162404	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
12	2216116	Harness, Fan Evaporator And Heater
13	2155789	Gasket, Evaporator Cover
14	2172840	Strap
16	2203876	Gasket
17	2206314	Cover, Evaporator
18	489355	Screw (6)
21	489478	Screw
22	2203595	Support, R.S.
23	2203596	Support, L.S.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2212005	Control Box
2	2216879	Cover
3	3196537	Screw
4	2219875	Light Switch
6	2252140	Control Board
7	489290	Screw
8	940014	Hole Plug
9	2212011	Insert, Control Board
17	2162085	Light Socket
19	527949	Light Bulb
20	2216115	Harness, Control Box
21	1115374	Clip, Wiring
25	2220255	Overlay, Control Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# UNIT PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

For Models: **KSRS25ILWH13**, **KSRS25ILBT13**, **KSRS25ILBL13**, **KSRS25ILSS13**  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut	26	2187783	Harness, Unit	Following Parts Not Illustrated and Optional Parts Not Included		
2	2190685	Fan, Blade	27		Drier			
3	2204484	Condenser Assembly		2199167	Production			
4	489464	Screw		4387019	Service			
5	2216914	Clip, Condenser	28	2212192	Compressor			
6	2255798	Tube, Condenser to Heat Loop			(Includes Items 10, 12, 13, 17, 27 & 29)			
7	2256150	Heat Shield And Drain Pan			(Also Order 876765 Tube Kit)			
8	2205765	Tube Suction	29	4387765	Wire, Capacitor (Service Only)			
9	2216997	Insert, Bracket	30	2157397	Unit Mounting Frame			
10	2183454	Relay (Service Only)	32	2181929	Bracket, Fan Motor			
11	8281160	Screw	33	2188175	Heater, Defrost			
12	4387731	Cover (Service Compressor Only)	34	2161330	Clip, Heater			
13	2154697	Overload (Service Compressor Only)	35	2196155	Bi-Metal, Defrost			
15	2223314	Clip, Retaining	37	489373	Screw			
16	2220475	Start-Device, Combination (Start Relay and Overload) for Production Compressor Only	39		Grommet (4) Production			
17		Capacitor		1100826	Service			
	999532	Production	40	489340	Screw			
	1118576	Service	41	2196202	Air Baffle			
20	2206281	Unit Cover, Bottom	42	2155547	Clip, Heat			
21	489396	Clip	48	1127911	Unit Mounting Rail			
22	2209611	Evaporator	49	8281232	Screw			
23	2161324	Clip	50	2186495	Guard, Fan			
24	2206005	Motor, Fan	51	2161302	Sleeve			
25	1105523	Tray, Evaporator	52	2172840	Wire Tie			
			53	489427	Screw			
			55	489478	Screw			
			59	2208280	Clip, Wire & Tube			
			63	2209709	Union			


### REFRIGERANT CHARGE

5.0 oz.  
(R-134A)



# ICEMAKER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
2	2256096	Fitting, Water Tube
3	2255012	Tube, Filter Outlet
4	2188744	Tube, Filter Inlet
5	628379	Clip, Fuse
9	489478	Screw
10	2188746	Valve, Solenoid
16	2208136	Clip, Tube
18	2174358	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Bearing & Inlet
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
29	2212322	Bracket, Ice Maker Mounting
30	489276	Screw
32	2187467	Harness, Wiring
35	626653	Module Assembly (Includes Items 37 & 38)
37	627811	Motor
38	489136	Screw
100	2198597	Icemaker Assembly

# PARTS NOT ILLUSTRATED

For Models: KRSR25ILWH13, KRSR25ILBT13, KRSR25ILBL13, KRSR25ILSS13  
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			<b>Miscellaneous</b>			<b>Refinishing Material</b>		
<b>Customer Touch-Up Material</b>				8129	Coil Brush		799340	Enamel, Black (1 Qt. Uncut)
	*350942	Primer, White (12 Oz. Spray Can)		212643	Sealer, Gum (4 Feet)		799344	Enamel, White (1 Qt. Uncut)
	*350939	Enamel, Black (12 Oz. Spray Can)		479502	Tape, Vinyl (3/4 x 108")		4392900	Enamel, Biscuit (1 Qt. Uncut)
	*350930	Enamel, White (12 Oz. Spray Can)		876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")		8171358	Enamel, Graphite (1 Qt. Uncut)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)		876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")	<b>TORX SCREW WRENCH</b>		
	*8171357	Enamel, Graphite (12 oz. Spray Can)		978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)		1117510	Torx Key
	72017	Brush Touch-Up Kit (White)		876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")			
	4392899	Brush Touch-Up Kit (Biscuit)		505587	Sealer, Mastic (1 Qt.)			
	72032	Brush Touch-up Kit (Black)		503695	Cork, Sealer (1/4 Pound)			
	80051	Brush Touch-up Kit (Graphite)		511873	Touch-Up, White Porcelain (2 Oz.)			
<p><b>*Important:</b> The spray paint is not to be used where the paint may make contact with the door gaskets.</p>				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				606755	Bag, Insulation (36-5/8" x 46")			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			
				2216051	Ice Container- Crusher Assembly			
				2006783	Cleaner, Stainless Steel			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST