


For Models: KSRS25RSWH01, KSRS25RSBT01, KSRS25RSBL01, KSRS25RSMS01, KSRS25RSMK01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: KSRS25RSWH01, KSRS25RSBT01, KSRS25RSBL01, KSRS25RSMS01, KSRS25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	15		Grille	29	4396841	Water Filter
	2318734	Energy Guide		2303292W	White	30		Cap, Water Filter
	2318586	Owner's Manual		2303292T	Biscuit		2260502W	White
	2303925	Service Sheet		2303292B	Black		2260502T	Biscuit
	2303929	Wiring Sheet		2303292AP	Apollo Gray		2260502B	Black
	2220407	Modular Icemaker Service Sheet	16	489497	Screw		2260502AP	Apollo Gray
	2308395	Instruction Sheet, Door Removal	17	489464	Screw	31	489500	Screw
2	2254628	Front Roller (2)	18	2304888	Drain Fitting	32	3400113	Screw
3	W10079910	Screw	19	1108438	Extension Tube	33	2303141	Bottom Hinge (FC)
4	2254625	Rear Roller (2)	20	1108439	Clip, Drain Tube	34	2260519	Block, Housing Support
5	489427	Screw	21	2188735	Cover, Unit	35	2304708	Tube, Filter Outlet
6	2155013	Clip, Grille	22		Cabinet (Not A Serviceable Part)	36	2203770	Hinge Top (FC)
7	488500	Screw	23		Hinge Cover	37	2319867	Tube, Filter Inlet
8	2156056	Shim		2303135W	White	38		Button, Water Filter
9	2203771	Hinge Top (RC)		2303135T	Biscuit		2260503W	White
11	8281227	Screw		2303135B	Black		2260503T	Biscuit
12		Hinge Cover		2303135AP	Apollo Gray		2260503B	Black
	2303134W	White	24	549193	Clamp, Service Cord		2260503AP	Apollo Gray
	2303134T	Biscuit	25	489084	Screw	39	2223751	Door Closer, FC
	2303134B	Black	26	2155311	Door Closer, RC	40	2305373	Clamp, Cord
	2303134AP	Apollo Gray	27	489483	Screw			
13	2304322	Bottom Hinge (RC)	28	2260507	Housing, Water Filter			
14		Filler, Wrapper						
	2304846	White						
	2304849	Biscuit						
	2304848	Black						
	2315169	Apollo Gray						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSRS25RSWH01, KSRS25RSBT01, KSRS25RSBL01, KSRS25RSMS01, KSRS25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2255612	Escutcheon, Meat Pan Control
3	2301339	Slide Meat Pan Control
4	2257741	Louver
5	2301235	Slide, Door Control
6	2179404	Wine Rack
9	2319866	Shelf Ladder
10	489478	Screw
11	W10004810	Screw
12	2301234	Housing, Door Control
13	2150331	Cover, Conduit
15	2216112	Air Diffuser Assembly
16	2212240	Cover, Air Diffuser
18	2162085	Socket
19	2305226	Reservoir
20	2255743	Light Bulb
21	2209769	Light Lens
22	488280	Screw
23	2256035	Bracket, Dual Crisper
24	2311637	Wire Harness, Dual Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1	2301072	Frame Assembly (2)
2	2301023	Snack Bin Asm (Includes 24 & 25)
3	2301567	Cover, Crisper (Includes 11, 12, 16, 17, 19 & 20)
4	2196485	Stud Assembly
5	3400894	Screw
6	2301028	Glass, Meat Cover
7	2301027	Glass, Cover
8	2301568	Cover, Meat Pan (Includes 16 & 18)
9	2196483	Stud Assembly
10	2301031	Crisper Pan Asm (Includes 21 & 24)
11	2301026	Slide, Humidity Control
12	2301025	Knob, Humidity Control
13	2301084	Shelf & Roller Assembly (2)
14	2301022	Meat Pan Asm (Includes 24 & 27)
15	8281158	Screw
16		Glide Assembly (Crisper Pan)
	2301548	Right Side
	2301549	Left Side
17	2301115	Gasket, Rear
18	2301126	Deflector
19	2301116	Gasket, Front
20	2301117	Gasket, Side (2)
21	2301001	Window, Crisper Pan
22	2301566	Shelf, Snack Pan
23		Support Assembly
	2301569	Right Side
	2301570	Left Side
24		Cap, Corner
	2301016	Right Side
	2301017	Left Side
25	2301006	Window, Snack Pan
26	2188212	Roller (2)
27	2301227	Window, Meat Pan
28	489439	Screw (2)
29		Glide Assembly (Snack Pan)
	2301550	Right Side
	2301551	Left Side

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSRS25RSWH01, KSRS25RSBT01, KSRS25RSBL01, KSRS25RSMS01, KSRS25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER LINER PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
6	2301139	Basket, Tall
11	3400893	Screw
12	2301134K	Front, Basket
14	2205837K	Shelf (2)
15	2301140	Basket, Sloped
16	8534064	Screw (12)
17	842534	Clip, Air Duct (2)
18	2301138	Basket, Top
19	2198587	Cover, Emitter
21	2198697	Gasket, Ladder
22	2198635	Spring
23	2198634	Pin
24		Glide Assembly, Top Basket
	2301540	Right Side
	2301541	Left Side
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2255590	Cover, Ice Maker
28	2212321	Slide, Ice Maker Mounting
29	489478	Screw
30	489214	Screw
31		Glide Assembly, Middle/Bottom Basket
	2301542	Right Side
	2301543	Left Side
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255561	Cover, Receiver
37	2301340	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2320024	Left Side
	2320025	Right Side
46	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


MOTOR AND ICE CONTAINER PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1	2305336	Ice Bin
2	2305294	Crusher Bin
3	2258222	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (4)
6	2305244	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2305382	Rubber Boot
20	2305441	Latch, Bin
21	2198608	Spring, Latch
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	2305243	Drive Shaft
32	2252130	Dispenser, Motor
33	2305208	Bracket, Motor
35	8281163	Screw
36	2212365	Sleeve, Coupling
100	2305425	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR DOOR PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #6)
	2303139W	White
	2303139T	Biscuit
	2303139B	Black
	2303139SAP	Stainless Steel
2	2301486	Door Compartment (Includes 7)
3	2223434K	Door Bin (4)
4	3400012	Screw
5	2219698	Stud, Handle
6		Door Gasket, Magnetic
	2221302	Mist Beige
	2221313	Black
	2326338	Apollo Grey
7	2159124	Gasket
8		Handle (Includes #13)
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless
9	488208	Screw
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
13		Screw, Set
	W10010140	Chrome
	W10010150	Black
14	2165792K	Butter Dish
15	2193409K	Beverage Holder(2)
16		Nameplate
	W10046670	(White)
	W10046700	(Biscuit)
	W10046640	(Black)
	W10046610	(Stainless)
17	2303107	Thimble, Top

FREEZER DOOR PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)


Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2303140W	White
	2303140T	Biscuit
	2303140B	Black
	2303140SAP	Stainless Steel
2		Handle (Includes #15)
	2319727W	White
	2319727T	Biscuit
	2319727B	Black
	2319727S	Stainless
3	2304925K	Trivet (3)
4	2219698	Stud, Handle
5	2303107	Thimble, Top
7	488208	Screw
8		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
	2326339	Apollo Grey
9	2304895	Safety Barrier
12	2223752	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
15		Screw, Set
	W10010140	Chrome
	W10010150	Black
17	3400012	Screw

Following Parts Not Illustrated

- 2305405 Tube,
Water Dispenser
- 2310075 Wire Assembly,
Freezer Door

DISPENSER FRONT PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
(White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
3	2305202	Bracket, Motor
4	2305242	Connector, Door Bracket
5	2305262	Motor, Ice Door
6	2305258	Door, Ice
7	2305204	Support, Ice Door
8	4449745	Screw (4)
9	2305447	Clip, Wiring
10	2305236	Spigot
11	2305456	Separator Assembly
12	2303843	Electronic Control (Core)
13		Pad, Water
	2305307CE	For White Model
	2305307MN	For Biscuit Model
	2305307GE	For Black Model
	2305307GN	For Monochromatic Stainless Model
14	2305287	Lens, Front Cover
16	2304140	Cover, Electronic Control (User Interface)
17		Pad, Ice
	2305306CE	For White Model
	2305306MN	For Biscuit Model
	2305306GE	For Black Model
	2305306GN	For Monochromatic Stainless Model
18	2305219	Cover, PC Board
20	2305342	LED Assembly
21		Front Cover, Housing (Not Available, Order #23)
22		Tray, Housing
	2315111W	White
	2315111T	Biscuit
	2315111B	Black
	2315111US	Universal Silver
23		Front Cover Assembly (Includes Items 13, 14, 16, 17, 20 & 21)
	2305312W	White
	2305312T	Biscuit
	2305312B	Black
	2305312S	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer Fan Motor
4	2313359	Air Duct, Upper
5	2198580	Air Duct Freezer
6	2319914	Bi-metal, Defrost
7	2315549	Fan Motor
8	2169142	Fan Blade
9	2188819	Thermister
10	2176759	Fan Grommet (2)
11	2304241	Gasket, Evaporator Cover (2)
12	2310238	Harness, Fan Evaporator (Includes #6)
13	2155789	Gasket, Fan Scroll
14	2172840	Strap
16	2203876	Gasket
17	2206314	Cover, Evaporator (Includes #11)
18	8281159	Screw (6)
21	489478	Screw
22	2203595	Support, R.S.
23	2203596	Support, L.S.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



Illus. No.	Part No.	DESCRIPTION
1	2212005	Control Box
2	2219875	Switch
3	3196537	Screw (4)
4	2216879	Cover, Control Box
6	2321728	Electronic Control


Illus. No.	Part No.	DESCRIPTION
7	8281244	Screw (4)
8	940014	Hole Plug
9	1115374	Clip, Wiring
10		Insert, Control Board (Not Available, Order #6)

Illus. No.	Part No.	DESCRIPTION
17	2162085	Light Socket
19	2255743	Light Bulb
20	2216115	Control Box Harness
25	2318773	Overlay, Control Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: **KSRS25RSWH01, KSRS25RSBT01, KSRS25RSBL01, KSRS25RSMS01, KSRS25RSMK01**
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION		
1	2169104	Insulation, Sound	26	2310229	Harness, Unit	52	2172840	Wire Tie		
2	2225834	Fan, Blade	27	2317845	Drier (Service Only)	53	489427	Screw		
3	W10121484	Condenser Assembly	28	W10120456	Compressor (Includes Items 12, 13, 17, 27, 29, 31 & 39) (Also Order 876765 Tube Kit)	55	489478	Screw		
4	489464	Screw				59	2208280	Clip, Wire & Tube		
5	2216914	Clip, Condenser				63	2305227	Union		
7	2217194	Heat Shield And Drain Pan				Following Parts Not Illustrated and Optional Parts Not Included				
8	2205765	Tube Suction				29	2183454	Relay (Service Only)	978025	Valve, Access (1/4")
10	8533993	Screw	30	2304904	Unit Mounting Frame	978026	Valve, Access (5/16")			
12	4387731	Cover (Service Only)	31	4387765	Wire, Capacitor (Service Only)	978027	Valve, Access (3/8")			
13	2255198	Overload (Service Only)	32	2181929	Bracket, Fan Motor	978028	Valve, Access (1/2")			
15	2255199	Clip, Retaining	33	2188175	Heater, Defrost	978029	Valve, Access (5/8")			
16	2319792	Start-Device, Combination (Start Relay and Overload) for Production Compressor Only	34	2304287	Clip, Heater	978030	Valve, Access (3/4")			
17		Capacitor	37	489373	Screw	876764	Valve, Access (3/16")			
	2169373	Production	39	1100826	Grommet (4) Production	REFRIGERANT CHARGE				
	1118576	Service	40	489340	Screw	5.0 oz. (R-134A)				
20	2304899	Unit Cover, Bottom	41	2196202	Air Baffle					
21	489396	Clip	42	2155547	Clip, Heat					
22	2188823	Evaporator	48	2305374	Unit Mounting Rail					
23	2161324	Clip	49	8281232	Screw					
24	2188874	Motor, Fan	50	2260517	Guard, Fan					
25	1105523	Tray, Evaporator	51	2161302	Sleeve					



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. No.	Part No.	DESCRIPTION
2	2256096	Fitting and Water Tube
5	628379	Clip, Fuse
9	489478	Screw (3)
10	2305225	Smart Valve
18	2174358	Cover
19	488649	Screw
20	2255835	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Bearing & Inlet
23	627843	Ejector
24	2198598	Ice Stripper
25	2194712	Support
26	2315522	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
29	2303583	Bracket, Ice Maker Mounting
30	489276	Screw
32	2187467	Harness, Wiring
35	626691	Module Assembly (Includes Items 37 & 38)
37	626683	Motor
38	489136	Screw
100	626663	Icemaker Assembly

OPTIONAL PARTS (NOT INCLUDED)

For Models: KRSR25RSWH01, KRSR25RSBT01, KRSR25RSBL01, KRSR25RSMS01, KRSR25RSMK01
 (White) (Biscuit) (Black) (Monochromatic Stainless) (Monochromatic Stainless)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<p><u>PAINT, PRESSURIZED SPRAY</u> <u>(12 oz.)</u></p> <ul style="list-style-type: none"> *350942 Primer, White *350939 Black *350930 White *4392901 Biscuit *8171357 Graphite <p><u>PAINT, TOUCH-UP (1/2oz.)</u></p> <ul style="list-style-type: none"> 72017 White 4392899 Biscuit 72032 Black 80051 Graphite <p>*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.</p>	<p><u>PAINT, BULK (1 qt.)</u></p> <ul style="list-style-type: none"> 799340 Black 799344 White 4392900 Biscuit 8171358 Graphite <p><u>Miscellaneous</u></p> <ul style="list-style-type: none"> 8129 Coil Brush 212643 Sealer, Gum (4 Feet) 479502 Tape, Vinyl (3/4 x 108") 505587 Sealer, Mastic (1 Qt.) 503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic (1-1/4 Oz.) 799833 Kit, Evaporator Repair (Aluminum Epoxy) 833938 Kit, Terminal Connector 	<p><u>ACCESSORIES</u></p> <ul style="list-style-type: none"> 2217192 Cleaner, Stainless Steel <p><u>TORX SCREW WRENCH</u></p> <ul style="list-style-type: none"> 1117510 Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST