


KitchenAid®

CABINET PARTS

For Model: KSSS36DBX01

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)	15	1112848	Drain Fitting	28		Gap, Cover
2	1112019	Leveler, Front (2)	16		Gap, Cover Assembly (Top)		2001200	Left Side
3	1113249	Retainer (2)		2000305	Left Side		2001199	Right Side
4	1112023	Roller, Front & Rear (4)		2000304	Right Side	29		Hinge (Bottom)
5	1112695	Leveler, Adjustable (2)	17	2001295	Shoulder Screw		2001733	Left Side
6	2000670	Adjusting Rod (2)	18		Hinge (Top)		2001732	Right Side
7	1113250	Sleeve, Retainer (2)		2000306	Left Side	30	1112942	Shim, Hinge (1)
8	1112937	Bushing, Rod (2)		2000307	Right Side		1112943	Shim, Hinge (2)
9	489359	Screw	19	2000770	Shim, Hinge Top	31	2000490	Screw
10	1112939	Hole Plug, Leveler	20	1112805	Guard, Wiring	33	2001266	Tube clamp
11	1112849	Cap, Grommet	21	487534	Screw (2)	34	2001962	Grille Base, Front
12	1112970	Grommet, Water Tube	23	1112992	Door Closer Assembly (2)	35	489238	Screw (6)
13	1113122	Grommet, Wiring	24	2000333	Bracket, Door Closer	36	2000727	Cover, Rear
14	2000830	Wiring Harness, Cabinet	25	486194	Screw, 8 x 1/2	37	1113123	Grommet, Wiring
			26	1112973	Tap Plate, Hinge Butt (2)	38	1113079	Grommet, Flexible
			27	1113227	Fastener (3)	39	1112926	Grommet, Tube
						41	2001377	Screw
						42	2000530	Grommet
						43	2001415	Screw (8)
						44	489359	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Model: KSSS36DBX01




Illus. No.	Part No.	DESCRIPTION
1	2000321	Cabinet, Trim R.S
2	2000322	Cabinet, Trim L.S
3	2001297	Screw
4	1112800	Cabinet, Trim (Bottom)
5	488649	Screw (8)
6	2001309	Cabinet, Trim Top
7	2000007	Retainer, Unit Base (2)
8	487944	Washer (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: KSSS36DBX01




Illus. No.	Part No.	DESCRIPTION
1	2001315	Decorative Panel Assembly
2	1113313	Back Up Panel
3	2002115	Top Grille Assembly
4	2002511	Cover, Unit
5	486194	Screw
6	2001874	Cover, Component Assembly
7	1113317	Brace

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
3	502037	Grommet, Screw
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw (8)
8	486194	Screw
9	1112257	Hole Plug
10	2000740	Meat Pan, Air Duct Cover (Also Order 12)
11	2000337	Meat Pan, Air Duct
12	2001302	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2001735	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	2000343	Air Baffle Assembly
20	2001073	Wiring Harness, Air Baffle
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2000736	Air Baffle Cover
26	2000527	Guard, Air Return

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Model: KSSS36DBX01




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw (2)
9	992720	Stud, Support (4)
12	486194	Screw
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (8)
18	487559	Screw (8)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Model: KSSS36DBX01




Illus. No.	Part No.	DESCRIPTION
1	1112365	Solid Shelf
2	2000885	Front, Ice Compartment
3	1113564	Shelf, Fixed (2)
	1113636	Shelf, Deep
4	2001551	Basket
5	1113642	Trim, Basket
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw
18	488307	Washer
22	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
24	1113169	Stop, Roller
25	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	1113542	Frame, Shelf
2	1112297	Glass, Shelf
3	1113546	Reflector, Shelf
4	1113790	Gasket, Glass (2)
5	1125913	Rack, Wine
7	1113550	Frame, Assembly
8	2164372	Egg Bin
9	1113893	Cover, Crisper
10	2000154	Glass, Crisper
11	2000742	Meat Pan, Connector
12	2164373	Egg Carrier
13	2164374	Cover
14	2000887	Crisper Pan
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw
18	488307	Washer
19	2000891	Utility Pan
20	2000815	Meat Pan
23	1112324	Retainer, Glass
25	1112165	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	1113890	Crisper Spacer, Left Side (2)
29	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	2000693	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	2000696	Hinge Assembly, Top
4	2000303	Spacer
5	489282	Screw
6	2000698	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112539	Gasket Retainer, Top & Bottom
9	2000878	Door Gasket, Magnetic
10	489101	Screw (36)
11	2000323	Handle, Door
12	2002314	Tap, Plate
13	2000697	Door, Spacer Bottom
15	487052	Screw
16	2000315	Trim (Top)
17	489112	Screw
18	2000314	Trim (Side)
19	2000318	Trim (Bottom)
20	1113952	Panel, Interior Door
21	1113951	Ladder, Shelf (2)
22	1112530	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw
25	1112720	Bin, Utility
26	1112735	Door, Utility Bin
27	2000911	Door Shelf (4)
28	1125936	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	2001136	Exterior Door Panel, Freezer (Includes Insulation)
2	1112997	Tube, Wiring
3	1112928	Retainer, Tube
6	2000720	Hinge, Bottom
7	489282	Screw
8	2000721	Hinge, Top
9	2000303	Door Spacer
10	2001031	Overlay, Shelf
11	2001323	Wiring Harness, Freezer Door
12	1112533	Gasket Retainer, Side (2)
13	1112538	Gasket Retainer, Top & Bottom
14	2000877	Door Gasket, Magnetic
15	489101	Screw (34)
16	2000324	Handle, Door
17	2002314	Tap, Plate
18	2000697	Door, Spacer
20	487052	Screw
21	2000326	Trim (Top)
22	489112	Screw
23	2000329	Trim (Bottom)
24	2000325	Trim (Side)
26	1113945	Panel, Interior Door
28	1112765	Door Shelf, Outer Trim
29	1112770	Door Shelf, Inner Trim
31	1112763	Support, Trim Ends
32	227991	Wire Connector
33	939101	Screw Anchor
34	2000798	Ice Chute

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER AND FRONT PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER AND FRONT PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	1107943	Housing, Dispenser
2	987049	Bracket, Water Fitting
3	2155018	Water Fitting Assembly (Includes Water Tube)
4	487916	Screw
5		Water Tube (See Item #3)
9	488316	Screw
10	987048	Grommet
11	2001334	Heater, Ice Dispenser
12	2147167	Ice Door Mechanism
13	2147168	Door, Ice
14	1129333	Shroud
16	489000	Screw
17	1127421	Lever, Ice Dispenser
19	987917	Bearing, Clip
20	2159196	Lever, Water Dispenser
21	488307	Washer
22	983696	Spring, Lever
23	983697	Bearing, Lever
24	1120581	Delay Mechanism
25	1107454	Bracket, Control
26	841336	Switch
27	984683	Insulation, Switch
28	488361	Screw
29	987265	Lamp Holder
30	488500	Screw
31	851386	Light Switch
32	1107457	Plunger, Extension
33	983986	Spring, Plunger
34	983987	Retainer, Pin
35	2001350	Wiring Harness, Door
36	984494	Wiring Shield
37	1118269	Guiding, Ice
38	1119056	Glass Stop
39	489197	Screw
40	487052	Screw
41	851389	Light Bulb
42	2001478	Front Cover, Housing
44	1112836	Cover, Dispenser Opening
45	2001475	Trim, Front (2)
46	487052	Screw
47	983900	Grille, Overflow
48	934316	Switch
49	2001481	Overlay, Cover
53	487944	Washer (2)
54	488568	Screw (2)
55	482672	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


For Model: KSSS36DBX01

REFRIGERANT CHARGE

8.5 oz.
(R-12)

LOWER UNIT AND TUBE PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw
4	2000860	Sleeve
5	2001778	Sleeve
6	2001705	Condenser Inlet Tube
8	2002408	Tube, Connect (Drier)
9	2000754	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw
13	2002381	Tube, Discharge
14	2003271	Sleeve
15	2000722	Heat Exchanger
16	1113040	Evaporator
17	2000630	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
22	1113070	Guard, Hook-Up
23	851095	Strap (7)
24	488946	Clamp, Wiring
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	(L.H.)
	1113207	(R.H.)
27	513942	Dampener
28	934011	Clip, Water Tube

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW AND RESERVOIR PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW AND RESERVOIR PARTS


For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION
1	2001086	Fan Motor
2	488908	Screw
3	2169142	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw
8	2000618	Motor, Wiring
9	488366	Clamp
10	1129179	Nut, Compression
11	489348	Clamp, Nylon
12	2001256	Channel, Wiring
13	2150347	Union
14	2000783	Scroll, Fan
15	2001791	Elbow
16	488772	Screw
17	2000744	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
19	1112870	Cup, Motor
20	2001150	Water Tube (Inlet)
21	1112871	Fastener (3)
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
24	2001153	Water Tube
25	2000339	Cover, Evaporator
26	2000797	Connector, Meat Pan Duct
27	487539	Screw
28	1112840	Baffle, Evaporator
29	1112851	Diffuser, Air Duct
30	1129170	Reservior, Water
31	488775	Screw
32		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
33	2001337	Gasket (2) Evaporator Cover
34	2001079	Gasket (2)
35	2001080	Gasket
36	2001081	Gasket
37	488819	O-Ring, Seal
38	841707	Insert
39	488795	Nut, Compression

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: KSSS36DBX01



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: KSSS36DBX01

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	489084	Screw	15	489348	Clamp, Nylon Valve	28	489322	Screw
2	2000829	Fitting, Water Tube	17	487857	Nut	29	628399	Module Assembly
3	2001087	Clamp, Tube	18	628355	Cover	30	489276	Screw
4	841707	Insert, Tube	20	628228	Mold & Heater (Also Order 542638 Silicone Grease)	31	2171593	Shut Off Arm
5	628379	Clip, Fuse	21	628398	Motor	32	1113403	Harness, Wiring
6	2000392	Wire Clip	22	628356	Cup-Water Fill	33	627915	Bracket
7	2001260	Tube, Water (To Ice Maker)	23	627843	Ejector	34	489242	Screw
8	1106508	Seal Gasket	24	627788	Ice Striper	35	628366	Module Assembly (Includes Items 21, 29, 41)
9	487627	Sleeve, Nut	25	627790	Support	37	2000803	Water Valve Mounting Bracket
10	2002182	Valve, Solenoid	26	627796	Retainer	38	2001098	Water Inlet Tube
11	627018	Nut, Compression	27	627985	Thermostat (Also Order 542639 Cement Alumilastic)	41	489136	Screw (2)
12	227991	Connector, Wire				43	486194	Screw, 8 x 1/2
13	2000836	Water Valve, Harness				44	1129179	Compression Nut
14	2001353	Copper, Water Line				45	1129177	Insert, Tube
						100	4317943	Complete Ice maker Assembly

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated (Optional Parts Only)		

4210464	Front Panel Kit (White)
4210469	Front Panel Kit (Black)
4211168	Front Panel Kit (Almond)
4210593	Stainless Steel

Black Acrylic
Static Cleaner Part No. 978849


LITERATURE PARTS

LIT2002424	Use & Care Guide
LIT2002693	Energy Label
LIT2002107	Service & Wiring Sheet
LIT628370	Modular Ice maker Service Sheet
LIT2002469	Installation Instructions

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICE CONTAINER PARTS

For Model: KSSS36DBX01



Illus. No.	Part No.	DESCRIPTION
1	1112282	Spacer, Track Left Side
	1112281	Right Side
2	1113870	Roller
3	1113871	Eyelet, Roller
5	1113169	Stop, Roller
6	488307	Washer
7	488645	Screw
8	1112291	Bracket, Motor
9	2155262	Motor Assembly


Illus. No.	Part No.	DESCRIPTION
10	489399	Screw
11	983663	Coupling, Motor
12	1112613	Socket, Light
13	1113128	Cover, Motor
14	487294	Screw
15	1112285	Ice Container
16	1112378	Conveyor
17	983668	Coupling, Conveyor
18	946192	Drive Bar, Drum

Illus. No.	Part No.	DESCRIPTION
19	946195	Bearing Nut
20	946193	Drum
21	946194	Baffle
22	2001034	Overlay, Cover
23	1112380	Front Cover
24	488886	Screw (5)
25	489211	Screw
28	1113140	Lens, Dispenser
29	547225	Light Bulb

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER CONTROL PANEL PARTS

For Model: KSSS36DBX01




Illus. No.	Part No.	DESCRIPTION
1	1112595	Control Panel
2	1113963	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	851387	Switch, Rocker Arm (Dispenser Motor)
6	1113132	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113767	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	2001737	Knob, Thermostat
17	1115375	Clip, Wiring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR CONTROL PANEL PARTS

For Model: KSSS36DBX01



Illus. No.	Part No.	DESCRIPTION
1	1112640	Control Panel
2	2000974	Inlay, Control Panel
3	2000789	Circuit Board
4	2001738	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113133	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113773	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw
14	2001074	Control, Panel Harness
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST