

KitchenAid® CABINET PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00


42" BUILT IN REFRIGERATOR

(Black)

(Biscuit)

(White)

(Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00


(Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT2215850	Literature Parts Use & Care Guide	12	2209022	Housing, Water Filter	32		Skirt-Grille, Bottom
	LIT2221055	Energy Label	13	2006806	Support, Bottom (Right Side)		2209025W	White
	LIT2221021	Service & Wiring Sheet	15	2203220	Filter, Water		2209025B	Black
	LIT628370	Modular Ice maker Service Sheet	16	2006807	Support, Bottom (Left Side)	33	8201584	Biscuit Extension Arm, Door Closer
	LIT2215852	Installation Instructions	17	2005378	Screw, Door Stop	34		Grille Bottom, Front
2		Cabinet (Not A Serviceable Part)	18	2005295	Hinge (Top)		2209428W	White
3	2005004	Grommet, Tube Crossover	19	489478	Screw		2209428B	Black
4	1112023	Roller, Front & Rear (4)	20	489464	Screw		2209428T	Biscuit
5		Support, Leveler Assembly	21	2004994	Lock, Adjustable Bushing	35	2005921	Screw
	2004506	Refrigerator Side	22	2002903	Bushing	36		Bracket, Support Base (Front)
	2004505	Freezer Side	23	2209090	Clamp, Filter Housing		2006616	Left
6	2005006	Grommet, Wiring	24	2004517	Spring, Door Closure (2)		2006556	Right
7	2005007	Grommet, Flexible	25	486194	Screw	37	1157158	Screw
8		Cap, Water Filter	26	2005008	Retaining Ring, Adjustable Bushing	38	2006617	Bracket, Support Base (Rear) (2)
	2186494W	White	27	1113227	Fastener (3)	39	2006346	Washer
	2186494B	Black	28	2006342	Gap, Cover Assembly (Bottom)	40	2006960	Bushing, Extension Arm
	2186494T	Biscuit	29		Hinge (Bottom)	41	1163283	Screw
9	2006442	Mounting Stud, Grill		2006780	Freezer Side	42	2196152	Union
10	2005237	Clip, Wire		2006779	Refrigerator Side	43	2001415	Screw (4)
11	2005783	Cam, Door Closer	30	2004992	Bushing, Adjustable	44		Switch, Rocker Arm
			31	2001415	Screw		1118894	Refrigerator Door Side
							1115373	Freezer Door Side
						45	2215938	Cover, Switch (2)
						46	487415	Screw (4)
						47		Bracket, Cover
							2215923	Right
							2215937	Left
						48	2209449	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)




Illus. No.	Part No.	DESCRIPTION
1		Cabinet, Trim (Right Side)
	2215919W	White
	2215919B	Black
	2215919T	Biscuit
	8201535	Etched Aluminum
2	2003857	Screw
3		Screw
	8281251	White
	8281252	Black
	8281253	Biscuit
	8281250	Stainless Steel
4	2209074	Cabinet, Trim (Bottom)
5	486194	Screw
6	2003646	Cabinet, Trim Top
7		Cabinet Trim (Left Side)
	2215936W	White
	2215936B	Black
	2215936T	Biscuit
	2215936	Etched Aluminum
9	2005925	Seal-Trim, Side
10	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER SHELF PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)




Illus. No.	Part No.	DESCRIPTION
1	2220890	Solid Shelf
2	2220847	Front, Ice Compartment
3	1113637	Shelf, Fixed (2)
	1113565	Shelf, Deep
4	2208194	Basket
5	2220844	Trim, Basket
6	2208198	Right Side
	2208197	Left Side
7	486194	Screw
8	2003046	Hole Plug, Front
9	2003047	Hole Plug, Rear
10	2208907	Ice Container
11	2003044	Front Cover
12	2002720	Right Side
	2002721	Left Side
13	488886	Screw
14	1113169	Stop, Roller
15	2188212	Roller
16	2174478	Eyelet, Roller
17	2003478	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
3	2208970	Air Duct
4	2209204	Clip, Thermistor
5	2208975	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw
8	486194	Screw
9	1112257	Hole Plug
10	2220888	Meat Pan, Air Duct Cover
11	2000337	Meat Pan, Air Duct
12	2220993	Release Valve
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2003811	Control Knob, Meat Pan
16	2003841	Retainer, Knob
17	2208904	Air Baffle Assembly
18	2209687	Reservoir
19	488280	Screw
21	2208997	Diffuser Assembly
22	1116793	Cover, Thermistor
23	2213442	Thermistor
25	2215728	Cover, Diffuser
26	2003577	Guard, Air Return

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)




Illus. No.	Part No.	DESCRIPTION
1	2215716	Control Box
2	2215670	Insert, Control Box
3	2209159	Circuit Board, Housing Control
4	2215941	Control Box Wire Harness
5	2003841	Retainer, Knob
11	2162085	Socket, Light (2)
12	2160708	Light Bulb (2)
13	486194	Screw
15	2221066	Overlay

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)




Illus. No.	Part No.	DESCRIPTION
1	2215962W	Top Grille Assembly White
	2215962B	Black
	2215962T	Biscuit
	8201577	Etched Aluminum
2	2209490	Cover, Unit
3	486194	Screw
4	2215830	Back Panel
5	2209492	Guard, Wiring
6	487415	Screw
7	2220808	Wire Assembly RC/FC Light Switch
8	2006440	Baffle-Air, Condenser
9	489348	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR SHELF PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	2174403	Frame, Shelf
2	2003376	Glass, Shelf
3	1113547	Reflector, Shelf
4	1113791	Gasket, Glass (2)
5	2179404	Rack, Wine
6	2216625	Egg Bin
7	2006524	Frame, Assembly Meat Pan
9	1113894	Cover, Crisper
10	2003379	Glass, Crisper (Includes #9)
11	2000742	Meat Pan, Connector
12	2169935	Cover
14	2220896	Crisper Pan (2)
15	2188212	Roller
16	2174478	Eyelet, Roller
17	2003478	Screw
20	2220902	Meat Pan
23	2002181	Retainer, Glass
25	2006515	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	2006516	Crisper Spacer, Left Side (2)
29	486194	Screw

FREEZER LINER AND AIR FLOW PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER AND AIR FLOW PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00


(Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	2208939	Fan Motor
2	2002732	Cup, Clearance
3	2169142	Fan Blade
4	2155590	Retainer, Fan Motor
5	2155789	Gasket, Cover
6	2208968	Grommet
7	486194	Screw
8	2003925	Deflector, Air Duct
9	488500	Screw, Ground
10	2162085	Socket, Light (2)
11	488937	Clamp, Nylon
12	2160708	Light Bulb
13	1112871	Fastner
14	2182120	Scroll, Fan
15	2003928	Deflector, Air Duct
16	2215612	Cover, Air Duct
17	2209332	Assembly, Air Duct
18	2182146	Duct, Icemaker
19	2209480	Right
	2209066	Left
20	2209318	Harness, Wire
21		Liner (Not Serviceable Part)
22	1112869	Gasket, Air Baffle
23	2215718	Cover, Air Outlet
24	2198589	Light Shield
25	2208978	Cover, Evaporator
26	486194	Screw
27	487539	Screw
28	2215823	Clip, Air Duct (4)
29	1112852	Diffuser, Air Duct
30	1112260	Support, Evaporator
31	2196483	Stud, Shelf (20)
32	8281158	Screw
33		Evaporator, Cover Rail
	2208979	Left Side
	2208980	Right Side
34	2220904	Gasket (2) Evaporator Cover
35	2221077	Wire, Jumper
36	2171931	Release Valve
37	2209220	Tube, Meat Pan
38	941839	Hole Plug
39	2213442	Thermistor
40	2209204	Clip, Thermistor
41	1116793	Cover, Thermistor
42	488208	Screw 8-15 x 7/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	2215988	Refrigerator Door Panel (Includes Insulation)
3	2220922	Hinge Assembly, Top
4	2004520	Spacer-Door, Top
5	489282	Screw
6	2220809	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112541	Gasket Retainer, Top & Bottom
9	2188498	Door Gasket, Magnetic
11		Handle, Door
	2005953	White
	2005956	Black
	2005955	Biscuit
	2005952	Etched Aluminum
12	2001230	Washer
13	2004549	Door, Spacer Bottom
15		Screw
	8281251	White
	8281252	Black
	8281253	Biscuit
	8281250	Stainless Steel
16		Trim (Top)
	2005014	White
	2005840	Black
	2005757	Biscuit
	2005011	Etched Aluminum
18		Trim (Side)
	2005968	White
	2005971	Black
	2005970	Biscuit
	2005967	Etched Aluminum
19		Trim (Bottom)
	2209418W	White
	2209418B	Black
	2209418T	Biscuit
	2209418	Etched Aluminum
20	1113953	Panel, Interior Door
21	1113951	Ladder, Shelf (2)
22	1112530	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw
25	1112721	Bin, Utility
26	2003464	Door, Utility Bin
27	1113973	Door Shelf (3)
28	2165792	Butter Tray
32	2188332	Shelf, Gallon Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	2215976	Freezer Door Panel (Includes Insulation)
6	2220810	Hinge, Bottom
7	489282	Screw
8	2220922	Hinge, Top
9	2004520	Spacer-Door, Top
12	1112533	Gasket Retainer, Side (2)
13	1112540	Gasket Retainer, Top & Bottom
14	2188496	Door Gasket, Magnetic
15	486194	Screw (34)
16		Handle, Door
	2005943	White
	2005946	Black
	2005945	Biscuit
	2005942	Etched Aluminum
18	2004549	Door, Spacer
20		Screw
	8281251	White
	8281252	Black
	8281253	Biscuit
	8281250	Stainless Steel
21		Trim (Top)
	2005023	White
	2005886	Black
	2005760	Biscuit
	2005020	Etched Aluminum
23		Trim (Bottom)
	2209421W	White
	2209421B	Black
	2209421T	Biscuit
	2209421	Etched Aluminum
24		Trim (Side)
	2005963	White
	2005966	Black
	2005965	Biscuit
	2005962	Etched Aluminum
26	2209031	Panel, Interior Door
28	2188515	Shelf Bin
29		Trim, Endcap
	2208954	Left Side
	2209134	Right Side
34	2005610	Seal

UPPER UNIT PARTS


For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS


For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION
1	2196155	Defrost Bi-Metal
2	2209119	Wire Harness
3	486194	Screw
4	2215508	Bracket
5	2209067	Side Support
6	2209035	Suction Tube
8	2209454	Tube, Connect (Drier)
9	2209451	Heater, Drain Pan
10	2209450	Hanger, Heater
11	2005908	Shield, Drain Pan
12	2002448	Sleeve
13	2209036	Tube, Discharge
16	2209064	Evaporator
17	2006750	Heater, Defrost
18	1113048	Clamp, Heater (2)
20	2220832	Gasket, Evaporator
21	857547	Wire Tie
22	2215691	Clip, Heat Exchanger
23	851095	Strap
24	2209444	Grommet, Water Tube
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	Left
	1113207	Right
27	513942	Dampener
28	2215648	Damper, Heater

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
(Black) (Biscuit) (White) (Etched Aluminum)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSSS42FKB00, KSSS42FKT00, KSSS42FKW00, KSSS42FKX00
 (Black) (Biscuit) (White) (Etched Aluminum)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
3	2005038	Plug, Water Valve	16	488937	Clamp Tube	28	489322	Screw
4	841707	Insert, Tube	18	2174155	Cover	30	489276	Screw
5	628379	Clip, Fuse	20	628228	Mold & Heater	31	2171593	Shut Off Arm
6	2214613	Tube, Filter Inlet			(Also Order	33	2171952	Bracket
7	2208933	Water Inlet Tube Assembly			542638 Silicone Grease)	34	489478	Screw
8	1106508	Seal Gasket	21	628398	Motor	35	628399	Module Assembly (Includes Items 21 & 41)
9	2209430	Tube, Filter Outlet	22	628356	Cup-Water Fill	36	2185988	Fitting, Water Tube
10	2006766	Valve, Solenoid	23	2194711	Ejector	37	2004914	Water Valve Mounting Bracket
11	627018	Nut, Compression	24	2182124	Ice Striper	41	489136	Screw (2)
12	227991	Connector, Wire	25	2194712	Support	43	486194	Screw
13	2209072	Water Valve, Harness	26	627796	Retainer	44	1129179	Compression Nut
14	1129177	Insert, Tube	27	627985	Thermostat (Also Order	100	4317943	Complete Ice maker Assembly
15	2208136	Clamp, Nylon Valve			542639 Cement Alumilastic)			

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated (Optional Parts Only)		
	2220853	Front Panel Kit (White)
	2220856	Front Panel Kit (Black)
	2220862	Front Panel Kit (Stainless Steel)
	2220859	Front Panel Kit (Biscuit)

Black Acrylic
 Static Cleaner Part No. 978849