




|    |         |                                  |
|----|---------|----------------------------------|
| 1  |         | Cabinet (Not A Serviceable Part) |
| 2  | 1112019 | Leveler, Front (2)               |
| 3  | 1113249 | Retainer (2)                     |
| 4  | 1112023 | Roller, Front & Rear (4)         |
| 5  | 1112695 | Leveler, Adjustable (2)          |
| 6  | 2000670 | Adjusting Rod (2)                |
| 7  | 1113250 | Sleeve, Retainer (2)             |
| 8  | 1112937 | Bushing, Rod (2)                 |
| 9  | 489359  | Screw                            |
| 10 | 1112939 | Hole Plug, Leveler               |
| 11 | 1112849 | Cap, Grommet                     |
| 13 | 1113122 | Grommet, Wiring                  |
| 14 | 2002002 | Wiring Harness, Cabinet          |
| 15 | 1112848 | Drain Fitting                    |
| 16 |         | Gap, Cover Assembly (Top)        |
|    | 2000305 | Left Side                        |
|    | 2000304 | Right Side                       |
| 17 | 2001295 | Shoulder Screw                   |
| 18 |         | Hinge (Top)                      |
|    | 2000306 | Left Side                        |
|    | 2000307 | Right Side                       |
| 19 | 2000770 | Shim, Hinge Top                  |
| 20 | 1112805 | Guard, Wiring                    |
| 21 | 487534  | Screw (2)                        |
| 23 | 1112992 | Door Closer Assembly (2)         |
| 24 | 2000333 | Bracket, Door Closer             |
| 25 | 486194  | Screw                            |
| 26 | 1112973 | Tap Plate, Hinge Butt (2)        |
| 27 | 1113227 | Fastener (3)                     |
| 28 |         | Gap, Cover Assembly (Bottom)     |
|    | 2001200 | Left Side                        |
|    | 2001199 | Right Side                       |
| 29 |         | Hinge (Bottom)                   |
|    | 2001733 | Left Side                        |
|    | 2001732 | Right Side                       |
| 30 | 1112942 | Shim, Hinge (1)                  |
|    | 1112943 | Shim, Hinge (2) Bottom (4)       |
| 31 | 2000490 | Screw                            |
| 33 | 2001266 | Tube clamp                       |
| 34 | 2001963 | Grille Base, Front               |
| 35 | 489238  | Screw (6)                        |
| 36 | 2000684 | Cover, Rear                      |
| 37 | 1113123 | Grommet, Wiring                  |
| 38 | 1113079 | Grommet, Flexible                |
| 41 | 2001377 | Screw                            |
| 42 | 2000530 | Grommet                          |
| 43 | 2001415 | Screw (8)                        |
| 44 | 489359  | Screw                            |

CABINET TRIM PARTS


For Model: KSSS42MBX01



|   |         |                         |
|---|---------|-------------------------|
| 1 | 2000321 | Cabinet, Trim R.S       |
| 2 | 2000322 | Cabinet, Trim L.S       |
| 3 | 2001297 | Screw                   |
| 4 | 2001189 | Cabinet, Trim (Bottom)  |
| 5 | 488649  | Screw (8)               |
| 6 | 2001310 | Cabinet, Trim Top       |
| 7 | 2000007 | Retainer, Unit Base (2) |
| 8 | 487944  | Washer (2)              |

TOP GRILLE AND UNIT COVER PARTS


For Model: KSSS42MBX01



|   |         |                           |
|---|---------|---------------------------|
| 1 | 2002674 | Top Grille Assembly       |
| 2 | 2001316 | Decorative Panel Assembly |
| 3 | 1113355 | Back Up Panel             |
| 4 | 2001883 | Cover, Unit               |
| 5 | 486194  | Screw                     |
| 6 | 2001874 | Cover, Component Assembly |
| 7 | 1113317 | Brace                     |

# REFRIGERATOR LINER PARTS

For Model: KSSS42MBX01




|    |         |  |
|----|---------|--|
| 1  |         | LINER (Not A Serviceable Part)           |
| 2  | 1112591 | Spacer, Control Panel (3)                |
| 5  | 2001117 | Ladder, Shelf (2)                        |
| 6  | 520965  | Screw Support, Ladder (8)                |
| 7  | 488357  | Screw (8)                                |
| 8  | 486194  | Screw                                    |
| 9  | 1112257 | Hole Plug                                |
| 10 | 2000740 | Meat Pan, Air Duct Cover (Also Order 12) |
| 11 | 2000337 | Meat Pan, Air Duct                       |
| 12 | 2001302 | Inlay, Control Meat Pan                  |
| 13 | 2001326 | Seal, Air Duct                           |
| 14 | 1112218 | Damper Control, Meat Pan                 |
| 15 | 2001735 | Control Knob, Meat Pan                   |
| 16 | 837444  | Retainer, Knob                           |
| 17 | 2000343 | Air Baffle Assembly                      |
| 20 | 2001073 | Wiring Harness, Air Baffle               |
| 21 | 2001146 | Seal                                     |
| 22 | 1116793 | Cover, Thermistor                        |
| 23 | 1116959 | Thermistor                               |
| 25 | 2000736 | Air Baffle Cover                         |
| 26 | 2000527 | Guard, Air Return                        |



# FREEZER LINER PARTS


For Model: KSSS42MBX01



|    |         |                                |
|----|---------|--------------------------------|
| 1  |         | Liner (Not A Serviceable Part) |
| 2  | 1113649 | Bracket, Light                 |
| 3  | 1113650 | Light, Lens                    |
| 4  | 1112613 | Light, Socket                  |
| 5  | 547225  | Light Bulb                     |
| 6  | 538533  | Support Clip, Icemaker (2)     |
| 7  | 2000193 | Grommet, Screw (2)             |
| 8  | 488552  | Screw (2)                      |
| 9  | 487294  | Screw                          |
| 12 | 486194  | Screw                          |
| 13 | 1112591 | Spacer, Control Panel (3)      |
| 14 | 842534  | Clip, Air Duct (4)             |
| 16 | 1112260 | Support, Evaporator            |
| 17 | 658944  | Stud, Shelf (20)               |
| 18 | 487559  | Screw (20)                     |

# REFRIGERATOR CONTROL PANEL PARTS


For Model: KSSS42MBX01



|    |         |                       |
|----|---------|-----------------------|
| 1  | 1112641 | Control Panel         |
| 2  | 2000975 | Inlay, Control Panel  |
| 3  | 2000789 | Circuit Board         |
| 4  | 2001738 | Control Knob          |
| 5  | 837444  | Retainer, Knob        |
| 6  | 1108112 | Switch, Rocker Arm    |
| 7  | 1113135 | Seal, Control Panel   |
| 8  | 489260  | Screw (3)             |
| 9  | 2000153 | Hole Plug (3)         |
| 10 | 1113774 | Shield, Control Panel |
| 11 | 1112613 | Socket, Light (2)     |
| 12 | 547225  | Light Bulb (2)        |
| 13 | 486194  | Screw                 |
| 14 | 2001074 | Control Harness       |
| 15 | 2001141 | Channel, Wiring       |
| 16 | 1115375 | Clip, Wiring (2)      |

# REFRIGERATOR SHELF PARTS


For Model: KSSS42MBX01



|    |         |                                |
|----|---------|--------------------------------|
| 1  | 1113543 | Frame, Shelf                   |
| 2  | 1112318 | Glass, Shelf                   |
| 3  | 1113547 | Reflector, Shelf               |
| 4  | 1113791 | Gasket, Glass (2)              |
| 5  | 1125913 | Rack, Wine                     |
| 6  | 2002181 | Retainer, Glass                |
| 7  | 1113551 | Frame Assembly                 |
| 9  | 1113894 | Cover, Crisper                 |
| 10 | 2002147 | Glass, Crisper                 |
| 11 | 2164372 | Egg Bin                        |
| 12 | 2164373 | Egg Carrier                    |
| 13 | 2164374 | Cover                          |
| 14 | 2000888 | Crisper Pan                    |
| 15 | 1113870 | Roller                         |
| 16 | 1113871 | Eyelet, Roller                 |
| 17 | 489211  | Screw                          |
| 18 | 488307  | Washer                         |
| 19 | 2000892 | Utility Pan                    |
| 20 | 2000816 | Meat Pan                       |
| 21 | 2000742 | Meat Pan Connector             |
| 25 | 1112165 | Crisper Spacer, Right Side (2) |
| 27 | 1113169 | Stop, Roller                   |
| 28 | 2002180 | Crisper Spacer, Left Side (2)  |
| 29 | 486194  | Screw                          |

# REFRIGERATOR DOOR PARTS

For Model: KSSS42MBX01




|    |         |  |
|----|---------|--|
| 1  | 2000694 | Door Panel, Refrigerator (Also Order Item 29)                |
| 2  | 939101  | Screw Anchor (8)   |
| 3  | 2000696 | Hinge Assembly, Top  |
| 4  | 2000303 | Spacer, Top  |
| 5  | 489282  | Screw  |
| 6  | 2000698 | Hinge Assembly, Bottom                                       |
| 7  | 1112533 | Gasket Retainer, Side (2)                                    |
| 8  | 1112541 | Gasket Retainer, Top & Bottom                                |
| 9  | 2000880 | Door Gasket, Magnetic  |
| 10 | 489101  | Screw (36)   |
| 11 | 2000323 | Handle, Door   |
| 12 | 2002314 | Tap Plate  |
| 13 | 2000697 | Spacer, Bottom   |
| 15 | 487052  | Screw  |
| 16 | 2000316 | Trim (Top)   |
| 17 | 489112  | Screw  |
| 18 | 2000314 | Trim (Side)  |
| 19 | 2000319 | Trim (Bottom)  |
| 20 | 1113953 | Panel, Interior Door   |
| 21 | 1113951 | Ladder, Shelf (2)  |
| 22 | 1112530 | Retainer, Shelf Ladder (2)                                   |
| 23 | 1112514 | Back Up Plate (8)  |
| 24 | 486194  | Screw  |
| 25 | 1112721 | Bin, Utility   |
| 26 | 1112736 | Door, Utility Bin  |
| 27 | 2000912 | Door Shelf (4)   |
| 28 | 1125936 | Butter Tray  |
| 29 | 876029  | Kit, Foam Slab (Required When Replacing Exterior Door Panel) |



# FREEZER DOOR PARTS


For Model: KSSS42MBX01



|    |         |   |
|----|---------|---|
| 1  | 2000715 | Exterior Door Panel, Freezer (Also Order Item 11)       |
| 4  | 2002314 | Tap Plate   |
| 6  | 2000720 | Hinge, Bottom   |
| 7  | 489282  | Screw   |
| 8  | 2000721 | Hinge, Top  |
| 9  | 2000303 | Spacer Plate  |
| 10 | 2000697 | Spacer, Bottom  |
| 11 | 876029  | Foam Insulation (Required When Replacing Exterior Door) |
| 12 | 1112533 | Gasket Retainer, Side (2)                               |
| 13 | 1112540 | Gasket Retainer, Top & Bottom                           |
| 14 | 2000879 | Door Gasket, Magnetic                                   |
| 15 | 489101  | Screw (34)  |
| 16 | 2000324 | Handle, Door  |
| 20 | 487052  | Screw   |
| 21 | 2000327 | Trim (Top)  |
| 22 | 489112  | Screw   |
| 23 | 2000330 | Trim (Bottom)   |
| 24 | 2000325 | Trim (Side)   |
| 26 | 2000178 | Panel, Interior Door                                    |
| 28 | 2000605 | Door Shelf, (4)   |
| 32 | 227991  | Wire Connector  |
| 33 | 939101  | Screw Anchor  |

# UPPER UNIT PARTS

For Model: KSSS42MBX01



|    |         |   |
|----|---------|---|
| 1  | 2001929 | Assembly, Unit Base   |
| 2  | 2163787 | Clip, Compressor Mounting (4)                                 |
| 3  | 2154558 | Compressor (Includes Items 7, 8, 9, 10, 11 & 12) (Also Order) |
|    | 876765  | Tube Kit  |
| 4  | 680975  | Washer  |
| 6  | 2163786 | Grommet, Mounting   |
| 7  | 1127675 | Wire Assembly   |
| 8  | 2154761 | Overload (Includes Relay)                                     |
| 9  | 1108115 | Terminal Cover  |
| 10 | 938384  | Strap, Cover  |
| 11 |         | Relay (See Overload)  |
| 12 |         | Capacitor   |
|    | 2169137 | Production  |
|    | 2154565 | Service   |
| 14 | 486899  | Screw   |
| 15 | 487869  | Screw   |
| 16 | 1113015 | Condenser   |
| 17 | 943447  | Grommet (4)   |
| 18 | 1113019 | Clamp (4)   |
| 19 | 487522  | Screw   |
| 20 | 1113228 | Wire Tie (2)  |
| 21 | 1108023 | Drier   |
| 22 | 2000358 | Mounting Bracket, Motor                                       |
| 23 | 2002409 | Motor, Fan  |
| 24 | 2000352 | Blade, Fan  |
| 25 | 2000351 | Orifice, Fan  |
| 26 | 1113303 | Gasket, Orifice   |
| 27 | 489399  | Screw (3)   |
| 28 | 489368  | Screw   |
| 29 | 486692  | Speed Nut   |
| 30 | 2162044 | Defrost Timer   |
| 31 | 488911  | Screw   |
| 32 | 2000645 | Sleeve, Condenser   |
| 33 | 1113066 | Clamp, Tube (2)   |
| 34 | 1113059 | Process, Tube   |
| 35 | 486194  | Screw   |
| 36 | 2000853 | Cover, Fan  |
| 37 | 2001878 | Cover, Condenser  |
| 38 | 1113076 | Extension, Housing  |
| 39 | 937360  | Service Cord  |
| 40 | 2001503 | Seal Strip (2)  |
| 41 | 1113162 | Clamp, Cord (2)   |
| 42 | 1113229 | Switch, Power Disconnect                                      |
| 43 | 488879  | Screw, Ground   |
| 44 | 653035  | Clip, Cord Plug   |
| 45 | 2001078 | Wiring Harness, Unit Compartment                              |
| 47 | 2001079 | Gasket (2)  |

Following Parts Not Illustrated and Optional Parts Not Included


|        |                       |
|--------|-----------------------|
| 978025 | Valve, Access (1/4")  |
| 978026 | Valve, Access (5/16") |
| 978027 | Valve, Access (3/8")  |
| 978028 | Valve, Access (1/2")  |
| 978029 | Valve, Access (5/8")  |
| 978030 | Valve, Access (3/4")  |
| 876764 | Valve, Access (3/16") |

REFRIGERANT CHARGE 9.5 oz.

Production Compressor Requires Production Electrical Components. Service Compressor Requires Service Electrical Components. For Further Information, Refer to Filmcard 19.1.

# LOWER UNIT AND TUBE PARTS


For Model: KSSS42MBX01



|    |         |                       |
|----|---------|-----------------------|
| 1  | 2000528 | Defrost Bi-Metal      |
| 2  | 1113043 | Clamp, Bi-Metal       |
| 3  | 486194  | Screw                 |
| 4  | 2002186 | Sleeve                |
| 5  | 2002171 | Sleeve                |
| 6  | 2002184 | Condenser Inlet Tube  |
| 8  | 2002408 | Tube, Connect (Drier) |
| 9  | 2000755 | Heater, Drain Pan     |
| 10 | 1113062 | Hanger, Heater        |
| 11 | 1113105 | Bracket, Heater       |
| 12 | 487534  | Screw                 |
| 13 | 2002381 | Tube, Discharge       |
| 14 | 2002187 | Sleeve                |
| 15 | 2001814 | Heat Exchanger        |
| 16 | 2001132 | Evaporator            |
| 17 | 2000631 | Heater, Defrost       |
| 18 | 1113048 | Clamp, Heater (2)     |
| 19 | 1108431 | Clamp, Heater (2)     |
| 20 | 1112844 | Gasket, Evaporator    |
| 21 | 857547  | Wire Tie              |
| 23 | 851095  | Strap (7)             |
| 24 | 488946  | Clamp, Wiring         |
| 25 | 2001264 | Drain Pan             |
| 26 |         | Bracket, Drain Pan    |
|    | 1113206 | (L.H.)                |
|    | 1113207 | (R.H.)                |
| 27 | 513942  | Dampener              |

# AIR FLOW AND RESERVOIR PARTS

For Model: KSSS42MBX01






|    |         |                             |
|----|---------|-----------------------------|
| 1  | 2001086 | Fan Motor                   |
| 3  | 2169142 | Fan Blade                   |
| 4  | 548263  | Bracket (Double)            |
| 5  | 938224  | Bracket (Single)            |
| 6  | 548268  | Grommet                     |
| 7  | 486194  | Screw                       |
| 8  | 2000618 | Motor, Wiring               |
| 9  | 488500  | Screw, Ground               |
| 11 | 488366  | Clamp, Tube                 |
|    | 489348  | Clamp, Nylon                |
| 12 | 2001257 | Channel, Wiring             |
| 14 | 2000783 | Scroll, Fan                 |
| 16 | 488772  | Screw                       |
| 17 | 2000748 | Assembly, Air Duct          |
| 18 | 2000048 | Air Deflector, Ice maker    |
| 22 | 1112869 | Gasket, Air Baffle          |
| 23 | 1113942 | Cover, Air Outlet           |
| 25 | 2000341 | Cover, Evaporator           |
| 26 | 2000795 | Connector, Meat Pan Duct    |
| 27 | 487539  | Screw                       |
| 28 | 1112840 | Baffle, Evaporator          |
| 29 | 1112852 | Diffuser, Air Duct          |
| 42 |         | Evaporator, Cover Rail      |
|    | 2000686 | Left Side                   |
|    | 2000685 | Right Side                  |
| 45 | 2001337 | Gasket (2) Evaporator Cover |
| 46 | 2001079 | Gasket (2)                  |
| 47 | 2001080 | Gasket                      |
| 48 | 2001081 | Gasket                      |

# ICEMAKER PARTS

For Model: KSSS42MBX01



|     |         |   |
|-----|---------|---|
| 1   | 489084  | Screw                                       |
| 2   | 2000829 | Fitting, Water Tube                         |
| 3   | 2001087 | Clamp, Tube                                 |
| 4   | 841707  | Insert, Tube                                |
| 5   | 628379  | Clip, Fuse                                  |
| 6   | 2000392 | Wire Clip                                   |
| 7   | 2001260 | Tube, Water (To Ice Maker)                  |
| 8   | 1106508 | Seal Gasket                                 |
| 9   | 487627  | Sleeve, Nut                                 |
| 10  | 2001318 | Valve, Solenoid                             |
| 11  | 627018  | Nut, Compression                            |
| 12  | 227991  | Connector, Wire                             |
| 13  | 2000837 | Water Valve, Harness                        |
| 14  | 2001354 | Copper, Water Line                          |
| 15  | 489348  | Clamp, Nylon Valve                          |
| 16  | 1113066 | Clamp Tube                                  |
| 17  | 487857  | Nut   |
| 18  | 1113703 | Cover                                       |
| 19  | 488645  | Screw                                       |
| 20  | 628228  | Mold & Heater (Also Order)                  |
|     | 542638  | Silicone Grease                             |
| 21  | 628258  | Motor                                       |
| 22  | 628356  | Cup-Water Fill                              |
| 23  | 627843  | Ejector                                     |
| 24  | 627788  | Ice Striper                                 |
| 25  | 627790  | Support                                     |
| 26  | 627796  | Retainer Thermostat (2)                     |
| 27  | 627985  | Thermostat (Also Order)                     |
|     | 542639  | Cement Alumilastic                          |
| 28  | 489322  | Screw                                       |
| 29  | 628357  | Module Assembly                             |
| 30  | 489276  | Screw                                       |
| 31  | 627792  | Shut Off Arm                                |
| 32  | 2002006 | Harness, Wiring                             |
| 33  | 627915  | Bracket                                     |
| 34  | 489242  | Screw                                       |
| 35  | 628366  | Module Assembly (Includes Items 21, 29, 41) |
| 36  | 2001098 | Water Inlet Tube                            |
| 37  | 2000803 | Water Valve Mounting Bracket                |
| 41  | 489136  | Screw (2)                                   |
| 43  | 486194  | Screw                                       |
| 100 | 4317943 | Icemaker                                    |

Following Parts Not Illustrated (Optional Parts Only)


|         |                                   |
|---------|-----------------------------------|
| 4318636 | Front Panel Kit (White)           |
| 4318633 | Front Panel Kit (Black)           |
| 4318639 | Front Panel Kit (Almond)          |
| 4318642 | Front Panel Kit (Stainless Steel) |
| 978849  | Black Acrylic Static Cleaner      |

LITERATURE PARTS

|            |                                |
|------------|--------------------------------|
| LIT2002424 | Use & Care Guide               |
| LIT2002436 | Energy Label                   |
| LIT2002160 | Service & Wiring Sheet         |
| LIT628370  | Modular Icemaker Service Sheet |
| LIT2002469 | Installation Instructions      |

# FREEZER CONTROL PANEL PARTS


For Model: KSSS42MBX01



|    |         |                               |
|----|---------|-------------------------------|
| 1  | 1113626 | Control Panel                 |
| 2  | 1113964 | Inlay, Control Panel          |
| 3  | 1113466 | Thermostat & Barrier Assembly |
| 4  | 488974  | Screw (2)                     |
| 6  | 1113134 | Seal, Control Panel           |
| 8  | 489260  | Screw (3)                     |
| 9  | 2000153 | Hole Plug (3)                 |
| 10 | 1113768 | Shield, Control Panel         |
| 11 | 1112613 | Socket, Light                 |
| 12 | 486194  | Screw                         |
| 13 | 547225  | Light Bulb                    |
| 14 | 1112707 | Channel, Wiring               |
| 15 | 1108112 | Switch, Rocker Arm (Light)    |
| 16 | 2001737 | Knob, Thermostat              |
| 17 | 1115375 | Clip, Wiring                  |

# FREEZER SHELF PARTS

For Model: KSSS42MBX01



|    |         |                           |
|----|---------|---------------------------|
| 1  | 1113629 | Solid Shelf               |
| 3  | 1113634 | Shelf, (Top)              |
| 4  | 2001625 | Basket                    |
| 5  | 1113643 | Trim, Basket              |
| 6  | 1122529 | Ice Cube Pan (Includes 7) |
| 7  | 1122530 | Trim, Ice Pan             |
| 8  | 1113565 | Shelf, (Middle)           |
| 9  | 1113637 | Shelf, Bottom (2)         |
| 15 | 1113870 | Roller                    |
| 16 | 1113871 | Eyelet, Roller            |
| 17 | 489211  | Screw                     |
| 18 | 488307  | Washer                    |
| 22 | 2000061 | Slide, Basket R.S.        |
|    | 2000062 | Slide, Basket L.S.        |
| 24 | 1113169 | Stop, Roller              |
| 25 | 486194  | Screw                     |