

# PARTS LIST

for

# KitchenAid®

## REFRIGERATOR

### MODEL KSSS48DAW00

SS-Stainless Steel



FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



KITCHENAID

ST. JOSEPH MICHIGAN 49085

12-92Litho In U.S.A.


© 1992 KITCHENAID

Part No. 4361435

12-92

# CABINET PARTS


For Model: KSSS48DAW00



1		Cabinet (Not A Serviceable Part)
2	1112019	Leveler, Front (2)
3	1113249	Retainer (2)
4	1112023	Roller, Front & Rear (4)
5	1112695	Leveler, Adjustable (2)
6	2000670	Adjusting Rod (2)
7	1113250	Sleeve, Retainer (2)
8	1112937	Bushing, Rod (2)
9	489359	Screw
10	1112939	Hole Plug, Leveler
11	1112849	Cap, Grommet
12	1112970	Grommet, Water Tube
13	1113122	Grommet, Wiring
14	2000832	Wiring Harness, Cabinet
15	1112848	Drain Fitting
16		Gap, Cover Assembly (Top)
	2000305	Left Side
	2000304	Right Side
17	2001295	Shoulder Screw
18		Hinge (Top)
	2000306	Left Side
	2000307	Right Side
19	2000770	Shim, Hinge Top
20	1112805	Guard, Wiring
21	487534	Screw (2)
23	1112992	Door Closer Assembly (2)
24	2000333	Bracket, Door Closer
25	486194	Screw, 8 x 1/2
26	1112973	Tap Plate, Hinge Butt (2)
27	1113227	Fastener (3)
28		Gap, Cover Assembly (Bottom)
	2001200	Left Side
	2001199	Right Side
29		Hinge (Bottom)
	2000308	Left Side
	2000309	Right Side
30	1112942	Shim, Hinge (1)
	1112943	Shim, Hinge (2) Bottom (4)
31	2000490	Screw, 1/4-28 x 3/4
32	2000854	Spacer, Lower Door Hinge
33	2001266	Tube clamp
34	1112139	Grille Base, Front
35	489238	Screw (6)
36	2000684	Cover, Rear
37	1113123	Grommet, Wiring
38	1113079	Grommet, Flexible
39	1112926	Grommet, Tube
40	1113078	Grommet (2)
41	2001377	Screw
42	2000530	Grommet
43	2000671	Screw (4)
44	489359	Screw

# CABINET TRIMS AND BREAKER TRIM PARTS


For Model: KSSS48DAW00



1	2000652	Breaker Trim & Retainer Assembly
5	1112682	Magnet, Side (4)
6	1112679	Magnet, Freezer (2)
7	1112681	Magnet, Refrigerator (2)
9	2000321	Cabinet, Trim R.S
10	2000322	Cabinet, Trim L.S
11	2001297	Screw
12	1112802	Cabinet, Trim (Bottom)
13	488649	Screw, 8-32 x 1/2 (8)
14	2000782	Cabinet, Trim Top
15	2000007	Retainer, Unit Base (2)
16	487944	Washer (2)

# REFRIGERATOR LINER PARTS


For Model: KSSS48DAW00



1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
3	843436	Grommet, Screw (3)
4	842339	Grommet
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw, 8 x 1-1/4 (8)
8	486194	Screw, 8 x 1/2
9	1112257	Hole Plug
10	2000740	Meat Pan, Air Duct Cover (Also Order 12)
11	2000337	Meat Pan, Air Duct
12	2001302	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	1112258	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	2000343	Air Baffle Assembly
20	2001073	Wiring Harness, Air Baffle
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2000736	Air Baffle Cover
26	2000527	Guard, Air Return

# FREEZER LINER PARTS

For Model: KSSS48DAW00






1		Liner (Not A Serviceable Part)
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw, 10-12 x 3/8 (2)
9	992720	Stud, Support (4)
12	486194	Screw, 8 x 1/2
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
15	842339	Grommet (15)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (8)
18	487559	Screw, 8-15 x 1-1/4 (8)

# ICE CONTAINER PARTS

For Model: KSSS48DAW00




1		Spacer, Track
	1112282	Left Side
	1112281	Right Side
2	1113870	Roller
3	1113871	Eyelet, Roller
5	1113169	Stop, Roller
6	488307	Washer
7	486194	Screw, 8 x 1/2
8	1113127	Bracket, Motor
9	1113960	Motor Assembly
10	488906	Screw, 8-32 x 5/16
11	983663	Coupling, Motor
12	1112613	Socket, Light
13	1113130	Cover, Motor
14	487294	Screw, 8-32 x 3/8
15	1112287	Ice Container
16	1112378	Conveyor
17	983668	Coupling, Conveyor
18	946192	Drive Bar, Drum
19	946195	Bearing Nut
20	946193	Drum
21	946194	Baffle
22	2001034	Overlay, Cover
23	1112382	Front Cover
24	488886	Screw, 8-18 x 1/2 (5)
25	489211	Screw, 10-16 x 3/4
28	1113140	Lens, Dispenser
29	547225	Light Bulb



1	1112004	Frame, Shelf
2	1113956	Glass, Shelf
3	1112006	Reflector, Shelf
4	1113792	Gasket, Glass (2)
5	1125913	Rack, Wine
6	1112324	Retainer Glass
7	1112014	Frame Assembly
9	1112247	Cover, Crisper
10	1113238	Glass, Crisper
11	2000742	Meat, Pan Connector
14	2000554	Crisper Pan
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
18	488307	Washer
19	2000557	Utility Pan
20	2000817	Meat Pan
25	1112165	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	1113890	Crisper Spacer, Left Side (2)
29	486194	Screw, 8 x 1/2


# FREEZER SHELF PARTS



1	1112367	Solid Shelf
2	2000529	Front, Ice Compartment
3	1112052	Shelf, Fixed (Large)
14	1113644	Trim, Basket
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
18	488307	Washer
19	1113641	Basket
22	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
24	1113169	Stop, Roller
25	486194	Screw, 8 x 1/2

# REFRIGERATOR DOOR PARTS


For Model: KSSS48DAW00





1	2000296	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	2000696	Hinge Assembly, Top
4	2000303	Spacer
5	489282	Screw
6	2000698	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112542	Gasket Retainer, Top & Bottom
9	2001049	Door Gasket, Magnetic
10	489101	Screw, 7 x 1/2 (36)
11	2000323	Handle, Door
12	2000349	Tap, Plate
13	2000697	Door, Spacer Bottom
15	487052	Screw
16	2000317	Trim (Top)
17	489112	Screw
18	2000314	Trim (Side)
19	2000320	Trim (Bottom)
20	1113950	Panel, Interior Door
21	1113949	Ladder, Shelf (2)
22	1113948	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw, 8 x 1/2
25	1113955	Gasket, Utility Door
26	1112737	Door, Utility Bin
27	2000622	Door Shelf (4)
28	1125936	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)


# REFRIGERATOR CONTROL PANEL PARTS



1	1112642	Control Panel
2	2000976	Inlay, Control Panel
3	2000789	Circuit Board
4	1116853	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113137	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113775	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw, 8 x 1/2
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)
17	2001074	Control, Harness


# FREEZER DOOR PARTS

For Model: KSSS48DAW00



1	2001138	Exterior Door Panel, Freezer (Includes Insulation)
2	1112997	Tube, Wiring
3	1112928	Retainer, Tube
6	2000720	Hinge, Bottom
7	489282	Screw
8	2000721	Hinge, Top
9	2000303	Door Spacer
11	2001323	Wiring Harness, Freezer Door
12	1112533	Gasket Retainer, Side (2)
13	1112539	Gasket Retainer, Top & Bottom
14	2000878	Door Gasket, Magnetic
15	489101	Screw, 7 x 1/2 (34)
16	2000324	Handle, Door
17	2000349	Tap, Plate
18	2000697	Door, Spacer
20	487052	Screw
21	2000328	Trim (Top)
22	489112	Screw
23	2000331	Trim (Bottom)
24	2000325	Trim (Side)
26	1113947	Panel, Interior Door
28	2000606	Door Shelf, Trim Assembly
32	227991	Wire Connector
33	939101	Screw Anchor
34	2000798	Ice Chute


# FREEZER CONTROL PANEL PARTS



1	1112597	Control Panel
2	1113959	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	851387	Switch, Rocker Arm (Dispenser Motor)
6	1113136	Seal, Control Panel
8	489260	Screw (3)
10	1113769	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw, 8 x 1/2
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	1112592	Knob, Thermostat
17	1115375	Clip, Wiring
18	1105570	Thermostat Barrier

# DISPENSER AND FRONT PARTS

For Model: KSSS48DAW00






1	1107943	Housing, Dispenser
2	987049	Bracket, Water Fitting
3	2155037	Water Fitting, Dispenser
4	487916	Screw, 8 x 3/8
5	987053	Water Tube
6	841707	Insert, Tube
8	488886	Screw, 8-18 x 1/2
9	488316	Screw, 8-18 x 3/4
10	987048	Grommet
11	2001334	Heater, Ice Dispenser
12	2147167	Ice Door Mechanism
13	2147168	Door, Ice
14	1129333	Shroud
16	489000	Screw, 9-12 x 1/2
17	1127421	Lever, Ice Dispenser
19	987917	Bearing, Clip
20	1115349	Lever, Water Dispenser
21	488307	Washer
22	983696	Spring, Lever
23	983697	Bearing, Lever
24	1120581	Delay Mechanism
25	1107454	Bracket, Control
26	841336	Switch
27	984683	Insulation, Switch
28	488361	Screw, 4-40 x 1
29	987265	Lamp Holder
30	488500	Screw, 8-32 x 3/8
31	851386	Light Switch
32	1107457	Plunger, Extension
33	983986	Spring, Plunger
34	983987	Retainer, Pin
35	2001350	Wiring Harness, Door
36	984494	Wiring Shield
37	1118269	Guiding, Ice
38	1119056	Glass Stop
39	489197	Screw
40	487052	Screw
41	851389	Light Bulb
42	1112353	Front Cover, Housing (Includes Item 49)
44	1112836	Cover, Dispenser Opening
45	2000069	Trim, Front (2)
46	487052	Screw, 8-15 x 1/2
47	1126120	Grille, Overflow
48	934316	Switch
49	1113383	Overlay, Cover
50	489098	Union
51	487857	Nut-Ball Sleeve
52	488794	"O" Ring Seal
53	487944	Washer (2)
54	488568	Screw (2)
55	482672	Seal

# UPPER UNIT PARTS

For Model: KSSS48DAW00




1	2001123	Assembly, Unit Base
2	1113386	Assembly, Sound Barrier
3	4318071	Compressor (Includes Items 8, 9, 10, 11, 13) (Also Order 876765 Tube Kit)
4	1105220	Bracket, Mounting
5	1105219	Grommet, Bracket
6	1105200	Grommet, Mounting
7	489334	Screw
8	2154948	Overload
9	2154452	Terminal Cover
10	1105222	Strap, Cover
11	1118797	Relay
12	2149684	Running Capacitor
13	2154949	Starting Capacitor
14	1108033	Clamp
15	487869	Screw, 8 x 3/8
16	1113015	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw, 8-32 x 5/8 (4)
20	1113228	Wire Tie (2)
21	1108023	Drier
22	2000358	Mounting Bracket, Motor
23	1113081	Motor, Fan
24	2000352	Blade, Fan
25	2000351	Orifice, Fan
26	1113303	Gasket, Orifice
27	488130	Nut (3)
28	489368	Screw, 8 x 1/2 (3)
29	486692	Speed Nut
30	2162044	Defrost Timer
31	488911	Screw, 6-20 x 3/8
32	2000645	Sleeve, Condenser
33	1113066	Clamp, Tube (2)
34	1113059	Process, Tube
35	486194	Screw, 8 x 1/2
36	2000853	Cover, Fan
37	1113028	Cover, Condenser
38	1113076	Extension, Housing
39	937360	Service Cord
40	2001503	Seal Strip (2)
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	2001078	Wiring Harness, Unit Compartment
47	2001079	Gasket (2)

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

# LOWER UNIT AND TUBE PARTS


For Model: KSSS48DAW00



1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw, 8 x 1/2
4	1113293	Tube, Connect (Suction)
5	1113209	Tube, Connect (Discharge)
6	1113296	Tube, Flow Divider (2)
7	1113292	Valve, Fluid Control
8	1113294	Tube, Connect (Drier)
9	2000756	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw, 8 x 1
13	2000857	Tube, Discharge
14	2000860	Sleeve
15	2000724	Heat Exchanger
16	2001133	Evaporator
17	2000563	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	549419	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
22	1113070	Guard, Hook-Up
23	851095	Strap (7)
24	488946	Clamp, Wiring
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	(L.H.)
	1113207	(R.H.)
27	513942	Dampener
28	934011	Clip, Water Tube
30	1113384	Tube, Connect (Suction)
31	1113297	Tube (2)
32	1113096	Tube, Condenser Inlet

# AIR FLOW AND RESERVOIR PARTS


For Model: KSSS48DAW00



1	2001086	Fan Motor
3	2154800	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw, 8 x 1/2
8	2000618	Motor, Wiring
10	1129179	Nut
11	488366	Clamp, Tube
	489348	Clamp, Nylon
12	2000113	Channel, Wiring
13	2150347	Union
14	2000783	Scroll, Fan
16	488772	Screw, 8 x 1/2
17	2000746	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
19	1112870	Cup, Motor
21	1112871	Fastener (3)
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
25	2000342	Cover, Evaporator
26	2000796	Connector, Meat Pan Duct
27	487539	Screw, 8 x 1/2
28	1112840	Baffle, Evaporator
29	1112853	Diffuser, Air Duct
30	1129170	Reservoir, Water
31	2001152	Water Tube (Inlet)
32	841707	Insert, Tube
33	488819	"O" Ring Seal
34	488795	Compression Nut
40	488775	Screw
42		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
43	2001322	Water Tube (Outlet)
45	2001337	Gasket (2) Evaporator Cover
46	2001079	Gasket (2)
47	2001080	Gasket
48	2001081	Gasket

# ICEMAKER PARTS

For Model: KSSS48DAW00





1	489084	Screw, 8 x 1/2
2	2000829	Fitting, Water Tube
3	2001087	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
6	2000392	Wire Clip
7	2001336	Tube, Water (To Ice Maker)
8	1106508	Seal Gasket
9	487627	Sleeve, Nut
10	2155062	Valve, Solenoid
11	627018	Nut, Compression
12	227991	Connector, Wire
13	2000836	Water Valve, Harness
14	2001353	Copper, Water Line
15	489348	Clamp, Nylon Valve
16	1113066	Clamp Tube
17	487857	Nut
18	628355	Cover
20	628228	Mold & Heater (Also Order 542638 Silicone Grease)
21	628258	Motor
22	628356	Cup-Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer Thermostat (2)
27	627985	Thermostat (Also Order 542639 Cement Alumilastic)
28	489322	Screw, 10-32 x 49/64
29	628357	Module Assembly
30	489276	Screw
31	627913	Shut Off Arm
32	1113403	Harness, Wiring
33	627915	Bracket
34	489365	Screw, 8-32 x 27/64
35	628366	Module Assembly (Includes Items 21, 29, 41)
36	2001098	Water Inlet Tube
37	2000803	Water Valve Mounting Bracket
41	489136	Screw, (2) 3-24 x 3/8
43	486194	Screw, 8 x 1/2
44	1129179	Compression Nut
45	1129177	Insert, Tube
46	2001152	Water, Tube (From Water Reservoir)
100	4317943	Icemaker

Following Parts Not Illustrated (Optional Parts Only)

4210545	Top Grille Trim Kit (8")
4210546	Top Grille Trim Kit (7-1/2")
4210464	Front Panel Kit (White)
4210469	Front Panel Kit (Black)
4211168	Front Panel Kit (Almond)
4210593	Stainless Steel

Black Acrylic Static Cleaner  
978849


LITERATURE PARTS

LIT2001362	Use & Care Guide
LIT2000868	Energy Label

LIT2000850 Service & Wiring Sheet  
LIT628370 Modular Icemaker Service Sheet  
LIT2001094 Installation Instructions  
LIT4361435 Parts List

# TOP GRILLE AND UNIT COVER PARTS

For Model: KSSS48DAW00



2	2001055	Decorative Panel Assembly
3	1113356	Back Up Panel
9	2000846	Top Grille Assembly
10	2001088	Cover, Unit
11	486194	Screw, 8 x 1/2
12	1113300	Cover, Component Assembly