


**KitchenAid®**

# CABINET PARTS

For Model: KSSS48DBX00

REFRIGERATOR




10/24

|    |         |                                  |
|----|---------|----------------------------------|
| 1  |         | Cabinet (Not A Serviceable Part) |
| 2  | 1112019 | Leveler, Front (2)               |
| 3  | 1113249 | Retainer (2)                     |
| 4  | 1112023 | Roller, Front & Rear (4)         |
| 5  | 1112695 | Leveler, Adjustable (2)          |
| 6  | 2000670 | Adjusting Rod (2)                |
| 7  | 1113250 | Sleeve, Retainer (2)             |
| 8  | 1112937 | Bushing, Rod (2)                 |
| 9  | 489359  | Screw                            |
| 10 | 1112939 | Hole Plug, Leveler               |
| 11 | 1112849 | Cap, Grommet                     |
| 12 | 1112970 | Grommet, Water Tube              |
| 13 | 1113122 | Grommet, Wiring                  |
| 14 | 2002000 | Wiring Harness, Cabinet          |
| 15 | 1112848 | Drain Fitting                    |
| 16 |         | Gap, Cover Assembly (Top)        |
|    | 2000305 | Left Side                        |
|    | 2000304 | Right Side                       |
| 17 | 2001295 | Shoulder Screw                   |
| 18 |         | Hinge (Top)                      |
|    | 2000306 | Left Side                        |
|    | 2000307 | Right Side                       |
| 19 | 2000770 | Shim, Hinge Top                  |
| 20 | 1112805 | Guard, Wiring                    |
| 21 | 487534  | Screw (2)                        |
| 23 | 1112992 | Door Closer Assembly (2)         |
| 24 | 2000333 | Bracket, Door Closer             |
| 25 | 486194  | Screw                            |
| 26 | 1112973 | Tap Plate, Hinge Butt (2)        |
| 27 | 1113227 | Fastener (3)                     |
| 28 |         | Gap, Cover Assembly (Bottom)     |
|    | 2001200 | Left Side                        |
|    | 2001199 | Right Side                       |
| 29 |         | Hinge (Bottom)                   |
|    | 2001733 | Left Side                        |
|    | 2001732 | Right Side                       |
| 30 | 1112942 | Shim, Hinge (1)                  |
|    | 1112943 | Shim, Hinge (2) Bottom (4)       |
| 31 | 2000490 | Screw                            |
| 33 | 2001266 | Tube clamp                       |
| 34 | 2001964 | Grille Base, Front               |
| 35 | 489238  | Screw (6)                        |
| 36 | 2000684 | Cover, Rear                      |
| 37 | 1113123 | Grommet, Wiring                  |
| 38 | 1113079 | Grommet, Flexible                |
| 39 | 1112926 | Grommet, Tube                    |
| 41 | 2001377 | Screw                            |
| 42 | 2000530 | Grommet                          |
| 43 | 2001415 | Screw (4)                        |
| 44 | 489359  | Screw                            |

# CABINET TRIM PARTS


For Model: KSSS48DBX00



|   |         |                         |
|---|---------|-------------------------|
| 1 | 2000321 | Cabinet, Trim R.S       |
| 2 | 2000322 | Cabinet, Trim L.S       |
| 3 | 2001297 | Screw                   |
| 4 | 2001190 | Cabinet, Trim (Bottom)  |
| 5 | 488649  | Screw                   |
| 6 | 2001311 | Cabinet, Trim Top       |
| 7 | 2000007 | Retainer, Unit Base (2) |
| 8 | 487944  | Washer (2)              |

# REFRIGERATOR LINER PARTS


For Model: KSSS48DBX00



|    |         |                                          |
|----|---------|------------------------------------------|
| 1  |         | LINER (Not A Serviceable Part)           |
| 2  | 1112591 | Spacer, Control Panel (3)                |
| 5  | 2001117 | Ladder, Shelf (2)                        |
| 6  | 520965  | Screw Support, Ladder (8)                |
| 7  | 488357  | Screw                                    |
| 8  | 486194  | Screw                                    |
| 9  | 1112257 | Hole Plug                                |
| 10 | 2000740 | Meat Pan, Air Duct Cover (Also Order 12) |
| 11 | 2000337 | Meat Pan, Air Duct                       |
| 12 | 2001302 | Inlay, Control Meat Pan                  |
| 13 | 2001326 | Seal, Air Duct                           |
| 14 | 1112218 | Damper Control, Meat Pan                 |
| 15 | 2001735 | Control Knob, Meat Pan                   |
| 16 | 837444  | Retainer, Knob                           |
| 17 | 2000343 | Air Baffle Assembly                      |
| 20 | 2001073 | Wiring Harness, Air Baffle               |
| 21 | 2001146 | Seal                                     |
| 22 | 1116793 | Cover, Thermistor                        |
| 23 | 1116959 | Thermistor                               |
| 25 | 2000736 | Air Baffle Cover                         |
| 26 | 2000527 | Guard, Air Return                        |

# FREEZER LINER PARTS


For Model: KSSS48DBX00



|    |         |                                |
|----|---------|--------------------------------|
| 1  |         | Liner (Not A Serviceable Part) |
| 6  | 538533  | Support Clip, Icemaker (2)     |
| 7  | 2000193 | Grommet, Screw (2)             |
| 8  | 488552  | Screw                          |
| 9  | 992720  | Stud, Support (4)              |
| 12 | 486194  | Screw                          |
| 13 | 1112591 | Spacer, Control Panel (3)      |
| 14 | 842534  | Clip, Air Duct (4)             |
| 16 | 1112260 | Support, Evaporator            |
| 17 | 658944  | Stud, Shelf (8)                |
| 18 | 487559  | Screw                          |

# ICE CONTAINER PARTS


For Model: KSSS48DBX00



|    |         |                    |
|----|---------|--------------------|
| 1  |         | Spacer, Track      |
|    | 1112282 | Left Side          |
|    | 1112281 | Right Side         |
| 2  | 1113870 | Roller             |
| 3  | 1113871 | Eyelet, Roller     |
| 5  | 1113169 | Stop, Roller       |
| 6  | 488307  | Washer             |
| 7  | 486194  | Screw              |
| 8  | 1113127 | Bracket, Motor     |
| 9  | 2155262 | Motor Assembly     |
| 10 | 489399  | Screw              |
| 11 | 983663  | Coupling, Motor    |
| 12 | 1112613 | Socket, Light      |
| 13 | 1113130 | Cover, Motor       |
| 14 | 487294  | Screw              |
| 15 | 1112287 | Ice Container      |
| 16 | 1112378 | Conveyor           |
| 17 | 983668  | Coupling, Conveyor |
| 18 | 946192  | Drive Bar, Drum    |
| 19 | 946195  | Bearing Nut        |
| 20 | 946193  | Drum               |
| 21 | 946194  | Baffle             |
| 22 | 2001034 | Overlay, Cover     |
| 23 | 1112382 | Front Cover        |
| 24 | 488886  | Screw              |
| 25 | 489211  | Screw              |
| 28 | 1113140 | Lens, Dispenser    |
| 29 | 547225  | Light Bulb         |

# REFRIGERATOR SHELF PARTS


For Model: KSSS48DBX00



|    |         |                                |
|----|---------|--------------------------------|
| 1  | 1112004 | Frame, Shelf                   |
| 2  | 1113956 | Glass, Shelf                   |
| 3  | 1112006 | Reflector, Shelf               |
| 4  | 1113792 | Gasket, Glass (2)              |
| 5  | 1125913 | Rack, Wine                     |
| 6  | 2002181 | Retainer Glass                 |
| 7  | 1112014 | Frame Assembly                 |
| 9  | 1112247 | Cover, Crisper                 |
| 10 | 2002148 | Glass, Crisper                 |
| 11 | 2000742 | Meat, Pan Connector            |
| 14 | 2000554 | Crisper Pan                    |
| 15 | 1113870 | Roller                         |
| 16 | 1113871 | Eyelet, Roller                 |
| 17 | 489211  | Screw                          |
| 18 | 488307  | Washer                         |
| 19 | 2000557 | Utility Pan                    |
| 20 | 2000817 | Meat Pan                       |
| 21 | 2164372 | Egg Bin                        |
| 22 | 2164373 | Egg Carrier                    |
| 23 | 2164374 | Cover                          |
| 25 | 1112165 | Crisper Spacer, Right Side (2) |
| 27 | 1113169 | Stop, Roller                   |
| 28 | 2002180 | Crisper Spacer, Left Side (2)  |
| 29 | 486194  | Screw                          |

# REFRIGERATOR DOOR PARTS


For Model: KSSS48DBX00



|    |         |                                                              |
|----|---------|--------------------------------------------------------------|
| 1  | 2000695 | Door Panel, Refrigerator (Also Order Item 29)                |
| 2  | 939101  | Screw Anchor (8)                                             |
| 3  | 2000696 | Hinge Assembly, Top                                          |
| 4  | 2000303 | Spacer                                                       |
| 5  | 489282  | Screw                                                        |
| 6  | 2000698 | Hinge Assembly, Bottom                                       |
| 7  | 1112533 | Gasket Retainer, Side (2)                                    |
| 8  | 1112542 | Gasket Retainer, Top & Bottom                                |
| 9  | 2001049 | Door Gasket, Magnetic                                        |
| 10 | 489101  | Screw                                                        |
| 11 | 2000323 | Handle, Door                                                 |
| 12 | 1113955 | Gasket Utility Door                                          |
| 13 | 2000349 | Tap Plate                                                    |
| 14 | 2000697 | Door, Spacer Bottom                                          |
| 15 | 487052  | Screw                                                        |
| 16 | 2000317 | Trim (Top)                                                   |
| 17 | 489112  | Screw                                                        |
| 18 | 2000314 | Trim (Side)                                                  |
| 19 | 2000320 | Trim (Bottom)                                                |
| 20 | 1113950 | Panel, Interior Door                                         |
| 21 | 1113949 | Ladder, Shelf (2)                                            |
| 22 | 1113948 | Retainer, Shelf Ladder (2)                                   |
| 23 | 1112514 | Back Up Plate (8)                                            |
| 24 | 486194  | Screw                                                        |
| 26 | 1112737 | Door, Utility Bin                                            |
| 27 | 2000622 | Door Shelf (4)                                               |
| 28 | 1125936 | Butter Tray                                                  |
| 29 | 876029  | Kit, Foam Slab (Required When Replacing Exterior Door Panel) |

# FREEZER DOOR PARTS


For Model: KSSS48DBX00



|    |         |                                                    |
|----|---------|----------------------------------------------------|
| 1  | 2001138 | Exterior Door Panel, Freezer (Includes Insulation) |
| 2  | 1112997 | Tube, Wiring                                       |
| 3  | 1112928 | Retainer, Tube                                     |
| 6  | 2000720 | Hinge, Bottom                                      |
| 7  | 489282  | Screw                                              |
| 8  | 2000721 | Hinge, Top                                         |
| 9  | 2000303 | Spacer Plate                                       |
| 10 | 2000697 | Door, Spacer Bottom                                |
| 11 | 2001323 | Wiring Harness, Freezer Door                       |
| 12 | 1112533 | Gasket Retainer, Side (2)                          |
| 13 | 1112539 | Gasket Retainer, Top & Bottom                      |
| 14 | 2000878 | Door Gasket, Magnetic                              |
| 15 | 489101  | Screw                                              |
| 16 | 2000324 | Handle, Door                                       |
| 20 | 487052  | Screw                                              |
| 21 | 2000328 | Trim (Top)                                         |
| 22 | 489112  | Screw                                              |
| 23 | 2000331 | Trim (Bottom)                                      |
| 24 | 2000325 | Trim (Side)                                        |
| 26 | 1113947 | Panel, Interior Door                               |
| 28 | 2000606 | Door Shelf, Assembly                               |
| 32 | 227991  | Wire Connector                                     |
| 33 | 939101  | Screw Anchor                                       |
| 34 | 2000798 | Ice Chute                                          |

# DISPENSER AND FRONT PARTS


For Model: KSSS48DBX00



|    |         |                                              |
|----|---------|----------------------------------------------|
| 1  | 1107943 | Housing, Dispenser                           |
| 2  | 987049  | Bracket, Water Fitting                       |
| 3  | 2155018 | Water Fitting Assembly (Includes Water Tube) |
| 4  | 487916  | Screw                                        |
| 5  |         | Water Tube (See Item #3)                     |
| 9  | 488316  | Screw                                        |
| 10 | 987048  | Grommet                                      |
| 11 | 2001334 | Heater, Ice Dispenser                        |
| 12 | 2147167 | Ice Door Mechanism                           |
| 13 | 2147168 | Door, Ice                                    |
| 14 | 1129333 | Shroud                                       |
| 16 | 489000  | Screw                                        |
| 17 | 1127421 | Lever, Ice Dispenser                         |
| 19 | 987917  | Bearing, Clip                                |
| 20 | 2159196 | Lever, Water Dispenser                       |
| 21 | 488307  | Washer                                       |
| 22 | 983696  | Spring, Lever                                |
| 23 | 983697  | Bearing, Lever                               |
| 24 | 1120581 | Delay Mechanism                              |
| 25 | 1107454 | Bracket, Control                             |
| 26 | 841336  | Switch                                       |
| 27 | 984683  | Insulation, Switch                           |
| 28 | 488361  | Screw                                        |
| 29 | 987265  | Lamp Holder                                  |
| 30 | 488500  | Screw                                        |
| 31 | 851386  | Light Switch                                 |
| 32 | 1107457 | Plunger, Extension                           |
| 33 | 983986  | Spring, Plunger                              |
| 34 | 983987  | Retainer, Pin                                |
| 35 | 2001350 | Wiring Harness, Door                         |
| 36 | 984494  | Wiring Shield                                |
| 37 | 1118269 | Guiding, Ice                                 |
| 38 | 1119056 | Glass Stop                                   |
| 39 | 489197  | Screw                                        |
| 40 | 487052  | Screw                                        |
| 41 | 851389  | Light Bulb                                   |
| 42 | 2001480 | Front Cover, Housing (Includes Item 49)      |
| 44 | 1112836 | Cover, Dispenser Opening                     |
| 45 | 2001477 | Trim, Front (2)                              |
| 47 | 983900  | Grille, Overflow                             |
| 48 | 934316  | Switch                                       |
| 49 | 2001483 | Overlay, Cover                               |
| 53 | 487944  | Washer (2)                                   |
| 54 | 488568  | Screw (2)                                    |
| 55 | 482672  | Seal                                         |

# UPPER UNIT PARTS

For Model: KSSS48DBX00



|    |         |                                                               |
|----|---------|---------------------------------------------------------------|
| 1  | 2001929 | Assembly, Unit Base                                           |
| 2  | 2163787 | Clip, Compressor Mounting (4)                                 |
| 3  | 2169273 | Compressor (Includes Items 7, 8, 9, 10, 11 & 12) (Also Order) |
|    | 876765  | Tube Kit                                                      |
| 6  | 2163786 | Grommet, Mounting                                             |
| 7  | 1127675 | Wire Assembly                                                 |
| 8  | 2162362 | Overload (Includes Relay)                                     |
| 9  | 1108115 | Terminal Cover                                                |
| 10 | 938384  | Strap, Cover                                                  |
| 11 |         | Relay (See Overload)                                          |
| 12 |         | Capacitor                                                     |
|    | 2169137 | Production                                                    |
|    | 2154565 | Service                                                       |
| 14 | 486899  | Screw                                                         |
| 15 | 487869  | Screw                                                         |
| 16 | 1113015 | Condenser                                                     |
| 17 | 943447  | Grommet (4)                                                   |
| 18 | 1113019 | Clamp (4)                                                     |
| 19 | 487522  | Screw                                                         |
| 20 | 1113228 | Wire Tie (2)                                                  |
| 21 | 1108023 | Drier                                                         |
| 22 | 2000358 | Mounting Bracket, Motor                                       |
| 23 | 2002409 | Motor, Fan                                                    |
| 24 | 2000352 | Blade, Fan                                                    |
| 25 | 2000351 | Orifice, Fan                                                  |
| 26 | 1113303 | Gasket, Orifice                                               |
| 27 | 489399  | Screw (3)                                                     |
| 28 | 489368  | Screw                                                         |
| 29 | 486692  | Speed Nut                                                     |
| 30 | 2162044 | Defrost Timer                                                 |
| 31 | 488911  | Screw                                                         |
| 32 | 2000645 | Sleeve, Condenser                                             |
| 33 | 1113066 | Clamp, Tube (2)                                               |
| 34 | 1113059 | Process, Tube                                                 |
| 35 | 486194  | Screw                                                         |
| 36 | 2000853 | Cover, Fan                                                    |
| 37 | 2001878 | Cover, Condenser                                              |
| 38 | 1113076 | Extension, Housing                                            |
| 39 | 937360  | Service Cord                                                  |
| 40 | 2001503 | Seal Strip (2)                                                |
| 41 | 1113162 | Clamp, Cord (2)                                               |
| 42 | 1113229 | Switch, Power Disconnect                                      |
| 43 | 488879  | Screw, Ground                                                 |
| 44 | 653035  | Clip, Cord Plug                                               |
| 45 | 2001078 | Wiring Harness, Unit Compartment                              |
| 47 | 2001079 | Gasket (2)                                                    |

Following Parts Not Illustrated and Optional Parts Not Included

|        |                       |
|--------|-----------------------|
| 978025 | Valve, Access (1/4")  |
| 978026 | Valve, Access (5/16") |
| 978027 | Valve, Access (3/8")  |
| 978028 | Valve, Access (1/2")  |
| 978029 | Valve, Access (5/8")  |
| 978030 | Valve, Access (3/4")  |
| 876764 | Valve, Access (3/16") |


REFRIGERANT CHARGE 10 oz.

**For Model: KSSS48DBX00**



|    |         |                       |
|----|---------|-----------------------|
| 1  | 2000528 | Defrost Bi-Metal      |
| 2  | 1113043 | Clamp, Bi-Metal       |
| 3  | 486194  | Screw                 |
| 4  | 2002186 | Sleeve                |
| 5  | 2002171 | Sleeve                |
| 6  | 2002184 | Condenser Inlet Tube  |
| 8  | 2002408 | Tube, Connect (Drier) |
| 9  | 2000756 | Heater, Drain Pan     |
| 10 | 1113062 | Hanger, Heater        |
| 11 | 1113105 | Bracket, Heater       |
| 12 | 487534  | Screw                 |
| 13 | 2002381 | Tube, Discharge       |
| 14 | 2002187 | Sleeve                |
| 15 | 2002403 | Heat Exchanger        |
| 16 | 2001133 | Evaporator            |
| 17 | 2001608 | Heater, Defrost       |
| 18 | 1113048 | Clamp, Heater (2)     |
| 19 | 1108431 | Clamp, Heater (2)     |
| 20 | 1112844 | Gasket, Evaporator    |
| 21 | 857547  | Wire Tie              |
| 22 | 1113070 | Guard, Hook-Up        |
| 23 | 851095  | Strap (7)             |
| 24 | 488946  | Clamp, Wiring         |
| 25 | 2001264 | Drain Pan             |
| 26 |         | Bracket, Drain Pan    |
|    | 1113206 | (L.H.)                |
|    | 1113207 | (R.H.)                |
| 27 | 513942  | Dampener              |
| 28 | 934011  | Clip, Water Tube      |


**For Model: KSSS48DBX00**



|    |         |                             |
|----|---------|-----------------------------|
| 1  | 2001086 | Fan Motor                   |
| 2  | 488908  | Screw                       |
| 3  | 2154800 | Fan Blade                   |
| 4  | 548263  | Bracket (Double)            |
| 5  | 938224  | Bracket (Single)            |
| 6  | 548268  | Grommet                     |
| 7  | 486194  | Screw                       |
| 8  | 2000618 | Motor, Wiring               |
| 9  | 488366  | Clamp                       |
| 11 | 489348  | Clamp, Nylon                |
| 12 | 2000113 | Channel, Wiring             |
| 13 | 2150347 | Union                       |
| 14 | 2000783 | Scroll, Fan                 |
| 16 | 488772  | Screw                       |
| 17 | 2000746 | Assembly, Air Duct          |
| 18 | 2000048 | Air Deflector, Icemaker     |
| 19 | 1112870 | Cup, Motor                  |
| 21 | 1112871 | Fastener (3)                |
| 22 | 1112869 | Gasket, Air Baffle          |
| 23 | 1113942 | Cover, Air Outlet           |
| 25 | 2000342 | Cover, Evaporator           |
| 26 | 2000796 | Connector, Meat Pan Duct    |
| 27 | 487539  | Screw                       |
| 28 | 1112840 | Baffle, Evaporator          |
| 29 | 1112853 | Diffuser, Air Duct          |
| 30 | 2000861 | Reservior, Water            |
| 31 | 488280  | Screw                       |
| 32 |         | Evaporator, Cover Rail      |
|    | 2000686 | Left Side                   |
|    | 2000685 | Right Side                  |
| 33 | 2001337 | Gasket (2) Evaporator Cover |
| 34 | 2001079 | Gasket (2)                  |
| 35 | 2001080 | Gasket                      |
| 36 | 2001081 | Gasket                      |

# ICEMAKER PARTS

For Model: KSSS48DBX00



|     |         |                                             |
|-----|---------|---------------------------------------------|
| 1   | 489084  | Screw                                       |
| 2   | 2000829 | Fitting, Water Tube                         |
| 3   | 2001087 | Clamp, Tube                                 |
| 4   | 841707  | Insert, Tube                                |
| 5   | 628379  | Clip, Fuse                                  |
| 6   | 2000392 | Wire Clip                                   |
| 7   | 2001260 | Tube, Water (To Ice Maker)                  |
| 8   | 1106508 | Seal Gasket                                 |
| 9   | 487627  | Sleeve, Nut                                 |
| 10  | 2002182 | Valve, Solenoid                             |
| 11  | 627018  | Nut, Compression                            |
| 12  | 227991  | Connector, Wire                             |
| 13  | 2000836 | Water Valve, Harness                        |
| 14  | 2001320 | Copper, Water Line                          |
| 15  | 489348  | Clamp, Nylon Valve                          |
| 16  | 1113066 | Clamp Tube                                  |
| 17  | 487857  | Nut                                         |
| 18  | 628355  | Cover                                       |
| 20  | 628228  | Mold & Heater (Also Order)                  |
|     | 542638  | Silicone Grease                             |
| 21  | 628258  | Motor                                       |
| 22  | 628356  | Cup-Water Fill                              |
| 23  | 627843  | Ejector                                     |
| 24  | 627788  | Ice Striper                                 |
| 25  | 627790  | Support                                     |
| 26  | 627796  | Retainer Thermostat (2)                     |
| 27  | 627985  | Thermostat (Also Order)                     |
|     | 542639  | Cement Alumilastic                          |
| 28  | 489322  | Screw                                       |
| 29  | 628357  | Module Assembly                             |
| 30  | 489276  | Screw                                       |
| 31  | 2171593 | Shut Off Arm                                |
| 32  | 2002006 | Harness, Wiring                             |
| 33  | 627915  | Bracket                                     |
| 34  | 489365  | Screw                                       |
| 35  | 628366  | Module Assembly (Includes Items 21, 29, 41) |
| 37  | 2000803 | Water Valve Mounting Bracket                |
| 38  | 2001098 | Water Inlet Tube                            |
| 41  | 489136  | Screw, (2)                                  |
| 42  | 857547  | Wire Tie                                    |
| 43  | 488645  | Screw                                       |
| 44  | 1129179 | Compression Nut                             |
| 45  | 1129177 | Insert, Tube                                |
| 100 | 4317943 | Icemaker                                    |

Following Parts Not Illustrated (Optional Parts Only)

|         |                                   |
|---------|-----------------------------------|
| 4318424 | Front Panel Kit (White)           |
| 4318423 | Front Panel Kit (Black)           |
| 4318425 | Front Panel Kit (Almond)          |
| 4318426 | Front Panel Kit (Stainless Steel) |
| 978849  | Black Acrylic Static Cleaner      |


LITERATURE PARTS

|            |                                |
|------------|--------------------------------|
| LIT2002424 | Use & Care Guide               |
| LIT2002437 | Energy Label                   |
| LIT2002160 | Service & Wiring Sheet         |
| LIT628370  | Modular Icemaker Service Sheet |

LIT2002469 Installation Instructions

# TOP GRILLE AND UNIT COVER PARTS


For Model: KSSS48DBX00



|   |         |                           |
|---|---------|---------------------------|
| 1 | 2001317 | Decorative Panel Assembly |
| 2 | 1113356 | Back Up Panel             |
| 3 | 2002664 | Top Grille Assembly       |
| 4 | 2001883 | Cover, Unit               |
| 5 | 486194  | Screw                     |
| 6 | 2001874 | Cover, Component Assembly |
| 7 | 1113317 | Brace                     |

# FREEZER SHELF PARTS


For Model: KSSS48DBX00



|    |         |                          |
|----|---------|--------------------------|
| 1  | 1112367 | Solid Shelf              |
| 2  | 2000529 | Front, Ice Compartment   |
| 3  | 1112052 | Shelf, Fixed             |
| 4  | 1113638 | Shelf, Fixes (2) (Large) |
| 14 | 1113644 | Trim, Basket             |
| 15 | 1113870 | Roller                   |
| 16 | 1113871 | Eyelet, Roller           |
| 17 | 489211  | Screw                    |
| 18 | 488307  | Washer                   |
| 19 | 2001626 | Basket                   |
| 22 | 2000061 | Slide, Basket R.S.       |
|    | 2000062 | Slide, Basket L.S.       |
| 24 | 1113169 | Stop, Roller             |
| 25 | 486194  | Screw                    |

# REFRIGERATOR CONTROL PANEL PARTS


For Model: KSSS48DBX00



|    |         |                       |
|----|---------|-----------------------|
| 1  | 1112642 | Control Panel         |
| 2  | 2000976 | Inlay, Control Panel  |
| 3  | 2000789 | Circuit Board         |
| 4  | 2001738 | Control Knob          |
| 5  | 837444  | Retainer, Knob        |
| 6  | 1108112 | Switch, Rocker Arm    |
| 7  | 1113137 | Seal, Control Panel   |
| 8  | 489260  | Screw (3)             |
| 9  | 2000153 | Hole Plug (3)         |
| 10 | 1113775 | Shield, Control Panel |
| 11 | 1112613 | Socket, Light (2)     |
| 12 | 547225  | Light Bulb (2)        |
| 13 | 486194  | Screw                 |
| 15 | 2001141 | Channel, Wiring       |
| 16 | 1115375 | Clip, Wiring (2)      |
| 17 | 2001074 | Control, Harness      |

# FREEZER CONTROL PANEL PARTS

For Model: KSSS48DBX00



|    |         |                                      |
|----|---------|--------------------------------------|
| 1  | 1112597 | Control Panel                        |
| 2  | 1113959 | Inlay, Control Panel                 |
| 3  | 1113466 | Thermostat & Barrier Assembly        |
| 4  | 488974  | Screw (2)                            |
| 5  | 851387  | Switch, Rocker Arm (Dispenser Motor) |
| 6  | 1113136 | Seal, Control Panel                  |
| 8  | 489260  | Screw (3)                            |
| 10 | 1113769 | Shield, Control Panel                |
| 11 | 1112613 | Socket, Light                        |
| 12 | 486194  | Screw                                |
| 13 | 547225  | Light Bulb                           |
| 14 | 1112707 | Channel, Wiring                      |
| 15 | 1108112 | Switch, Rocker Arm (Light)           |
| 16 | 2001737 | Knob, Thermostat                     |
| 17 | 1115375 | Clip, Wiring                         |