


KitchenAid.

CABINET PARTS

For Model: KSSS48MBX00

REFRIGERATOR




10/94

1		Cabinet (Not A Serviceable Part)
2	1112019	Leveler, Front (2)
3	1113249	Retainer (2)
4	1112023	Roller, Front & Rear (4)
5	1112695	Leveler, Adjustable (2)
6	2000670	Adjusting Rod (2)
7	1113250	Sleeve, Retainer (2)
8	1112937	Bushing, Rod (2)
9	489359	Screw
10	1112939	Hole Plug, Leveler
11	1112849	Cap, Grommet
13	1113122	Grommet, Wiring
14	2002003	Wiring Harness, Cabinet
15	1112848	Drain Fitting
16		Gap, Cover Assembly (Top)
	2000305	Left Side
	2000304	Right Side
17	2001295	Shoulder Screw
18		Hinge (Top)
	2000306	Left Side
	2000307	Right Side
19	2000770	Shim, Hinge Top
20	1112805	Guard, Wiring
21	487534	Screw (2)
23	1112992	Door Closer Assembly (2)
24	2000333	Bracket, Door Closer
25	486194	Screw
26	1112973	Tap Plate, Hinge Butt (2)
27	1113227	Fastener (3)
28		Gap, Cover Assembly (Bottom)
	2001200	Left Side
	2001199	Right Side
29		Hinge (Bottom)
	2001733	Left Side
	2001732	Right Side
30	1112942	Shim, Hinge (1)
	1112943	Shim, Hinge (2) Bottom (4)
31	2000490	Screw
33	2001266	Tube clamp
34	2001964	Grille Base, Front
35	489238	Screw (6)
36	2000684	Cover, Rear
37	1113123	Grommet, Wiring
38	1113079	Grommet, Flexible
41	2001377	Screw
42	2000530	Grommet
43	2001415	Screw (4)
44	489359	Screw

CABINET TRIM PARTS


For Model: KSSS48MBX00



1	2000321	Cabinet, Trim R.S
2	2000322	Cabinet, Trim L.S
3	2001297	Screw
4	2001190	Cabinet, Trim (Bottom)
5	488649	Screw
6	2001311	Cabinet, Trim Top
7	2000007	Retainer, Unit Base (2)
8	487944	Washer (2)

REFRIGERATOR LINER PARTS


For Model: KSSS48MBX00



1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw
8	486194	Screw
9	1112257	Hole Plug
10	2000740	Meat Pan, Air Duct Cover (Also Order 12)
11	2000337	Meat Pan, Air Duct
12	2001302	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2001735	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	2000343	Air Baffle Assembly
20	2001073	Wiring Harness, Air Baffle
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2000736	Air Baffle Cover
26	2000527	Guard, Air Return

FREEZER LINER PARTS


For Model: KSSS48MBX00



1		Liner (Not A Serviceable Part)
2	1113649	Bracket
3	1113650	Light Lens
4	1112613	Light Socket
5	547225	Light Bulb
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw
12	486194	Screw
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (8)
18	487559	Screw

TOP GRILLE AND UNIT COVER PARTS


For Model: KSSS48MBX00



1	2001317	Decorative Panel Assembly
2	1113356	Back Up Panel
3	2001916	Top Grille Assembly
4	2001883	Cover, Unit
5	486194	Screw
6	2001874	Cover, Component Assembly
7	1113317	Brace

REFRIGERATOR SHELF PARTS


For Model: KSSS48MBX00



1	1112004	Frame, Shelf
2	1113956	Glass, Shelf
3	1112006	Reflector, Shelf
4	1113792	Gasket, Glass (2)
5	1125913	Rack, Wine
6	2002181	Retainer Glass
7	1112014	Frame Assembly
9	1112247	Cover, Crisper
10	2002148	Glass, Crisper
11	2000742	Meat, Pan Connector
14	2000554	Crisper Pan
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw
18	488307	Washer
19	2000557	Utility Pan
20	2000817	Meat Pan
21	2164372	Egg Bin
22	2164373	Egg Carrier
23	2164374	Cover
25	1112165	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	2002180	Crisper Spacer, Left Side (2)
29	486194	Screw

REFRIGERATOR DOOR PARTS


For Model: KSSS48MBX00



1	2000695	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	2000696	Hinge Assembly, Top
4	2000303	Spacer
5	489282	Screw
6	2000698	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112542	Gasket Retainer, Top & Bottom
9	2001049	Door Gasket, Magnetic
10	489101	Screw
11	2000323	Handle, Door
12	1113955	Gasket Utility Door
13	2000349	Tap Plate
14	2000697	Door, Spacer Bottom
15	487052	Screw
16	2000317	Trim (Top)
17	489112	Screw
18	2000314	Trim (Side)
19	2000320	Trim (Bottom)
20	1113950	Panel, Interior Door
21	1113949	Ladder, Shelf (2)
22	1113948	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw
26	1112737	Door, Utility Bin
27	2000622	Door Shelf (4)
28	1125936	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)

FREEZER DOOR PARTS


For Model: KSSS48MBX00



1	2000716	Exterior Door Panel, Freezer
4	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)
6	2000720	Hinge, Bottom
7	489282	Screw
8	2000721	Hinge, Top
9	2000303	Spacer Plate
10	2000697	Door, Spacer Bottom
12	1112533	Gasket Retainer, Side (2)
13	1112539	Gasket Retainer, Top & Bottom
14	2000878	Door Gasket, Magnetic
15	489101	Screw
16	2000324	Handle, Door
20	487052	Screw
21	2000328	Trim (Top)
22	489112	Screw
23	2000331	Trim (Bottom)
24	2000325	Trim (Side)
26	2000179	Panel, Interior Door
28	2000606	Door Shelf, Assembly
33	939101	Screw Anchor

UPPER UNIT PARTS

For Model: KSSS48MBX00



1	2001929	Assembly, Unit Base
2	2163787	Clip, Compressor Mounting (4)
3	2169273	Compressor (Includes Items 7, 8, 9, 10, 11 & 12) (Also Order)
	876765	Tube Kit
6	2163786	Grommet, Mounting
7	1127675	Wire Assembly
8	2162362	Overload (Includes Relay)
9	1108115	Terminal Cover
10	938384	Strap, Cover
11		Relay (See Overload)
12		Capacitor
	2169137	Production
	2154565	Service
14	486899	Screw
15	487869	Screw
16	1113015	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw
20	1113228	Wire Tie (2)
21	1108023	Drier
22	2000358	Mounting Bracket, Motor
23	2002409	Motor, Fan
24	2000352	Blade, Fan
25	2000351	Orifice, Fan
26	1113303	Gasket, Orifice
27	489399	Screw (3)
28	489368	Screw
29	486692	Speed Nut
30	2162044	Defrost Timer
31	488911	Screw
32	2000645	Sleeve, Condenser
33	1113066	Clamp, Tube (2)
34	1113059	Process, Tube
35	486194	Screw
36	2000853	Cover, Fan
37	2001878	Cover, Condenser
38	1113076	Extension, Housing
39	937360	Service Cord
40	2001503	Seal Strip (2)
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	2001077	Wiring Harness, Unit Compartment
47	2001079	Gasket (2)

Following Parts Not Illustrated and Optional Parts Not Included


978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE 10 OZ.

Production Compressor Requires Production Electrical Components. Service Compressor Requires Service electrical Components. For Further Information, Refer to Standard Brand and Related Components.

LOWER UNIT AND TUBE PARTS


For Model: KSSS48MBX00



1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw
4	2002186	Sleeve
5	2002171	Sleeve
6	2002184	Condenser Inlet Tube
8	2002408	Tube, Connect (Drier)
9	2000756	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw
13	2002381	Tube, Discharge
14	2002187	Sleeve
15	2002403	Heat Exchanger
16	2001133	Evaporator
17	2001608	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
23	851095	Strap (7)
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	(L.H.)
	1113207	(R.H.)
27	513942	Dampener

AIR FLOW AND RESERVOIR PARTS


For Model: KSSS48MBX00



1	2001086	Fan Motor
2	488908	Screw
3	2154800	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw
8	2000618	Motor, Wiring
9	488500	Screw, Ground
10	488366	Clamp, Tube
11	489348	Clamp, Nylon
12	2000113	Channel, Wiring
14	2000783	Scroll, Fan
16	488772	Screw
17	2000749	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
25	2000342	Cover, Evaporator
26	2000796	Connector, Meat Pan Duct
27	487539	Screw
28	1112840	Baffle, Evaporator
29	1112853	Diffuser, Air Duct
42		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
45	2001337	Gasket (2) Evaporator Cover
46	2001079	Gasket (2)
47	2001080	Gasket
48	2001081	Gasket

ICEMAKER PARTS

For Model: KSSS48MBX00



1	489084	Screw
2	2000829	Fitting, Water Tube
3	2001087	Clamp, Tube
4	841707	Insert, Tube
5	628379	Clip, Fuse
6	2000392	Wire Clip
7	2001260	Tube, Water (To Ice Maker)
8	1106508	Seal Gasket
9	487627	Sleeve, Nut
10	2001318	Valve, Solenoid
11	627018	Nut, Compression
12	227991	Connector, Wire
13	2000837	Water Valve, Harness
14	2001320	Copper, Water Line
15	489348	Clamp, Nylon Valve
16	1113066	Clamp Tube
17	487857	Nut
18	1113703	Cover
20	628228	Mold & Heater (Also Order)
	542638	Silicone Grease
21	628258	Motor
22	628356	Cup-Water Fill
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer Thermostat (2)
27	627985	Thermostat (Also Order)
	542639	Cement Alumilastic
28	489322	Screw
29	628357	Module Assembly
30	489276	Screw
31	627792	Shut Off Arm
32	2002006	Harness, Wiring
33	627915	Bracket
34	489365	Screw
35	628366	Module Assembly (Includes Items 21, 29, 41)
37	2000803	Water Valve Mounting Bracket
38	2001098	Water Inlet Tube
41	489136	Screw, (2)
42	857547	Wire Tie
43	488645	Screw
100	4317943	Icemaker

Following Parts Not Illustrated (Optional Parts Only)


4318637	Front Panel Kit (White)
4318634	Front Panel Kit (Black)
4318640	Front Panel Kit (Almond)
4318643	Front Panel Kit (Stainless Steel)
978849	Static Cleaner

LITERATURE PARTS

LIT2002424	Use & Care Guide
LIT2002438	Energy Label
LIT2002405	Service & Wiring Sheet
LIT628370	Modular Icemaker Service Sheet
LIT2002469	Installation Instructions

FREEZER SHELF PARTS


For Model: KSSS48MBX00



1	1113630	Solid Shelf
2	837141	Ice Cube Pan
3	1112052	Shelf, Fixed
4	1113638	Shelf, Fixed (2) (Large)
5	1122530	Trim
6	1113635	Shelf
14	1113644	Trim, Basket
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw
18	488307	Washer
19	2001626	Basket
22	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
24	1113169	Stop, Roller
25	486194	Screw

REFRIGERATOR CONTROL PANEL PARTS


For Model: KSSS48MBX00



1	1112642	Control Panel
2	2000976	Inlay, Control Panel
3	2000789	Circuit Board
4	2001738	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113137	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113775	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)
17	2001074	Control, Harness

FREEZER CONTROL PANEL PARTS

For Model: KSSS48MBX00



1	1113627	Control Panel
2	1113959	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	487294	Screw
6	1113136	Seal, Control Panel
8	489260	Screw (3)
10	1113769	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	2001737	Knob, Thermostat
17	1115375	Clip, Wiring