

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)	16		Gap, Cover Assembly (Top)	29		Hinge (Bottom)
2	1112019	Leveler, Front (2)		2000305	Left Side		2001733	Left Side
3	1113249	Retainer (2)		2000304	Right Side		2001732	Right Side
4	1112023	Roller, Front & Rear (4)	17	2001295	Shoulder Screw	30	1112942	Shim, Hinge (1)
5	1112695	Leveler, Adjustable (2)	18		Hinge (Top)		1112943	Shim, Hinge (2)
6	2000670	Adjusting Rod (2)		2000306	Left Side	31	2000490	Bottom (4)
7	1113250	Sleeve, Retainer (2)		2000307	Right Side			Screw, 1/4-28 x 3/4
8	1112937	Bushing, Rod (2)	19	2000770	Shim, Hinge Top	33	2001266	Tube clamp
9	489359	Screw	20	1112805	Guard, Wiring	34	2001964	Grille Base, Front
10	1112939	Hole Plug, Leveler	21	487534	Screw (2)	35	489238	Screw (6)
11	1112849	Cap, Grommet	23	1112992	Door Closer Assembly (2)	36	2000684	Cover, Rear
13	1113122	Grommet, Wiring	24	2000333	Bracket, Door Closer	37	1113123	Grommet, Wiring
14	2000835	Wiring Harness, Cabinet	25	486194	Screw, 8 x 1/2	38	1113079	Grommet, Flexible
15	1112848	Drain Fitting	26	1112973	Tap Plate, Hinge Butt (2)	41	2001377	Screw
			27	1113227	Fastener (3)	42	2000530	Grommet
			28		Gap, Cover Assembly (Bottom)	43	2001415	Screw (4)
				2001200	Left Side	44	489359	Screw
				2001199	Right Side			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIMS AND BREAKER TRIM PARTS


For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION
1	2001764	Breaker Trim & Retainer Assembly
5	1112682	Magnet, Side (4)
6	1112679	Magnet, Freezer (2)
7	1112681	Magnet, Refrigerator (2)
9	2000321	Cabinet, Trim R.S
10	2000322	Cabinet, Trim L.S
11	2001297	Screw
12	1112802	Cabinet, Trim (Bottom)
13	488649	Screw, 8-32 x 1/2 (8)
14	2001311	Cabinet, Trim Top
15	2000007	Retainer, Unit Base (2)
16	487944	Washer (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION
1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw, 8 x 1-1/4 (8)
8	486194	Screw, 8 x 1/2
9	1112257	Hole Plug
10	2000740	Meat Pan, Air Duct Cover (Also Order 12)
11	2000337	Meat Pan, Air Duct
12	2001302	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2001735	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	2000343	Air Baffle Assembly
20	2001073	Wiring Harness, Air Baffle
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2000736	Air Baffle Cover
26	2000527	Guard, Air Return

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Model: KSSS48MAX03




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	1113649	Bracket
3	1113650	Light Lens
4	1112613	Light Socket
5	547225	Light Bulb
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw, 10-12 x 3/8 (2)
12	486194	Screw, 8 x 1/2
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (8)
18	487559	Screw, 8-15 x 1-1/4 (8)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Model: KSSS48MAX03




Illus. No.	Part No.	DESCRIPTION
1	2001317	Decorative Panel Assembly
2	1113356	Back Up Panel
3	2001579	Top Grille Assembly
4	2001088	Cover, Unit
5	486194	Screw
6	1113300	Cover, Component Assembly
7	1113317	Brace

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: KSSS48MAX03




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	1112004	Frame, Shelf	10	1113238	Glass, Crisper	19	2000557	Utility Pan
2	1113956	Glass, Shelf	11	2000742	Meat, Pan Connector	20	2000817	Meat Pan
3	1112006	Reflector, Shelf	14	2000554	Crisper Pan	25	1112165	Crisper Spacer, Right Side (2)
4	1113792	Gasket, Glass (2)	15	1113870	Roller	27	1113169	Stop, Roller
5	1125913	Rack, Wine	16	1113871	Eyelet, Roller	28	1113890	Crisper Spacer, Left Side (2)
6	1112324	Retainer Glass	17	489211	Screw, 10-16 x 3/4	29	486194	Screw, 8 x 1/2
7	1112014	Frame Assembly	18	488307	Washer			
9	1112247	Cover, Crisper						

FREEZER SHELF PARTS




Illus. No.	Part No.	DESCRIPTION
1	1113630	Solid Shelf
2	837141	Ice Cube Pan
3	1112052	Shelf, Fixed
4	1113638	Shelf, Fixed (2) (Large)
5	1122530	Trim
6	1113635	Shelf
14	1113644	Trim, Basket
15	1113870	Roller
16	1113871	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
18	488307	Washer
19	2001626	Basket
22	2000061	Slide, Basket R.S.
	2000062	Slide, Basket L.S.
24	1113169	Stop, Roller
25	486194	Screw, 8 x 1/2

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR DOOR PARTS

For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2000695	Door Panel, Refrigerator (Also Order Item 29)	9	2001049	Door Gasket, Magnetic	20	1113950	Panel, Interior Door
2	939101	Screw Anchor (8)	10	489101	Screw, 7 x 1/2 (36)	21	1113949	Ladder, Shelf (2)
3	2000696	Hinge Assembly, Top	11	2000323	Handle, Door	22	1113948	Retainer, Shelf Ladder (2)
4	2000303	Spacer	12	1113955	Gasket Utility Door	23	1112514	Back Up Plate (8)
5	489282	Screw	13	2000349	Tap Plate	24	486194	Screw, 8 x 1/2
6	2000698	Hinge Assembly, Bottom	14	2000697	Door, Spacer Bottom	26	1112737	Door, Utility Bin
7	1112533	Gasket Retainer, Side (2)	15	487052	Screw	27	2000622	Door Shelf (4)
8	1112542	Gasket Retainer, Top & Bottom	16	2000317	Trim (Top)	28	1125936	Butter Tray
			17	489112	Screw	29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)
			18	2000314	Trim (Side)			
			19	2000320	Trim (Bottom)			

REFRIGERATOR CONTROL PANEL PARTS


Illus. No.	Part No.	DESCRIPTION
1	1112642	Control Panel
2	2000976	Inlay, Control Panel
3	2000789	Circuit Board
4	2001738	Control Knob
5	837444	Retainer, Knob
6	1108112	Switch, Rocker Arm
7	1113137	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	1113775	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw, 8 x 1/2
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)
17	2001074	Control, Harness



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2000716	Exterior Door Panel, Freezer	12	1112533	Gasket Retainer, Side (2)	21	2000328	Trim (Top)
4	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)	13	1112539	Gasket Retainer, Top & Bottom	22	489112	Screw
6	2000720	Hinge, Bottom	14	2000878	Door Gasket, Magnetic	23	2000331	Trim (Bottom)
7	489282	Screw	15	489101	Screw, 7 x 1/2 (34)	24	2000325	Trim (Side)
8	2000721	Hinge, Top	16	2000324	Handle, Door	26	2000179	Panel, Interior Door
9	2000303	Spacer Plate	20	487052	Screw	28	2000606	Door Shelf, Assembly
10	2000697	Door, Spacer Bottom				33	939101	Screw Anchor

FREEZER CONTROL PANEL PARTS

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	1112597	Control Panel
2	1113959	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
6	1113136	Seal, Control Panel
8	489260	Screw (3)
10	1113769	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw, 8 x 1/2
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	1108112	Switch, Rocker Arm (Light)
16	2001737	Knob, Thermostat
17	1115375	Clip, Wiring



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS


For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2001123	Assembly, Unit Base	20	1113228	Wire Tie (2)	43	488879	Screw, Ground
2	1113386	Assembly, Sound Barrier	21	1108023	Drier	44	653035	Clip, Cord Plug
3	2154923	Compressor (Includes Items 8, 9, 10, 11, 13) (Also Order 876765 Tube Kit)	22	2000358	Mounting Bracket, Motor	45	2001077	Wiring Harness, Unit Compartment
4	1105220	Bracket, Mounting	23	1113081	Motor, Fan	47	2001079	Gasket (2)
5	1105219	Grommet, Bracket	24	2000352	Blade, Fan	Following Parts Not Illustrated and Optional Parts Not Included		
6	1105200	Grommet, Mounting	25	2000351	Orifice, Fan			
7	489334	Screw	26	1113303	Gasket, Orifice	978025		Valve, Access (1/4")
8	2154948	Overload	27	488130	Nut (3)	978026		Valve, Access (5/16")
9	2154452	Terminal Cover	28	489368	Screw, 8 x 1/2 (3)	978027		Valve, Access (3/8")
10	1105222	Strap, Cover	29	486692	Speed Nut	978028		Valve, Access (1/2")
11	1118797	Relay	30	2162044	Defrost Timer	978029		Valve, Access (5/8")
12	2149684	Running Capacitor	31	488911	Screw, 6-20 x 3/8	978030		Valve, Access (3/4")
13	2154949	Starting Capacitor	32	2000645	Sleeve, Condenser	876764		Valve, Access (3/16")
14	1108033	Clamp	33	1113066	Clamp, Tube (2)	REFRIGERANT CHARGE		
15	487869	Screw, 8 x 3/8	34	1113059	Process, Tube	11.5 oz.		
16	1113015	Condenser	35	486194	Screw, 8 x 1/2			
17	943447	Grommet (4)	36	2000853	Cover, Fan			
18	1113019	Clamp (4)	37	1113028	Cover, Condenser			
19	487522	Screw, 8-32 x 5/8 (4)	38	1113076	Extension, Housing			
			39	937360	Service Cord			
			40	2001503	Seal Strip (2)			
			41	1113162	Clamp, Cord (2)			
			42	1113229	Switch, Power Disconnect			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER UNIT AND TUBE PARTS


For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION
1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw, 8 x 1/2
4	1113293	Tube, Connect (Suction)
5	1113209	Tube, Connect (Discharge)
6	1113296	Tube, Flow Divider (2)
7	1113292	Valve, Fluid Control
8	2001727	Tube, Connect (Drier)
9	2000756	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw, 8 x 1
13	2000857	Tube, Discharge
14	2000860	Sleeve
15	2000724	Heat Exchanger
16	2001133	Evaporator
17	2001608	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
23	851095	Strap (7)
25	2001264	Drain Pan
26		Bracket, Drain Pan (L.H.) 1113206 (R.H.) 1113207
27	513942	Dampener
30	1113384	Tube, Connect (Suction)
31	1113297	Tube (2)
32	1113096	Tube, Condenser Inlet

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW AND RESERVOIR PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


AIR FLOW AND RESERVOIR PARTS

For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION
1	2001086	Fan Motor
3	2154800	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw, 8 x 1/2
8	2000618	Motor, Wiring
9	488500	Screw, Ground
11	488366	Clamp, Tube
	489348	Clamp, Nylon
12	2000113	Channel, Wiring
14	2000783	Scroll, Fan
16	488772	Screw, 8 x 1/2
17	2000749	Assembly, Air Duct
18	2000048	Air Deflector, Icemaker
22	1112869	Gasket, Air Baffle
23	1113942	Cover, Air Outlet
25	2000342	Cover, Evaporator
26	2000796	Connector, Meat Pan Duct
27	487539	Screw, 8 x 1/2
28	1112840	Baffle, Evaporator
29	1112853	Diffuser, Air Duct
42		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
45	2001337	Gasket (2) Evaporator Cover
46	2001079	Gasket (2)
47	2001080	Gasket
48	2001081	Gasket

ICEMAKER PARTS

For Model: KSSS48MAX03



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Model: KSSS48MAX03

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	489084	Screw, 8 x 1/2	15	489348	Clamp, Nylon Valve	28	489322	Screw, 10-32 x 49/64
2	2000829	Fitting, Water Tube	16	1113066	Clamp Tube	29	628357	Module Assembly
3	2001087	Clamp, Tube	17	487857	Nut	30	489276	Screw
4	841707	Insert, Tube	18	1113703	Cover	31	627792	Shut Off Arm
5	628379	Clip, Fuse	20	628228	Mold & Heater (Also Order 542638 Silicone Grease)	32	1113403	Harness, Wiring
6	2000392	Wire Clip				33	627915	Bracket
7	2001260	Tube, Water (To Ice Maker)				34	489365	Screw, 8-32 x 27/64
8	1106508	Seal Gasket	21	628258	Motor	35	628366	Module Assembly (Includes Items 21, 29, 41)
9	487627	Sleeve, Nut	22	628356	Cup-Water Fill			
10	2001318	Valve, Solenoid	23	627843	Ejector	37	2000803	Water Valve Mounting Bracket
11	627018	Nut, Compression	24	627788	Ice Striper			
12	227991	Connector, Wire	25	627790	Support	38	2001098	Water Inlet Tube
13	2000837	Water Valve, Harness	26	627796	Retainer Thermostat (2)	41	489136	Screw, (2)
14	2001320	Copper, Water Line	27	627985	Thermostat (Also Order 542639 Cement Alumilastic)	42	857547	Wire Tie
						43	488645	Screw, 8 x 1/2
						100	4317943	Icemaker

PARTS NOT ILLUSTRATED

Illus. Part
No. No. DESCRIPTION

Following Parts Not Illustrated
(Optional Parts Only)

4318637 Front Panel Kit (White)
4318634 Front Panel Kit (Black)
4318640 Front Panel Kit (Almond)
4318643 Front Panel Kit (Stainless Steel)

Black Acrylic
Static Cleaner Part No. 978849

LITERATURE PARTS

LIT2001362 Use & Care Guide
LIT2001672 Energy Label
LIT2000850 Service & Wiring Sheet
LIT628370 Modular Icemaker Service Sheet
LIT2001094 Installation Instructions

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST