


KitchenAid® CABINET PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

48" BUILT IN
REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	9	2006442	Mounting Stud, Grill	29		Hinge (Bottom)
	LIT2006136	Use & Care Guide					2006732	Freezer Side
	LIT2006653	Energy Label	10	2005237	Clip, Wire		2006733	Refrigerator Side
	LIT2005930	Service & Wiring Sheet	11	1112849	Cap, Grommet	30	2004992	Bushing, Adjustable
	LIT628370	Modular Icemaker Service Sheet	13	1113122	Grommet, Wiring			
	LIT2006137	Installation Instructions	14	2006754	Wiring Harness, Cabinet	31	2001415	Screw
			16	488946	Tube, Clamp	33	2004516	Linkage, Door Closure
			17	2005378	Screw, Door Stop	34		Grille Base, Front
2		Cabinet (Not A Serviceable Part)	18	2005295	Hinge (Top)		2004535	White
3	2005004	Grommet, Tube Crossover	20	1112805	Guard, Wiring		2004532	Black
4	1112023	Roller, Front & Rear (4)	21	2004994	Lock, Adjustable Bushing	35	489238	Screw
5		Support, Leveler Assembly	22	2002903	Bushing	36	2004512	Cover, Rear
	2004506	Refrigerator Side	24		Spring, Door Closure	37	2207518	Grommet, Wiring
	2004505	Freezer Side		2004566	Refrigerator Side	39	2006346	Washer
6	2005006	Grommet, Wiring		2004567	Freezer Side	40	2004565	Bushing, Door Closure
7	2005007	Grommet, Flexible	25	486194	Screw	41	1163283	Screw
			26	2005008	Retaining Ring, Adjustable Bushing	42	2150347	Union
			27	1113227	Fastener (3)	43	2001415	Screw (4)
			28	2006342	Gap, Cover Assembly (Bottom)	44	489464	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET TRIM PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	2004668	Cabinet, Trim (2) White
	2005820	Black
	2005730	Biscuit
2	2003857	Screw
3	1163283	Screw
4	2004538	Cabinet, Trim (Bottom)
5	486194	Screw
6	2003647	Cabinet, Trim Top
8	487944	Washer (2)
9	2005925	Seal-Trim, Side

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2005567	Bracket, Light
3	1113650	Lens
4	2005042	Light, Socket
5	548049	Light, Bulb
6	538533	Support Clip, Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw
12	486194	Screw
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support, Evaporator
17	2004068	Stud, Shelf (20)
18	487559	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS


For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
5	2001117	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw
8	486194	Screw
9	1112257	Hole Plug
10	2003579	Meat Pan, Air Duct Cover
11	2000337	Meat Pan, Air Duct
12	2003299	Inlay, Control Meat Pan
13	2001326	Seal, Air Duct
14	1112218	Damper Control, Meat Pan
15	2003811	Control Knob, Meat Pan
16	2003841	Retainer, Knob
17	2004484	Air Baffle Assembly
21	2001146	Seal
22	1116793	Cover, Thermistor
23	1116959	Thermistor
25	2003578	Air Baffle Cover
26	2003577	Guard, Air Return

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR CONTROL PANEL PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	1112642	Control Panel
2	2003303	Inlay, Control Panel
3	2004005	Circuit Board
4	2003842	Control Knob
5	2003841	Retainer, Knob
6	1118894	Switch, Rocker Arm
7	1113137	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	2005566	Shield, Control Panel
11	2005043	Socket, Light
12	548049	Light Bulb (2)
13	486194	Screw
14	2006223	Wire, Light
15	2001141	Channel, Wiring
16	1115375	Clip, Wiring (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER CONTROL PANEL PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	1113627	Control Panel
2	2003309	Inlay, Control Panel
3	1113466	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	1115373	Switch, Rocker Arm
6	1113136	Seal, Control Panel
8	489260	Screw (3)
9	2000153	Hole Plug (3)
10	2005563	Shield, Control Panel
11	2005042	Socket, Light
12	486194	Screw
13	548049	Light Bulb
14	2001974	Channel, Wiring
16	2182112	Knob, Thermostat
17	1115375	Clip, Wiring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


REFRIGERATOR SHELF PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2174404	Frame, Shelf
2	2003377	Glass, Shelf
3	1112006	Reflector, Shelf
4	1113792	Gasket, Glass (2)
5	2179375	Rack, Wine
6	2169933	Egg Bin
7	2006525	Frame, Assembly Meat Pan
8	2164373	Egg Carrier
9	1112247	Cover, Crisper
10	2003380	Glass, Crisper (Includes #9)
11	2000742	Meat Pan, Connector
12	2169935	Cover
14	2006546	Crisper Pan (2)
15	2188212	Roller
16	2174478	Eyelet, Roller
17	2003478	Screw
20	2006531	Meat Pan
23	2002181	Retainer, Glass
25	2003411	Crisper Spacer, Right Side (2)
27	1113169	Stop, Roller
28	2003410	Crisper Spacer, Left Side (2)
29	486194	Screw

FREEZER SHELF PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	2003144	Solid Shelf
2	2003135	Front, Ice Compartment
3	1113638	Shelf, Fixed (2)
	1112052	Shelf, Deep
4	2208196	Basket
5	2003114	Trim, Basket
6		Slide, Basket
	2208198	Right Side
	2208197	Left Side
7	486194	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP GRILLE AND UNIT COVER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1		Top Grille Assembly
	2003718	White
	2005903	Black
	2006397	Biscuit
2	2005549	Cover, Unit
3	486194	Screw
4	2002484	Grille, Bracket
5	2001415	Screw
6		Decorative Panel Assembly
	2003727	White
	2005906	Black
	2006400	Biscuit

Illus. No.	Part No.	DESCRIPTION
7	2005534	Guard, Compressor Wiring
10		Trim, Grille Bottom
	2003616	White
	2005832	Black
	2005764	Biscuit
11		Trim, Grille Top
	2003622	White
	2005829	Black
	2005765	Biscuit


Illus. No.	Part No.	DESCRIPTION
12		Trim, Grille Right Side
	2003602	White
	2005821	Black
	2005732	Biscuit
13		Trim, Grille Left Side
	2003608	White
	2005824	Black
	2005733	Biscuit
14	2003347	Tee Bolt
15	1161548	Lock Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00

(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2003941	Bracket, Motor
2	2155263	Motor, Dispenser
3	2003979	Solenoid Assembly
4	2149100	Guide, Solenoid
5		Slide, Container
	2002720	Right Side
	2002721	Left Side
6	1113169	Stop, Roller
7	2004006	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	983663	Coupling, Motor
10	489478	Screw
12	1113130	Cover, Motor
13	486194	Screw
14	2208908	Ice Container
15	983668	Coupling, Conveyor
16	3400912	Washer
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2160602	Conveyor
28	2196194	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2002728	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
36	2188212	Roller
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
43	2174478	Eyelet, Roller
44	2002724	Front Cover, Ice Container
47	2003478	Screw
99	2160606	Complete Ice Crusher Mechanism Assembly
100	2006543	Complete Ice Container Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2003872	Refrigerator Door Panel (Includes Insulation)
2	939101	Screw Anchor (8)
3	2005329	Hinge Assembly, Top
4	2004520	Spacer-Door, Top
5	489282	Screw
6	2004523	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112542	Gasket Retainer, Top & Bottom
9	2005533	Door Gasket, Magnetic
11		Handle, Door
	2005953	White
	2005956	Black
	2005955	Biscuit
12	2001230	Washer
13	2004549	Door, Spacer Bottom
15		Screw
	2001208	White
	3400878	Black
	3400877	Biscuit
16		Trim (Top)
	2005015	White
	2005841	Black
	2005769	Biscuit
18		Trim (Side)
	2005968	White
	2005971	Black
	2005970	Biscuit
19		Trim (Bottom)
	2003668	White
	2005882	Black
	2005770	Biscuit
20	1113950	Panel, Interior Door
21	1113949	Ladder, Shelf (2)
22	1113948	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw
25	1113955	Gasket
26	2003465	Door, Utility Bin
27	2003132	Door Shelf (4)
28	2165792	Butter Tray
29	2004881	Retaining Ring, Door-Closure
30	2006381	Shelf, Gallon Door
31	2006421	Overlay

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door Panel (Includes Insulation)
	2202548W	White
	2202548B	Black
	2202548T	Biscuit
4	2004881	Retaining Ring, Door-Closure
6	2004524	Hinge, Bottom
7	489282	Screw
8	2005329	Hinge, Top
9	2004520	Spacer-Door, Top
12	1112533	Gasket Retainer, Side (2)
13	1112539	Gasket Retainer, Top & Bottom
14	2005531	Door Gasket, Magnetic
15	486194	Screw (34)
16		Handle, Door
	2005943	White
	2005942	Black
	2005945	Biscuit
18	2004549	Door, Spacer
20		Screw
	2001208	White
	487052	Stainless Steel
21		Trim (Top)
	2005024	White
	2005887	Black
	2005772	Biscuit
23		Trim (Bottom)
	2004671	White
	2005890	Black
	2005773	Biscuit
24		Trim (Side)
	2005963	White
	2005966	Black
	2005965	Biscuit
26	2002840	Panel, Interior Door
28	2003129	Shelf Bin (2)
33	939101	Screw Anchor
34	2208909	Ice Chute

DISPENSER FRONT PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER AND FRONT PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviceable)	20		Lever, Water Dispenser	45		Trim, Front (2)
2	2195051	Strain, Relief		2180268	White		2208919	White
10	2180209	Spring, Torsion		2180270	Black		2208928	Black
11	2196195	Pin		2186852	Biscuit		2208925	Biscuit
12	2180208	Ice Door Mechanism	22	2194719	Spring, Lever	47		Grille, Overflow
13	2180205	Door, Ice	24	2180223	Delay Mechanism		2180323	White
16	489000	Screw	25	2183771	Bracket, Control		2180325	Black
17		Lever, Ice Dispenser	26	2162361	Switch (2)	49		Biscuit
	2180259	White	27	625834	Insulation, Switch		2202571	Overlay, Cover
	2180261	Black	29	2180200	Lamp Holder		2202574	White
	2186850	Biscuit	30	488500	Screw		2202577	Black
18	2202551	Switch Assembly	36	2196199	Wire Assembly	53	487944	Biscuit
19	489000	Screw	37	2180224	Guide, Ice	54	488568	Washer (2)
			40	487052	Screw	55		Screw (2)
			41	3406124	Light Bulb			Front Cover
								Assembly
								(Includes Items
								18, 36, & 49)
							2202568W	White
							2202568B	Black
							2202568T	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


UPPER UNIT PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00

(White)

(Black)

(Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2003398	Assembly, Unit Base
2	2163787	Clip, Compressor Mounting (4)
3	2183420	Compressor (Includes Items 8, 9, 11, 12 & 21) (Also Order 876765 Tube Kit)
4	680975	Washer
6	2163786	Grommet, Mounting
8	2176858	Overload
9	2162358	Terminal Cover
11	1108143	Relay
12	2169137	Capacitor
14	486899	Screw
15	487869	Screw
16	2003392	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw
20	851095	Wire Tie (2)
21	2202581	Drier

Illus. No.	Part No.	DESCRIPTION
23	2208903	Motor, Fan
24	2190685	Blade, Fan
25	2003169	Orifice, Fan
27	489099	Screw (3)
29	486692	Speed Nut
30	2162044	Defrost Timer
31	488911	Screw
32	2000645	Sleeve, Condenser
34	2003011	Process, Tube
35	486194	Screw
36	2003174	Cover, Fan
37	2005535	Cover, Condenser
39	2003381	Service Cord
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	2207479	Wiring Harness, Unit Compartment

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")


REFRIGERANT CHARGE

7.5 oz.
(R-134A)



LOWER UNIT AND TUBE PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


LOWER UNIT AND TUBE PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2000528	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw
4	2003271	Sleeve
5	2002171	Sleeve
6	2002999	Condenser Inlet Tube
7	2003484	Sleeve
8	2003015	Tube, Connect (Drier)
9	2004545	Heater, Drain Pan
10	1113062	Hanger, Heater
11	2005908	Shield, Drain Pan
12	2002448	Sleeve
13	2002995	Tube, Discharge
14	2003272	Sleeve
15	2003003	Heat Exchanger
16	2002966	Evaporator
17	2006751	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
23	851095	Strap
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	Left
	1113207	Right
27	513942	Dampener

AIR FLOW AND RESERVOIR PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW AND RESERVOIR PARTS


For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2188322	Fan Motor
2	2002732	Cup, Clearance
3	2169142	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw
8	2003926	Deflector, Air Duct
9	488500	Screw, Ground
10	488366	Clamp, Tube
11	489348	Clamp, Nylon
12	2001145	Channel, Wiring
13	1112871	Fastner
14	2000783	Scroll, Fan
15	2003929	Deflector, Air Duct
17	2208902	Assembly, Air Duct (Also Order Items 8 & 15)
18	2182146	Duct, Icemaker
22	1112869	Gasket, Air Baffle
23	2003576	Cover, Air Outlet
25	2202598	Cover, Evaporator
26	2000796	Connector, Meat Pan Duct
27	487539	Screw
28	1112840	Baffle, Evaporator
29	1112853	Diffuser, Air Duct
30	2006145	Reservoir
31	488280	Screw
42		Evaporator, Cover Rail
	2000686	Left Side
	2000685	Right Side
45	2001337	Gasket (2) Evaporator Cover
46	2001079	Gasket (2)
47	2001080	Gasket
48	2001081	Gasket

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSSS48QHW00, KSSS48QHB00, KSSS48QHT00
(White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
4	841707	Insert, Tube	20	628228	Mold & Heater (Also Order 542638 Silicone Grease)	30	489276	Screw
5	628379	Clip, Fuse				31	2171593	Shut Off Arm
7	2208933	Water Inlet Tube Assembly				33	2171952	Bracket
8	1106508	Seal Gasket	21	628398	Motor	34	489478	Screw
9	2154472	Connector	22	628356	Cup-Water Fill	35	628399	Module Assembly (Includes Items 21 & 41)
10	2003791	Valve, Solenoid	23	2194711	Ejector			
11	627018	Nut, Compression	24	2182124	Ice Striper	36	2185988	Fitting, Water Tube
12	227991	Connector, Wire	25	2194712	Support	37	2004914	Water Valve Mounting Bracket
13	2006738	Water Valve, Harness	26	627796	Retainer Thermostat (2)	41	489136	Screw (2)
14	1129177	Insert, Tube	27	627985	Thermostat (Also Order 542639 Cement Alumilastic)	43	486194	Screw
15	489348	Clamp, Nylon Valve				44	1129179	Compression Nut
16	488946	Clamp Tube				100	4317943	Complete Icemaker Assembly
18	2174155	Cover	28	489322	Screw			

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated
(Optional Parts Only)

4378652	Front Panel Kit (White)
4378655	Front Panel Kit (Black)
4378658	Front Panel Kit (Almond)
4378661	Front Panel Kit (Stainless Steel)
4392888	Front Panel Kit (Biscuit)

Black Acrylic
Static Cleaner Part No. 978849