



BLUETOOTH SPEAKERS

PBT626X2 | USER MANUAL



Questions?
Need some help?
This manual will help you
enjoy your new product.



If you still have questions,
call our help line:
1-877-768-8481




or visit us at:
www.southerntelecom.com
Click on "Product Support"

IN THE BOX



Bluetooth Speakers



User Manual



Micro USB Charging Cable




Mini USB Connecting Cable




3.5mm Auxiliary Cable

LOCATION OF CONTROLS




1. Micro USB DC 5V charging port
2. AUX IN jack
3. Mini USB connecting port
4. ON/OFF switch



5. Mini USB connecting port

CHARGING THE SPEAKER

1. Connect the small end of the Micro USB Charging Cable to the Micro USB DC 5V charging port on the back of the Main speaker.
2. Connect the other end of the Micro USB Charging Cable to the USB port on your computer or other device made for USB charging.
3. The LED light is RED when charging. It will shut off when the speaker is fully charged.
4. Make sure you charge the Main speaker for at least 8 hours before using the speakers for the first time.



There is no need to charge the Sub speaker as it will be powered by the Main speaker once they are connected with the Mini USB connecting cable.


USING THE SPEAKERS

Powering ON/OFF

- Slide the power switch on the back of the main speaker to the ON or OFF position.
- Check that your Bluetooth features are turned ON. If you have already paired the speaker with a Bluetooth enabled device, it will automatically connect.
- If you are using the speakers for the first time, go to the "PAIRING THE SPEAKERS" section of this User Manual, and pair the speakers to your desired Bluetooth device.

Connecting the speakers

1. Plug one end of the Mini USB connecting cable into the Mini USB connecting port on the Main speaker.
2. Plug the other end of the Mini USB connecting cable into the Mini USB connecting port on the Sub speaker.




PAIRING THE SPEAKERS

1. Slide the power switch on the back of the main speaker to the ON position.
2. Connect the two speakers with the Micro USB connecting cable.
3. A tone will be heard, indicating that the speaker is in pairing mode.
4. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.
5. Set your Bluetooth enabled device to search for Bluetooth devices.

If there are no paired devices in range when the speaker is turned on, it will go into pairing mode automatically. If a paired device is in range, the speaker will connect to it automatically.

On an iPhone


- Go to SETTINGS > BLUETOOTH (Make sure Bluetooth is turned ON)



PAIRING THE SPEAKERS (cont'd)


On a Blackberry

- Go to SETTINGS/OPTIONS > BLUETOOTH
- Enable BLUETOOTH



On an Android Phone


- Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)



PAIRING THE SPEAKERS (cont'd)

On other Cell Phones/Devices

- Review the instruction manual that came with your phone/device.



6. When the Bluetooth enabled device finds the speaker, select "PBT626X2" from the list of found devices.
7. If required, enter the password 0000. Select OK or Yes to pair the two units.
8. After a successful registration, a beep will be heard.

NOTE: If you would like to connect the speakers to another device, you must unpair the speakers from the currently paired device first. On your device's Bluetooth settings, select "PBT626X2" then select "unpair". When the speakers have been unpaired, they automatically go into pairing mode again.

The screenshots above are typical of many Bluetooth enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth enabled device's interface and interaction with the Bluetooth Speakers may slightly differ from the illustrations above.

PLAYING MUSIC

To enjoy wireless music on your Bluetooth Speakers, make sure you are connected to a Bluetooth enabled device. Once connected press PLAY on your Bluetooth device. When playback has begun, control the music with your connected device (that has the AVRCP Bluetooth profile).

NOTE: To enable the dancing water feature, you must turn up the volume of your connected device.

USING AS WIRED SPEAKERS

1. Turn the Main speaker ON.
2. Connect one end of the included 3.5mm auxiliary cable to the AUX IN jack on the speaker and the other end to an external device's headphone jack (smartphone, tablet, or MP3 player).
3. Open a media player on your device and click on PLAY to start playing your music.
4. Use the controls on your connected device to control music playback and volume.

Connecting the audio cable will override Bluetooth mode. When the cable is disconnected, the speaker will automatically reconnect to the last paired device.

TROUBLESHOOTING

I can pair the Bluetooth Speakers with my Bluetooth device, but I cannot hear any music.

1. Make sure your Bluetooth device supports A2DP profile.
2. Turn up the volume on your Bluetooth device.
3. You may have to unpair the speaker, then re-pair to your device.

My Bluetooth device is not able to pair with the Bluetooth Speakers.

1. Make sure the Main Bluetooth Speaker is turned ON before beginning the pairing process.
2. Keep your Bluetooth Speakers and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. The speaker will emit a tone to indicate that it is in pairing mode.
4. Check that YOUR device's Bluetooth feature is turned ON.
5. Try repeating the pairing process, see "Pairing the speaker."
6. Make sure that the Main speaker is fully charged.

TROUBLESHOOTING (cont'd)

I cannot get the Bluetooth Speakers into pairing mode.

1. Make sure the Main Bluetooth Speaker is turned ON before beginning the pairing process.
2. The speaker will emit a tone indicating that it is in pairing mode.

WARRANTY

This product as supplied and distributed new by AIT, Inc. ("AIT") to the original consumer purchaser is warranted by AIT against defects in material and workmanship for a period of one year from your date of purchase ("Warranty").

- TO OBTAIN WARRANTY SERVICE:**
- Call the Customer Support number located below, or go to our website portal to receive an SRQ number.
 - Provide proof of the date of purchase within the package (Dated bill of sale).
 - Prepay all shipping costs to the authorized service center, and remember to insure your return.
 - Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
 - Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

AIT, Inc.
AITN Customer Service (2nd Floor)
14-C 63rd Street
Brooklyn, NY 11232

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY.



Questions?
Need some help?
This manual will help you
enjoy your new product.



If you still have questions,
call our help line:
1-877-768-8481



or visit us at:
www.southerntelecom.com
Click on "Product Support"