I. Introduction


Thank you for purchasing the Belkin Universal AC Travel Adapter. This innovation makes it convenient for you to connect your devices to virtually any AC power source in the world — without adding country-specific adapters.

The Travel Adapter from Belkin includes our patented, integrated World AC Plug that works in many countries the world over, including: England, Europe, North America, South America, China, Asia, Australia, and New Zealand.

II. Operation Instructions

(North America)

 Locate the button/latch at the base of the Travel Adapter where the North American and Australian plugs are embedded (see illustration).



2. Press the release button that frees the North American/Australian plug

from its embedded position. Continue to push the North American plug upward until it locks into a 90-degree position.

CAUTION: For safe and proper use, make sure that the North American plug locks into a 90-degree angled position. If, for some reason, it does not lock into place, do not use the Adapter. Return it to your purchase location in the original packaging.

3. You may now plug any portable device from around the world into the open slots provided on the side opposite of the North American, Australian, UK, and Euro plugs.

(Australia/New Zealand)

 Locate the black button/latch at the base of the Travel Adapter where the North American plug is embedded.



2. Press the release button that frees the North American plug from its embedded position. Continue to push the North American plug upward until it locks into a 90-degree position.


CAUTION: For safe and proper use make sure that the North American plug locks into a 90-degree angled position. If for some reason it does not lock into place, do not use the adapter. Return it to your purchase location in the original packaging.

- **3.** Twist the North American plug on the left side in a clockwise direction until it reaches a 45-degree angled position. Twist the North American plug on the right side in a counter-clockwise direction until it reaches a 45-degree angled position.
- 4. Insert the North American/Australian plug into the wall outlet.

(Europe/Asia)

1. Locate the Euro plug on the same side as the North American plug. Grasp the end of the Euro plug and pull it up until it locks into a 90-degree angled position.

CAUTION: For safe and proper use, make sure that the North American plug locks into a 90-degree angled position. If for some reason it does not lock into place, do not use the Adapter. Return it to your purchase location in the original packaging.



2. Insert the Euro plug into the now-opened power socket on the wall outlet.

(United Kingdom)

 Locate the Euro plug on the same side as the North American plug. Grasp the end of the Euro plug and pull it up until it locks into a 90-degree angled position.

CAUTION: For safe and proper use, make sure that the North American plug locks into a 90degree angled position. If for some reason it does not lock into place, do not use the Adapter . Return it to your purchase location in the original packaging.



- 2. Pull the UK key from its position on the side of the unit.
- **3.** First insert the UK key into the ground socket of the wall outlet. This action will open the two top power sockets. Now insert the Euro plug into the now opened power sockets on the wall outlet.
- You may now plug any portable device from around the world into the open slots provided on the side opposite of the North American, Australian, UK, and Euro plugs.

NOTE: When you have completed your work on your computer reattach the UK key to the iAdapt power cable.

NOTE: This unit does not convert voltage.

III. Certifications

• CE

IV. Specifications

Dimensions: 63.5 (L) x 49 (W) x 40.5mm(H) Weight: 60g Input Voltage: 100 to 240 VAC



User Manual F8F449

CE Declaration of Conformity

We, Belkin Corporation, declare under our sole responsibility that the F8E449, to which this declaration EN 55024 and LVD 1998.

Belkin Components Limited Lifetime Product Warranty

Belkin Components warrants this product against defects in materials and workmanship for its lifetime. If a defect is discovered, Belkin will, at its option, repair or replace the product at no charge provided it is returned during the warranty period, with transportation charges prepaid, to the authorized Belkin dealer from whom you purchased the product. Proof of purchase may be required.

This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication; if the product has been modified without the written permission of Belkin; or if any Belkin serial number has been removed or defaced.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED. BELKIN SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE

No Belkin dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

BELKIN IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH BELKIN PRODUCTS

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusions you specific legal rights, and you may also have other rights that vary from state to state.



belkin.com

Belkin Corporation 501 West Walnut Street Compton • CA • 90220 • USA Tel: 310.898.1100 Fax: 310.898.1111

Belkin Components, Ltd.

Express Business Park Shipton Way • Rushden • NN10 6GL United Kingdom Tel: +44 (0) 1933 35 2000 Fax: +44 (0) 1933 31 2000

Belkin Components B.V.

Starparc Building • Boeing Avenue 333 1119 PH Schiphol-Rijk • The Netherlands Tel: +31 (0) 20 654 7300 Fax: +31 (0) 20 654 7349

Belkin Components, Ltd. 7 Bowen Crescent • West Gosford NSW 2250 • Australia Tel: +61 (0) 2 4372 8600 Fax: +61 (0) 2 4372 8603

Tech Support US: 310.898.1100 ext. 2263 800.223.5546 ext. 2263 Europe: 00 800 223 55 460 Australia: 1-800-666-040

Plug							÷											÷											
Socket											o															(BELKIN			
Code		A.D.		A	A.D.	A	A	A.B.	A	A	A	B.D.	B.D.	В	A.B.	A.B.	В	А	A.D.	A.B.D.	А		B.D.	B.D.	D	В	B.D.	D	B.D.
Volt	North/South America	120	120	120/240	120	120	120	110/220	115	110	120	220	220	220	127/220	220	220	110/115/220	110/220	110	110	ica	220	240	230	115/127/220	230	230	220/230/250
Ηz	orth/Sou	09	60	09	90	09	09	50	60	90	09	50	50	50	60	60	50	60	09	60	p. 60	Africa	50	50	50	50	50	50	50
Country	Ž	Canada	U.S.A.	Alaska	Costa Rica	Nicaragua	Venezuela	Bolivia	El Salvador	Colombia	Guatemala	Argentina	Uruguay	Paraguay	Brazil	Peru	Chile	Panama	Belize	Cuba	Dominican Rep.		Egypt	Kenya	Zambia	Morocco	Mauritius	Nigeria	R.S.A.
Code	J	A		В	в	ш	в	В	B.C.	В	В	ш	В	В	В	В	в	В	A.B.	В	В	в	В	ш	A.B.	В	C.D.	D	
Volt	240	127	be	220	127/220	120/220	220	127/220	127/220	220	220	220/230	220	220	220	220	220	220	127/220	220	220	220	220	127/220	127/220	220	240	240	
Ηz	50	50	Europe	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	
Country	Fiji	Tahiti		The Netherlands	Belgium	Luxemburg	West Germany	East Germany	France	Denmark	Finland	Norway	Sweden	Switzerland	Austria	Hungary	Czechoslovakia	Poland	U.S.S.R.	Rumania	Bulgaria	Yugoslavia	Greece	Italy	Spain	Portugal	England	Malta	
Code		A	В	A.B.C.D.	В	A.B.C.	A	A.B.C.	A.B.	D	В	D	B.D.	A.B.D.	В	В	В	В		B.D.	B.D.	B.D.	В	B.D.	A.B.D.	B.D.		С	С
Volt	ia	110	200	110/200	115/127/220	100/220	100	115/200	120/220/230	230	127/230	240	240	220	230	220	230	220/230	e East	e East 220	220	220	220 240	240	127/220	220/230/240	& Nz	240/250	230
Hz	Asia	09	50	50	50	09	50/60	09	50	50	50	50	50	50	50	50	50	50	Middle East	50	20 20	50	50	50	50/60	50	A.A. & Nz	50	50
Country		Taiwan	Hong Kong	Mainland China	Macao	Korea	Japan	Philippines	Vietnam	Singapore	Indonesia	Malaysia	Brunei	Thailand	India	Nepal	Bangladesh	Pakistan		Jordan	Iran	Iraq	Turkey	Kuwait	Saudi Arabia	U.A.E.		Australia	New Zealand

© 2002 Belkin Corporation. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. P74195