



singtrix

A FEW
QUICK TIPS
& **TRIXS** TO GET YOU **SINGING** LIKE A
ROCKSTAR!



Singtrix® uses the same powerful vocal effects that the pros use and is designed to sound amazing when properly setup and the music and vocal volume mix set to optimal levels.

With Singtrix fully assembled, connected to your music device, and powered on, you're ready to start!

Setting Your Volume Is The Most Important Step!

Leave your Singtrix Studio at the default volume settings. The Speaker controls your overall mic volume and your music device controls the music mix. Start with the Speaker Volume, Treble and Bass set between 2 and 3 o'clock positions and sing into the mic. With your music device volume at 30%, play your music and slowly raise the music device volume while singing to achieve the ideal balance between the mic and music. Always adjust the music mix level from your music device ONLY and NOT at the Speaker or Studio. If you can't hear your voice well, turn down the music device volume. Raising the music device volume above 70-80% can cause distortion and will make it difficult to hear your singing over the music.

Where Do I Get My Karaoke Music?

Plug in any music device with a headphone output including smart phones, tablets, mp3 players and computers. For FREE karaoke tracks, log into YouTube® using your web browser and search "Karaoke" plus name of any song or artist for thousands of free karaoke videos or lyrics videos. As a secondary option, if you already know the words to your existing mp3 music library, use the "SONG VOICE" feature to lower vocals in standard songs to create karaoke tracks on the fly. Singtrix also works with some third party karaoke apps so the options are endless.

So Many Presets, So Little Time!

Start off with Preset #1, "BIG TRIO" and see how you sound. The MY VOICE button on "ENHANCED" will offer the highest levels of effects & pitch correction for that preset. Presets 1 - 15 are the best for beginners to get started! Need even more pitch-correction? Try using any preset with the word "TUNED" in the name. The Song Effects are more authentic but some can be harder for beginners.

As you start experimenting with other presets and skill levels, spin the effects dial quickly in any direction, you can jump 70-100 effects with 1 spin. Download our Preset Guide for more recommendations.

Vocal Tips: Belt It Out And Let Singtrix Do The Rest!

Singtrix sounds best when you "commit" to a song and try to hit those notes, even falsetto. Project your voice, not matter how off it may sound. Sing! However to avoid distortion and straining, do not scream. Singtrix makes your voice sound rich and full even when singing softly but projecting. Always start your Trixing™ sessions with easy songs in your natural range, to properly warm up. If you don't know your natural range, that's okay, just let it out and Singtrix will help. After singing a few songs, your voice and pitch will naturally improve. To really experience the full sound of our amazing vocal effects in stereo, try using headphones!


Want To Get The Most Out Of Your Singtrix?


Visit our Support Page on www.singtrix.com. Check out the "HOW IT WORKS" video for features and operation tour. The "UNBOXING & SETUP" video provides an informative view of the box contents and detailed set up information. The FAQ section provides answers to the most common customer questions, along with quick tips and troubleshooting.



***PARTY BUNDLE
SETUP REFERENCE GUIDE***

INPUT ► SINGTRIX ► OUTPUT







AC Power Adapter

RCA Speaker Input



THE MOST IMPORTANT STEP!

Setting the volume mix between the microphone and music track is the **MOST** important step. This will ensure that Singtrix performs properly & optimally.

Singtrix is a pure audio experience. Improper mix levels will cause distortion, low sounding vocals, weak mic dynamics, and overall poor quality sound & performance.

The goal is to have relatively equal volumes between your microphone voice and music track. **ONLY** use the volume adjustment on your Music Device (PC, smart phone, tablet etc.) to set the relative music volume mix to your mic volume. **DO NOT** use the studio unit's mic volume for this.

NEVER attempt to raise your Music Device's volume to achieve a louder overall performance. This will cause your vocals to be lower relative to the music & distort. To adjust overall performance volume, always use the volume controls on the speaker amplifier. This guide highlights the proper procedure in a few simple steps....



**Adjust Music/Mic Mix – Use
Volume on Your Music Device**



VS



**Overall Performance Volume – Use
Volume on Speaker Amp**



STEP 1

- A. After complete assembly as per the user's manual, check that ALL cables are connected and FULLY inserted into the proper inputs and outputs.**

Firmly press on all connections!

NOTE: Sometimes new cables are stiff and feel like they are fully inserted but are not. This is a common oversight made by many users. Improper connections will cause noise, feedback static and other performance issues (including vocal-tuning accuracy or pitch-correction problems).

- B. Power "ON" the Studio Console**



STEP 2

- A. Power “ON” the Speaker
- B. Start with the **VOLUME, BASS** and **TREBLE** knobs to 75% or 3 o’clock. This establishes your overall volume.

NOTE: The speaker needs to be loud for optimal performance and to hear your effected voice over your real ambient voice. You can fine-tune these settings later.



- C. Test by singing through the Singtrix Mic using preset “1) BIG TRIO”. *Do not play your background music yet!*

You should hear your voice loud and clear. Try the “HIT” Button on the mic or Studio Console to hear your vocal harmonies.



You can use headphones or other speaker/PA systems connected to the Studio Console speaker output. When using headphones, use the Studio Console Main Volume to set headphone levels. When using external speakers with amplifiers, like the Singtrix Speaker or PA system, keep the Studio Console Main Volume at default levels and adjust your overall performance volume on the external speaker amplifier. NEVER use your music device volume to increase overall system volume.


STEP 3


- A. With your Music Device (PC, tablet or phone) connected, lower your device's volume to approximately  30% before playing.
- NOTE:** If you play your Music Device at 100% volume, the signal going to the speaker will be too loud, distort and result in an improper vocal mix.
- B. Using YouTube™ on your device's web browser, search “KARAOKE” plus name of any song or artist. There will be thousands of FREE YouTube karaoke tracks.
- C. Play the karaoke track and slowly raise your Music Device  volume while singing to set the desired music/vocal mix. The louder the music, the more each effect (delay, reverb, harmonies etc.) will blend with the background track. Lower music volumes will result in more prominent sounding effects.

Computer



Smart Phone / Tablet



 Always adjust the music mix level from your Music Device ONLY and NOT at the Speaker or Studio. If you can't hear your voice well, turn down the Music Device volume. Raising the Music Device volume above 70-80% can cause distortion and will make it difficult to hear your singing over the music.

You can use your own music library, karaoke apps and other music sources. 95% of customers use YouTube.



YOUR FIRST SINGTRIX SESSION



Always start your “trixing™” sessions with easy songs in your natural range, to properly warm up your voice. After singing a few songs, your voice and pitch will naturally improve.

- Singtrix strengthens the sound of your natural voice. Sing softly using falsetto (your higher voice) to reach higher notes without straining.
- Your singing technique and note accuracy will greatly improve by just “singing” with Singtrix. Singtrix will naturally help make you a better singer!
- For best system performance & accurate pitch correction, ALWAYS use high-fidelity music with a quality audio device and quality audio cables.




Yes, Singtrix has A LOT of effects presets! Get familiar with “core universal fx” 1-15 first. They are most versatile and will work with most songs. You will find “favorites” based on the unique tone and range of your voice, and the types of songs you prefer to sing.

- Start by singing your favorite song with preset “**1) BIG TRIO**”
- Press the MY VOICE button and test the “enhanced”, “semipro”, and “pro” skill levels.
- For the most pitch correction possible, try “**14) TUNED TRIO**” or other fx presets named “tuned _____”.

Preset effects are dynamic and will sound & feel differently in the context of different songs. Try “re-mixing” a favorite song using different preset & song combinations (e.g. “TUNED DUO” with a Classic Rock song).

- Enhanced song-styled presets with hard tune™ and big delays or reverbs will be easiest to use.
- Song-styled presets will sound great when used for songs in different genres.
- If using a PC or home theater system, disable all audio enhancements (like surround sound). Use a standard stereo output signal, not a digitally enhanced signal in your device’s audio settings.
- If pitch correction is too dominant for a song, use the MY VOICE button and switch to semi-pro level, or use the preset bank 30-37 named “semipro” (e.g. **SEMIPRO TRIO**).
- Don’t forget to print extra copies of the preset list for parties-download from our Support Page at singtrix.com.



As you improve and become more comfortable singing your favorite songs, challenge yourself by using each preset’s semi-pro and pro skill levels.

- Slightly increasing the mic volume level, allows for softer singing while maintaining good dynamics & tone control - make sure to sing further from the mic.
- One preset such as “**1) BIG TRIO**” can be used for an entire session. As you find cool presets, save them to your 1-10 favorites (hold the MIC VOLUME button down for 5 seconds) and also mark other favorites in the preset effects book.

www.singtrix.com

Go to [singtrix.com](http://www.singtrix.com) for technical support for answers to many common questions, downloads including preset guides, and links to a variety of videos including setup and independent customer video posts and demos.

Singtrix YouTube Channel: <https://www.youtube.com/user/singtrix>

- **User Posts – Friends & Fans Playlist:**
https://www.youtube.com/playlist?list=PL_3dlGnPgUZiud5j7mgbbmzkQYOO6geK4
Check out customer performances and see what songs and presets everyone is using

Singtrix.com Support Page: <http://www.singtrix.com/pages/support>

- **Quick Start Video:** <https://www.youtube.com/watch?v=0unrtD22w38>
- **Unboxing & Assembly Video:** <https://www.youtube.com/watch?v=NSnubfVZLSA>
- **Preset Effects Booklet** – offers a guide to usage and effects characteristics for universal and extreme presets. It will also make it easier to navigate and select from the entire list of 300+ effects. Download and print copies from our site.
- **Quick FAQs** – more detailed features and options on our support page
 - Most users will use 2-5 different presets for all their singtrix sessions. There is no right and wrong preset-song combination. Everyone has different tastes. Select the ones you think sound good with your voice and music you enjoy. Experiment and have fun!
 - Save 10 presets to the favorites bank – press and hold the MIC VOLUME button for 5 seconds
 - Using an instrument or with a live band - If you connect a live instrument to the "music in" input, press the SONG VOICE and MY VOICE buttons at the same time for 5 seconds. It will remove the latency/Audio delay. More details on our Support page.
 - Singtrix can be used with other mics. Recommendations for using wireless and other mic systems on our Support page.



More Resources

VOXX Tech & Warranty Support

HOURS

9-5 EST (Mon-Fri)

CUSTOMER PORTAL

Create a customer account and log in for real-time support & incident tracking

<http://voxrightnow.custhelp.com/app/home>

Toll Free (800) 645-4994