



## Spy Loud Earpiece

Spy loud earpiece produces loud voice compared with other models. It has compact size and full skin color.

**Package list:**  
It includes one pc TE07 spy loud earpiece, 1 pc button battery hidden in the sponge. It is packed in the Skin box with golden sticker.



TE07 Earpiece



Button Battery

### Quick Start:

#### Step 1> Load battery into the earbud

1). Open the plastic earpiece box and press the sponge, you will find the battery. Cut the sponge and take it out.

Open the battery hook and make sure cathode face to handle and anode opposite to handle. Then close the battery case.



**\*Note:**

After loaded battery, earpiece starts work.  
Do not load battery in wrong direction.  
If the battery is loaded wrongly, the battery case will broken or battery gets stuck inside the earpiece.

2). Put the small earpiece into ear canal carefully. It should be worn deeply in the ear canal. Please refer to the right photo.

#### Step 2> Wear Earpiece


- 1) Clean ear canal by cotton swab.
- 2) Load earpiece into ear canal horizontally for maximize signal reception. Handle is better in down position for easy take out.
- 3) Put earpiece into canal deeply until its invisible.  
Please take out earpiece and unload battery if stop use it.



### Maintenance:

Wireless earbud is high-tech electrical device. Please operate and maintain carefully.

**\*Note:** Please check wax filter in front end termly. If wax is full, please use cleaner to pickup the wax. The cleaner is not included. You should buy it separately.



### FAQ:

Q: There is no sound from the earpiece.  
A: Please check if the battery is loaded correctly.

Q: Why I can hear little static noise?  
A: It's normal to hear some static noise. It means the earbud is under working status.

Q: Why I hear loud "zzz" noise?  
A: The battery is running of power. Please change to a new button battery.

Q: The Volume is low. What should I do?  
A: Please check if wax filter is full. Please adjust the volume of cellphone and neckloop.

Q: The battery life is very short.  
A: Please use brand new high quality button battery. After using it, please take the battery out of the battery compartment.

