Universal Media Interface (UMI)

The Universal Media Interface (UMI) it is designed to provide USB portable media interconnect to the car.

Features:

- iPod/iPhone Media Support
- Portable Media Player Support
- Mass Storage Device Support
- Bluetooth Stereo Audio Streaming
- Text to Speech interface
- Bluetooth Hands free Interface
- Phone Device Interface
- USB Charging Support

Decoding: MP3, Ogg Vorbis, iTunes

<u>Post-processing:</u> SRS WOW, Digital 5-band EQ, Bass Boost



USB Host Interface



Quick USB Start Guide



The USB media player is available by choosing the CDC Menu from the Audio options in the Mercedes Head Unit



If there is no USB media device connected to the USB connector the screen shows "No Media" message



When USB flash media is connected the device is indexing the folders and the screen shows "searching..." for short time before start playing



After the indexing is completed the play starts automatically from the first song on the list indexed

To change folders press 2 from the phone keyboard and the screen will show you the folder names you can scroll with SEEK+ and SEEK-




To select a folder press and hold SEEK+, if there is no selection the screen will timeout to the current song playing



Pressing "Magaz." button will show the current folder and the available functions assigned at the first 6 buttons from the phone keyboard





Universal Media Interface

Quick Phone Installation Guide


To pair a phone to the HU choose option 6 from the CDC screen that will go to a Bluetooth menu screen as below



If press and hold SEEK+ it will go to the Bluetooth pairing sub menu where different pairing options are available



Scroll with SEEK+ or SEEK- to select the right action from the available choices to either pair new device or delete all and pair a device



Scrolling further on a sub menu level the current version of the Bluetooth software is shown



To pair new device select "Pair New Device" tab and press and hold SEEK+ until the menu screen changes and hear the voice confirmation



The voice will prompt to enter the access code for the Phone device then pairing will be finished when voice confirms "Phone connected"



The pairing process is similar with the "Delete all & pair" tab except it will delete the list of all paired devices available in the unit



The list of all paired devices is available at the Bluetooth menu level together with a "Settings Menu"



Placing a call is as same as using the original Mercedes Phone kit by selecting the Phone tab and dialing the number from the numeric keyboard



To dial type the number and then press SEND, on the bottom right screen corner the phone field strength is shown and a phone ready message



There will be a voice confirmation reading the number when dialing then the phone call will be routed through the car speaker system



Universal Media Interface

Quick iPod/iPhone Support Guide

Connecting an iPod/iPhone device shows "Searching.." while indexing the media and starts playing the first song in the default playlist



Pressing "Magaz." shows all categories available for selection via the phone keys 1-6 as in the iPod connected



To change category select the corresponding phone key and the category will take place on the upper screen tab then scroll via subcategories



To select press and hold SEEK+ button then the first song from the selected category will take place at the lower tab while playing




Pressing "Scan" tab will go to another item from the same category



Pressing "Detail" tab will show the song name for the song currently playing



Choosing "Setting" tab will allow a function selection for track playing sequence as mix or repeat of the track or the CD



In the "Magaz." tab the selected category will be shown at the category list with a : <name>



Sound controls are accessible via the three tabs at the right side of the head unit display



If the playlist has more than 99 songs the songs will be shown as 99 per page and to select page up use SEEK+ or page down SEEK-



The page tab is located at the position of the last song and to select page up use SEEK+ or page down SEEK-



Installation Instructions

NOTE:

UMI replaces the CD Changer in the MOST network. After the installation the CD changer optical connection is not connected anymore.

Step 1

First remove the ashtray and the CD Changer to allow access to the head unit. Remove all electrical connectors and slide out the navigation screen to allow easy access to the back.






Step 2

On the **CD Changer** harness lift the lock tab gently and pull the insert out of the housing.

Step 3

Take the **UMI connector** housing from the kit and plug back the inserts with the leads into the **UMI connector**.




Step 4

Crimp the black wire to ground and the red wire to 12V Battery Power off the CD changer harness.


Step 5

Remove the white optical dust protector from UMI optical connector and insert it into the CD Changer optical MOST connector to protect from dust and contaminations.



Step 6

Connect the MOST and the Power plugs to the rear **UMI** panel.



Step 7

Connect the USB and the microphone plugs to the front panel of the **UMI.**

Step 8

Pull the decorative edge and wire the microphone from the UMI to the right side of the dash panel.

Note: avoid installing the microphone in the dash cavity to prevent eco effect.



Step 9

Install UMI behind the navigation screen horizontally and slide the screen back to its position. Be sure that no wires stand in between.



Secure the navigation screen, the decorative edge and the CD Changer in their original positions. Plug back all electrical connectors to power the CD Changer panel.

Step 11

Install the USB receptacle to extend to the glove box or the ash tray using the grommet included in the kit.




Step 12

You may also use the special USB grommet for panel installation as shown.

Step 13


Insert the ashtray back and lock it to its original position. Now you can power the head unit and follow the User Guide for operation instructions. You will find the UMI at the CDC menu and the Bluetooth hands free and A2DP at the TEL menu.





Quick Software Upgrade Procedure

Extract the umia2m.bin file if archived and copy it to the top directory of USB flash drive as shown below.



Power the head unit and make sure that the media interface is running and can be found into the Audio CDC menu as shown below:



Plug the USB flash drive in the USB connector and the update will proceed immediately. It takes about 30 seconds until the screen refreshes:



Disconnect the USB drive and power down the head unit. Wait for about 30 seconds and power up again so the new configuration take effect:



To pair the phone go to CDC 6 selection and enter in More menu where the Bluetooth menu is displayed by default:



The software version can be verified from the Settings menu which is next after the Bluetooth men selected with Seek+ key push:



Press and hold Seek+ enters into the Settings menu and by default displays the current software version loaded in the device:



Press and hold Seek— returns back. To pair a phone select Bluetooth menu with Seek+ which will change to Pair New Phone menu:



Select Pair New Phone while hold Seek+ and message will say: "Please select the hands-free device from mobile phone and enter pin code ..."



Finish pairing by entering the default pin code "0000" or cancel the process. Paring completes with the announcement "Phone connected":



It takes about a minute for the phone book to upload in the telephone menu and enable the Dialed, Received and Phone Book tabs.



Quick Phone Pairing Procedure

Power the head unit and make sure that the media interface is running and can be selected from the Audio CDC menu as shown below.



To pair the phone go to CDC 6 selection and enter in More menu where the Bluetooth menu is displayed by default:



To pair a phone select Bluetooth menu press and hold Seek+ which will change the menu to Pair New Device:



Pair New Device by press and hold Seek+ and message will say: "Please select the hands-free device from mobile phone and enter pin code ..."



Finish pairing by entering the default pin code "0000". Paring completes with the announcement "Phone connected" and shows the signal bars:



Another phone can be paired from the same menu. The active phones can be switched by selecting their name in More (CD6) menu:



Selecting the phone tab will open the phone screen that will allow number dialing as the originally installed Mercedes phone would operate:



It takes about a minute for the phone book to upload in the telephone menu and enable the Dialed, Received and Phone Book tabs.



Select Phone Book icon will display phone book records alphabetically by name. Switching between letters A..Z and up/down is via joystick:



Selecting 123 tab switches the Phone Book display by phone number. The phones are identified by icon for work, home or cell number:



Selecting the Audio tab the control returns to Media player mode operated with the CD 1-5 keys for Playlist, Album, Artist, Genre and song modes:



DIP Switch Settings - Device Configuration Modes

Find the configuration switch on the rear right side of the panel by the MOST optical plug.




Unplug the device and configure the settings when the unit is not powered. Then reconnect and power the unit.


Switch	Mode	Description
Det 1 2 5 i	Media Only	USB and Wireless Media with no Phone installed
DIT 1 2 3 1	Full Featured	USB and Wireless Media with full Phone support
DIT 1 2 3 1	Wireless Only	Wireless Media, Phone support and USB charging
Off 1 2 3 4	Phone Only	Wireless Phone Support with CDC installed

The table above shows the configuration option applicable to the available hardware


- USB Media Player and iPod/iPhone iAP interface
 (A2DP) BT Audio Streaming and Media Controls
- USB Accessory Charging




- USB Media Player and iPod/iPhone iAP interface
- (A2DP) BT Audio Streaming and Media Controls
- Phone Menu Support and Phone Book Download



- (A2DP) BT Audio Streaming and Media Controls
- Phone Menu Support and Phone Book Download
- USB Accessory Charging



- Phone Menu Support and Phone Book Download
- USB Accessory Charging



In mode with CDC installed the pairing procedure is via the phone touch keyboard.




To pair dial "PAIR" <SEEK+> from the number keyboard or 7274 <SEEK+>.

Alternative command is "**7" < SEEK+>

To delete pairing dial "DEL" <SEEK+> from the number keyboard or 335 <SEEK+>.

Alternative command is "**3" < SEEK+>

MOST 4+2 FOT Connector Plug pinout is shown below looking from the rear side.



Pairing to cars with single line Head Unit display

When in phone only mode press Tel button and dial **7 then press SEND




Some head units does not allow * dialing so alternative way for pairing is dialing "DIAL" or 7247 then press SEND



On your phone search for the accessory audio device "Carmedia" and select to pair. The default pairing code is "0000".



After successful pairing the phone signal strength bars will be shown at the upper right corner of the head unit.



To delete Bluetooth pair press Tel button and dial
**3 then press SEND



Some head units does not allow * dialing so alternative way for pairing is dialing "DEL" or 335 then press SEND



After the pairing is deleted the phone signal strength bars will disappear from the upper right corner of the head unit.



When the head unit is in the full featured or wireless only modes be sure that the audio interface is running and the CD6 is selected as shown below.



Press and hold "SEEK+" until the time of the track is shown and message will sound: "Please select the hands-free ... and enter pin code 0000"



Paring is completed with the announcement "Phone connected" and the display shows the phone signal bars.



After the phone book is downloaded press >> to go to voicemail

