


ink-Man® User's Manual

H800C/P

Refill System of color-Ink for HP 700, 800, 1100 Series
HP51641A, HP1823A

• Easy & Fast

Save money.
Best print quality.
Preserve our environment.



• Before use

- Choose a suitable Ink-man product for your printer.
- Before the nozzle dries out, refill the empty cartridge.
- In case that the nozzle has completely dried out, the printer may not give you satisfactory copies.
- New cartridge can be re-cycled about 8 times with ink refill.
- You can save as much money as the price of your printer with 8 times refill.
- Refilling with Ink-man products will not cause any problem for your printer.
- The cartridge head could possibly be out of order when we refill in the totally empty cartridge.
- The best way to refill is to add Ink-mans refill ink before your cartridge dries up.
- Do not touch the nozzle and keep out of moisture and unnecessary substance from the nozzle area.

Caution

1. Do not drink or inhale.
2. Keep out of reach of children.
3. In case of getting ink into eye, wash with fresh water and get prescription from a doctor.
4. Be careful not to be hurt by dispensing needle while refilling.
5. After use, cover the needle with cap, and discard it to an appropriate place.

Figure 1.

- 1) Push the cap plugging refill hole downward into the cartridge using tools as like ballpoint pen.
- 2) Put on the enclosed tissue pad on the cartridge nozzle.





Figure 2.

- 3) Remove the cap from syringe, and assemble the injection needle and the plunger. (counter clockwise: disassemble, clockwise: assemble)



All brand names and trademarks are the property of their respective owners.

Figure 3.

- 4) Insert deeply the needle into cartridge after checking color inside of cartridge, and then inject 10ml of ink per color very slowly.
- 5) Caution
If you inject the ink into a wrong position, the printing color may not be acquired properly.





Figure 4.

- 6) Seal the refill hole with the enclosed plastic stopper and remove the tissue pad. By using soft tissue, clean both the nozzle and the bottom of the cartridge.
- 7) In case of refilling again, insert needle into hole of the plastic stopper.



Ink can be mixed up in the nozzle position if refilling fast.
Print out 2 or 3 copies with color graphic, when different colors be mixed in the nozzle.

• Troubles shooting

- Trouble/Consecutive white line on the paper. Cause/Cartridge head might be hurt.
Treatment/If the problem can not be solved with head cleaning, the cartridge should be replaced with a new one.
- Trouble/Not working or error message on the printer after installing cartridge.
Cause/Moisture or ink on the Metallic Surface of cartridge.
Treatment/Clean moisture or ink on the metallic surface of cartridge.
- Trouble/irregular printing or no printing after refill.
Treatment/Place the cartridge on a wet tissue. Let a small amount of ink flow on the tissue.
Use after head cleaning two or three times.
- Before printing
 - Although a small amount of ink may leak out from nozzle area during refill, it can be solved by self-controlling within a minute.
 - With soft tissue, wipe out ink and unnecessary substance from the nozzle.Install the refilled cartridge to the printer and make sure that there is no more ink leaking.
"Head cleaning" is recommended before use in order to obtain high performance of printing.

EC World

TEL: +82-2-3281-6400, FAX: +82-2-3275-0025
http://www.inkman.co.kr e-mail: info@inkman.co.kr