

Q1048 Wicked Colors™ *Color Changing Candle Holder*

Enjoy the enduring beauty of color with the Wicked Colors candle holder. Watch as it glows from deep within, slowly changing across a rainbow of tones in perfect harmony with the dancing flame of the tea candle. Combines the classic touch of an open flame with the latest LED technology. Energy efficient design insures extra long battery life for extended enjoyment. Comes with 4 tea candles or burn your own scented tea candles.

APPLICATIONS:

Indoors: Use scented or unscented tea candles. Place the candle holder in a safe location for unique decorative illumination.

Outdoors: Use citronella tea candles to help repel insects.

⚠ WARNING: Follow these safety instructions to avoid injury and damage from fire or smoke:

- **Make sure the tea candle is placed properly in the candle holder so it does not fall out.**
- **Make sure the candle holder is placed on a stable heat-resistant surface where it will not fall to the floor.**
- **Keep out of reach of children.**
- **Do not burn candles unattended. Extinguish all burning candles before leaving the area. Do not move a burning candle.**
- **Use care when extinguishing candles to avoid injury and burns.**
- **Do not handle candle holder or tea candles while hot. Allow them to cool first.**
- **Use care to avoid contact with molten wax.**
- **Only burn citronella candles outdoors or in well ventilated areas.**

INCLUDES:

- **1 Wicked Colors™ Candle Holder**
- **4 Unscented tea candles**
- **These instructions**

HOW TO OPERATE:

- Remove any plastic wrap. Remove the battery door on the bottom of the unit. Install 2X C alkaline batteries (not included). Orient the negative side of the battery toward the spring contacts. Close the battery door.
- Move the power switch to the ON position. Observe the LED illumination. If LED does not light, batteries are empty. Replace them.
- To turn the unit off, move the power switch to the OFF position. Observe the LED will no longer illuminate. Do not operate the ON/OFF switch while the tea candle is burning or the wax is molten.
- Insert the tea candle in the glass cup on top of the candle holder. Make sure the tea candle is placed properly so it does not fall out. Light candle.
- When tea candle is fully burned, remove it and discard properly once it has cooled.

SPECIFICATIONS:

Height: 4.6" Diameter: 3.1"

Weight: 14 oz.

Batteries: 2x C alkaline cells (not included)

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only, that its product is free from defects in material or workmanship under the condition of normal use and service for a period of ninety (90) days from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of ninety (90) days from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defeat of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your unit, or if your unit requires repair please contact:

P3 INTERNATIONAL CORPORATION
TECHNICAL SUPPORT

Tel: 212-741-7289

Fax: 212-741-2288

Email: techsupport@p3international.com

rev. 11/05

Specifications subject to change without notice.