


## SHEERSASH 34 WINDOW SYSTEM



#### PRODUCT MANUAL

Disclaimer: The right to make alterations is reserved © 2010 Sheerline, All Rights Reserved

Revision: 01/10/2010



#### LEGAL DISCLAIMER

All information, recommendations or advice contained in this documentation is given in good faith to the best of Sheerline's knowledge and is based on current procedures in effect.

Since the actual use of this documentation by the user is beyond the control of Sheerline, such use is within the exclusive responsibility of the user. Sheerline cannot be held responsible for any loss incurred through incorrect or faulty use of this documentation.

Great care has been taken to ensure that the information provided is correct. Sheerline will accept no responsibility for any errors and/or omissions, which may have inadvertently occurred.

All mechanical joints must be sealed with a Sheerline approved joint sealer.

Laminated glass must not stand in water.

All drawings in the Sheerline Documentation are shown NOT to scale.

Sheerline cannot accept responsibility for the use of standard products since Sheerline does not know where these products are being installed.

The use of anti-magnetic stainless steel screws and pop rivets is recommended to reduce galvanic corrosion in harsh environments.

The hardware recommended in this documentation is suitable for use in most atmospheric environments. When hardware is used in severe costal environments the manufacturer of the hardware must be consulted.


Fixing lugs on frames must be positioned as per the user manual and used in accordance to the AAAMSA specifications. When profiles are screwed together the screw centers must also be according to the user manual.

All glass used within Sheerline products must comply with SAGGA regulations.

By continuing to use this documentation you acknowledge that you understand and accept the legal disclaimer.


### SHEERSASH 34 WINDOW SYSTEM PROFILE IDENTIFICATION





### SHEERSASH 34 WINDOW SYSTEM PROFILE IDENTIFICATION






Disclaimer: The right to make alterations is reserved © 2010 Sheerline, All Rights Reserved

### SHEERSASH 34 WINDOW SYSTEM HARDWARE IDENTIFICATION





#### \* MAINTENANCE OF STAINLESS STEEL FRICTION STAYS


To preserve the appearance and prevent corrosion, wipe down Friction Stays with warm water and a mild detergent. For stubborn dirt or stains, use a non corrosive cleaner, for more aggressive stains add a small amount of vinegar to water. Carbon steel brushes and steel wool should be avioded as they may leave particles embedded in the surface which may lead to rusting. After cleaning rinse with hot water and dry using a clean cloth.

Cleaning is recommended once a month or more frequently when subjected to regular use or heavy soiling.


### SHEERSASH 34 WINDOW SYSTEM SASH LIMITATION CHARTS



		Maximum Vent Width in mm	Maximum Vent Height in mm
Top Hung	3401	1200	900




		Maximum Vent Width in mm	Maximum Vent Height in mm
Side Hung	3401	700	1500



#### STANDARD TOP HUNG SHEERSASH 34 WINDOWS 600Pa WINDLOAD




- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.



#### STANDARD TOP HUNG SHEERSASH 34 WINDOWS 1000Pa WINDLOAD




- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.



#### STANDARD TOP HUNG SHEERSASH 34 WINDOWS 1500Pa WINDLOAD



- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.



#### STANDARD SIDE HUNG SHEERSASH 34 WINDOWS 600Pa WINDLOAD



- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.

	<mark>600</mark> (590)	900 (890)	1 200 (1190)	1 500 (1490)	1 800 (1790)	2 400 (2390)
600 (590)						
900 (890)	340 -0609S	340 -0909\$	340 -1209S	340 -15098	340 -1809SS	340 -2409\$\$
1200 (1190)	340 -0612S	340 -0912S	340 -1212S	340 -1512S	340 -1812SS	340 -2412\$\$
1500 (1490)	340 -0615S	340 -09158	340 -12158	340 -1515S	340 -1815SS	340 -2415SS
1800 (1790)	340 -0618S	2000 MIPW EE99	340 -1218S	340 -1518S	340 -1818SS	25 25 20 IM IN

#### STANDARD SIDE HUNG SHEERSASH 34 WINDOWS 1000Pa WINDLOAD



- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.

	600 (590)	900 (890)	1 200 (1190)	1 500 (1490)	1 800 (1790)	2 400 (2390)
600 (590)						
900 (890)	340 -0609\$	340 -0909S	340 -1209S	340 -15098	340 -1809SS	340 -2409SS
1200 (1190)	340 -0612S	340 -0912S	340-12128	340 -1512S	340 -1812SS	340 -2412SS
1500 (1490)	340 -0615S	340 -0915S	340 -1215S	2920 Mill M 1000 M	28 20 1	340 -2415SS
1800 (1790)	340 -0618\$	25001 MIIIM EE99 340 -09185	2920 LM III M 10299 340 -1218S	2920 I M III M Wall 99	25 25 25 25 25 25 25 25 25 25 25 25 25 2	25 20 I.M. IDM ELE 99 340 -2418SS

#### STANDARD SIDE HUNG SHEERSASH 34 WINDOWS 1500Pa WINDLOAD




- 1. SEE THE MULLION LIMITATION CHART
- 2. OPENING SIZES SHOWN IN RED
- 3. ACTUAL WINDOW SIZES SHOWN IN BLACK AND BRACKETS.

400	600 (590)	<b>900</b> (890)	1 200 (1190)	1 500 (1490)	1 800 (1790)	2 400 (2390)
600 (590)						
<mark>900</mark> (890)	340 -0609\$	340 -0909\$	340 -12098	340 -15098	340 -1809SS	340 -2409SS
1200 (1190)	340 -0612S	340 -0912S	2520 Muli W N10256 W N10255	340 -1512S	340 -1812SS	340 -2412SS
1500 (1490)	340 -0615S	340 -0915S	340 -1215S	2520 IW IIM MER 863 1915 1915 1915 1915 1915 1915 1915 191	28 20 0 1 M   M   M   M   M   M   M   M   M   M	340 -2415SS
1800 (1790)	340 -0618\$	2920 Mill M 10262	79201M Mul W10263		340 -1818SS	


## SHEERSASH 34 SYSTEM STANDARD TOP HUNG WINDOW TYPICAL CONFIGURATIONS







## SHEERSASH 34 SYSTEM STANDARD SIDE HUNG WINDOW TYPICAL CONFIGURATIONS









B SIDE HUNG OVER FIXED



C FIXED OVER SIDE HUNG




TOP HUNG OVER SIDE HUNG



CC SIDE HUNG NEXT TO SIDE HUNG

## SHEERSASH 34 SYSTEM COTTAGE PANE WINDOW FIXED PANEL TYPICAL CONFIGURATIONS





# SHEERSASH 34 SYSTEM COTTAGE PANE WINDOW TOP HUNG & SIDE HUNG TYPICAL CONFIGURATIONS



#### TOP HUNG




P 2 x 1 PANE SINGLE TOP HUNG



R 3 x 1 PANE SINGLE TOP HUNG




Q 2 x 2 PANE SINGLE TOP HUNG




3 x 2 PANE SINGLE TOP HUNG

#### SIDE HUNG




P 2 x 3 PANE SINGLE SIDE HUNG




2 x 4 PANE SINGLE SIDE HUNG

### SHEERSASH 34 WINDOW SYSTEM FASTENING POSITIONS








#### General:

The window is fixed into position - the sill is then built at a later stage - the bottom lugs can be left in place but it is often found that most times the mason either bends them out of his way or breaks them off. This practically means that most windows are only secured on 3 sides.


## SHEERSASH 34 WINDOW SYSTEM TYPICAL COUPLING CONFIGURATIONS






MULLION COUPLING DETAIL EQUAL LEG OUTER FRAME & SMALL T COUPLING MULLION (3401 + W11019)

MAXIMUM HEIGHT: 1500mm




MULLION COUPLING DETAIL SHORT LEG OUTER FRAME & SMALL T COUPLING MULLION (3410 + W11019)

MAXIMUM HEIGHT: 1500mm



MULLION COUPLING DETAIL EQUAL LEG OUTER FRAME & BIG T COUPLING MULLION 3404 + W10593)

MAXIMUM HEIGHT: 1500mm





MULLION COUPLING DETAIL SHORT LEG OUTER FRAME & BIG T COUPLING MULLION (3410 + W10593)

MAXIMUM HEIGHT: 1500mm

### SHEERSASH 34 WINDOW SYSTEM FASTENING POSITIONS








#### General:

The window is fixed into position - the sill is then built at a later stage - the bottom lugs can be left in place but it is often found that most times the mason either bends them out of his way or breaks them off. This practically means that most windows are only secured on 3 sides.


## SHEERSASH 34 WINDOW SYSTEM TYPICAL CROSS SECTIONAL DETAIL DOUBLE TOP HUNG OVER FIXED







#### SHEERSASH 34 WINDOW SYSTEM TYPICAL CROSS SECTIONAL DETAIL SIDE HUNG OVER FIXED









SECTION A - A




SECTION C - C





#### SHEERSASH 34 WINDOW SYSTEM OUTER FRAME COMPONENT ASSEMBLY DETAIL






Disclaimer: The right to make alterations is reserved © 2010 Sheerline, All Rights Reserved


## SHEERSASH 34 WINDOW SYSTEM SASH FRAME COMPONENT ASSEMBLY DETAIL






## SHEERSASH 34 WINDOW SYSTEM EQUAL LEG OUTER FRAME SILL LEVEL & MACHINING DETAIL






## SHEERSASH 34 WINDOW SYSTEM SHORT LEG OUTER FRAME SILL LEVEL & MACHINING DETAIL






## SHEERSASH 34 WINDOW SYSTEM SIDELIGHT FRAME 72mm SILL LEVEL & MACHINING DETAIL






## SHEERSASH 34 WINDOW SYSTEM SIDELIGHT BOX SILL 72mm SILL LEVEL & MACHINING DETAIL






#### SHEERSASH 34 WINDOW SYSTEM STANDARD MULLION MACHINING DETAIL FOR END MILLING ON EQUAL LEG OUTER FRAME






#### SHEERSASH 34 WINDOW SYSTEM STANDARD MULLION MACHINING DETAIL FOR END MILLING ON SHORT LEG OUTER FRAME






#### SHEERSASH 34 WINDOW SYSTEM STANDARD MULLION MACHINING DETAIL FOR END MILLING ON SIDELIGHT FRAME 72mm






#### SHEERSASH 34 WINDOW SYSTEM STANDARD MULLION MACHINING DETAIL FOR END MILLING ON SIDELIGHT BOX SILL 72mm






# SHEERSASH 34 WINDOW SYSTEM COTTAGE PANE MULLION MACHINING DETAIL FOR END MILLING ON EQUAL LEG OUTER FRAME







# SHEERSASH 34 WINDOW SYSTEM COTTAGE PANE MULLION MACHINING DETAIL FOR END MILLING ON SHORT LEG OUTER FRAME











# SHEERSASH 34 WINDOW SYSTEM COTTAGE PANE MULLION MACHINING DETAIL FOR END MILLING ON SIDELIGHT FRAME 72mm






# SHEERSASH 34 WINDOW SYSTEM COTTAGE PANE MULLION MACHINING DETAIL FOR END MILLING ON SIDELIGHT BOX SILL 72mm






#### SHEERSASH 34 WINDOW SYSTEM CORNER CLEAT ASSEMBLY DETAIL FOR TUBULAR SASH






#### SHEERSASH 34 WINDOW SYSTEM GLAZING BAR FRAME JOINT ASSEMBLY DETAIL





#### SHEERSASH 34 WINDOW SYSTEM CROSS JOINT ASSEMBLY DETAIL STANDARD MULLION






Disclaimer: The right to make alterations is reserved © 2010 Sheerline, All Rights Reserved

## SHEERSASH 34 WINDOW SYSTEM CROSS JOINT ASSEMBLY DETAIL COTTAGE PANE MULLION





### SHEERSASH 34 WINDOW SYSTEM GLAZING PROCEDURE




Insert the pull-in vinyl gasket into glazing beads by sliding or pressing it into the groove (1). Before cutting gasket, ensure that it has not stretched and cut 6mm longer so that corners are in compression at all times.


Position bottom glazing bead in glazing bead rebate (2).

Place glass on glazing blocks (3).


Insert top and then side glazing beads ensuring that they are in correctly.

Starting from top centre, insert roll in gasket (4) without stretching it (5). Stop 150mm from corner and partly cut gasket 6mm longer than the edge of the vertical bead. Insert gasket at corner and then roll in remaining 150mm. Repeat this on the other sides. Where gasket ends meet, cut gasket 6mm longer. Insert cut ends first and complete.





ENSURE GASKETS ARE NOT STRETCHED AT ANY STAGE



Disclaimer: The right to make alterations is reserved © 2010 Sheerline, All Rights Reserved

### SHEERSASH 34 WINDOW SYSTEM GLAZING PROCEDURE CONTINUED



#### **GLAZING**

#### 1. SELECTION OF GLAZING METHODS

#### 1.1 SETTING AND LOCATION BLOCKS

Glass-to-metal contact must be avoided at all times by using setting and location blocks having a hardness of 50° to 90° shore A durometer. Use only blocks made of Neoprene, EPDM, Silicone or other elastomeric material.

Setting blocks are to have a minimum thickness of 3mm and must be at least 27mm in length per square metre of glass area.

In the event of laminated glass and/or sealed insulated glass units drainage is to be provided to prevent the glass edge to be submerged. Two or more 7mm diameter holes or 5mm x 9mm slotted holes, or larger, are to be equally spaced in the sill section of sash or frame to allow for such ventilation/drainage.

The position of the setting and location blocks is illustrated in Figure 2.





FIGURE 2 - POSITION OF SETTING AND LOCATION BLOCKS


### SHEERSASH 34 WINDOW SYSTEM FRICTION STAY ASSEMBLY DETAIL






### SHEERSASH 34 WINDOW SYSTEM HANDLE ASSEMBLY DETAIL





NO 8 x 10 COUNTERSUNK SELF-TAPPING FLAT END SCREWS



### SHEERSASH 34 WINDOW SYSTEM FIXING LUG PREPARATION DETAIL



