# **User Manual of Tie Camera JVE-3305**

# Product Accessories

- Tie camera USB cable Remote Control
- User manual CD Charger

# Picture & Buttons



1. Power on/off 2. Camera 3. USB Port 4. LED 5.Remote Control

# Technical Data

- 1) Functions: recording video and audio, USB drive
- 2 ) Video: AVI, 640\*480 resolution
- 3 ) Internal Memory: 2GB/4GB/8GB
- 4 ) USB: 2.0 ( Hs )
- 5) Charging time:4-5 hours
- 6 ) Battery use time: built-in Li battery, 1-2 hours

7 ) Operation systems: No need for driver installation if the operating system is Windows ME/ 2000/ XP/ VISTA or above (windows98 is excepted)

# Operation

#### Switch on

After opening zip of tie, push the power switch to "ON" position, the camera comes to power-saving mode.

#### Record video

- 1) Under electricity-saving mode, press the remote control button for 2 seconds, the green light is on, after 2 seconds the green light will blink, which indicates that the camera is recording.
- 2) Press the remote control again, it will begin to save data and the green light stop blinking and keep on, the camera come to standby mode.

**Attention**: if no operation during 30 seconds, the green light will be off, the camera comes to electricity-saving mode.

#### Switch off

Under standby mode or power-saving mode, push the power to "OFF" position, the camera will turn off.

**Attention**: In order to save power, please turn off when you don't use the product.

### Charging

Under power off mode, connect the camera via USB with the charger, the green light of the charger will turn on. The green light turns off when it is fully charged.

### Playback

After recoding, switch on the camera, at the standby mode, connect the camera to the computer via USB cable, then the files can be played in the computer. Before connecting please make sure the computer has been installed the related playing software.

### Setting Time

When using the device for the first time, you can set the time of video as follows:

- 1) Connect the camera with computer
- 2) Create a new "PHTIME.txt" file
- 3) Edit time as format: 2009-12-12 12:12:12 in the file
- 4) Copy the file to the root of the disk of the camera
- 5) When starting the camera again next time, the time will be simultaneous as the time file.

**Attention**: Please keep power on when you set time, otherwise it will skip to the default time.

### Attention

- 1) When the device is lack of battery when taking video, the system will save the video data first, then shut down automatically.
- 2) When taking video continually, the system will automatically generate a new video file after each operation.
- 3) As the device has built-in high-capacity polymer lithium battery, so it has a memory effect .We advise in the first 5 times of usage, charge the battery fully after the battery is out of use, so that the battery can work with its max working hours perfectly.