

# MONSTER Tower of Music Quick Start Guide

Portable, Wireless Speaker with built in Bluetooth, NFC and EZ-Play Features

For complete operational guidelines, please refer to your user manual.

## Basic Set up

### 1 Connect the AC Power



- Connect the included AC Cable to the Tower of Music.
- Plug cord into wall outlet.
- Charge battery for approximately 10 hours before you start using the unit for the first time.

### 2 Charge built-in batteries on the Monster Tower



- By connecting the AC power, battery will be charged and Red LED will turn on.
- Red LED indicator means that unit is plugged in and charging.
- Red LED indicator will turn off when unit is fully charged.
- If Red LED indicator is flashing, this means that the battery levels are low and need charging.

### 3 Bluetooth pairing with NFC enabled device

- Turn on NFC function on your Bluetooth enabled device.
- Place your Bluetooth device on the silkscreen "NFC" on the top surface of the Monster Tower.
- Confirm Bluetooth connection on your Bluetooth device.
- Blue LED indicator on the Monster Power will be solid.



- Once paired you can play audio from your Bluetooth device and audio can be heard through the speaker.

Note: If pairing won't complete automatically, your Bluetooth device might not be NFC enabled.

Skip to Step 5 so that you can manually complete pairing.

## Bluetooth® Connection

### 4 Manual Bluetooth Pairing



Press and hold BT button for 2 seconds



Blue LED Indicator (Flashing Rapidly)



- Place the Monster Tower and your Bluetooth device so that they are no more than 3 feet apart.
- Press and hold the Bluetooth button on the Monster Tower for 2 Seconds to enter into Bluetooth pairing mode.
- Bluetooth LED will flash rapidly.

- Set your Bluetooth device to search for Bluetooth connections. You will recognize the speaker by its Bluetooth name "Monster Tower".



EZ-Play allows you to easily connect up to 8 speakers wirelessly and broadcast your favorite music to all speakers simultaneously to create an Audio Surround Experience indoors or outdoors.

\*EZ-Play technology also available on Monster BTW248XBK

### 5 EZ-Play wireless connection



- Press and hold the "EZ Play" button on the speaker for 3 seconds to send a connection request to a second unit.

NOTE: This function can only be completed with other EZ Play speakers.

- EZ Play Amber LED will pulse on the transmitting speaker.
- Press and hold the "EZ Play" button on the transmitting speaker for 3 seconds to scan for a connection request from the receiving speaker.
- EZ Play Amber LED on both units will turn solid upon completion of connection.